## CX15EV

Mini Excavator

# **OPERATOR'S MANUAL**





## COMMISSIONING

Fill-in before commissioning	of the equipment:
Machine model:	
Machine serial no./PIN:	
Engine Serial No.:	
Year of construction:	
Commissioned on:	
Dealer:	

1.1 - Regarding this manual       1-1         1.1.1 - Manual consultation and terminology       1-3         1.2 - Machine identification data       1-7         1.3 - Manufacturer       1-10         1.4 - Spare Parts       1-10         1.4 - Spare Parts       1-11         1.5 - Information to the owner of the machine       1-12         1.6 - Intended use       1-13         1.7 - Prohibited use       1-14         1.8 - CE Declaration of Conformity       1-16         2 - SAFETY       2-1         2.1 - Safety symbol       2-1         2.2 - General safety       2-1         2.1 - Manual safety sign consultation       2-3         2.3 - Safety signs and operation related labels       2-3         2.3 - Safety signs and operation related labels       2-5         2.4 - Machine driver       2-1         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-24         2.8 - Safety devices       2-24         2.8 - Safety devices       2-24         2.8	1 - INTRODUCTION	1-1
1.2 - Machine identification data       1.7         1.3 - Manufacturer       1-10         1.3.1 - Contact the after-sales network       1-11         1.4 - Spare Parts       1-11         1.5 - Information to the owner of the machine       1-12         1.6 - Intended use       1-13         1.7 - Prohibited use       1-14         1.8 - CE Declaration of Conformity       1-16         2 - SAFETY       2-1         2.1 - Safety symbol       2-1         2.2 - General safety       2-1         2.1 - Manual safety sign consultation       2-3         2.3 - Safety signs and operation related labels       2-5         2.4 - Machine driver       2-14         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-27         2.8 - Safety devices       2-27         2.8 - Safety devices       2-24         2.8.1 - Operator protective structure       2-42         2.8.1 - Operator protective structure       2-42         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever </th <th>1.1 - Regarding this manual</th> <th>1-1</th>	1.1 - Regarding this manual	1-1
1.3 - Manufacturer       1-10         1.3.1 - Contact the after-sales network       1-10         1.4 - Spare Parts       1-11         1.5 - Information to the owner of the machine       1-12         1.6 - Intended use       1-13         1.7 - Prohibited use       1-14         1.8 - CE Declaration of Conformity       1-16         2 - SAFETY       2-1         2.1 - Safety symbol       2-1         2.2 - General safety       2-1         2.2.1 - Manual safety sign consultation       2-3         2.3 - Safety signs and operation related labels       2-5         2.4 - Machine driver       2-1         2.4.1 - Personal Protective Equipment (PPE)       2-16         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-27         2.8 - Safety devices       2-27         2.8.1 - Operator protective structure       2-42         2.8.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Emergency stop button       2-48         3.5 - Emergency stop button       2-48         3.5 - Encertical system		
1.3.1 - Contact the after-sales network       1-10         1.4 Spare Parts       1-11         1.5 - Information to the owner of the machine       1-12         1.6 - Intended use       1-13         1.7 - Prohibited use       1-14         1.8 - CE Declaration of Conformity       1-16         2 - SAFETY       2-1         2.1 - Safety symbol       2-1         2.2 - General safety       2-1         2.2 - 1 - Manual safety sign consultation       2-3         2.3 - Safety signs and operation related labels       2-3         2.4 - Machine driver       2-14         2.4 - Yachine driver       2-14         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.7 - Safety procedures       2-17         2.8 - Safety devices       2-27         2.8 - Safety devices       2-27         2.8 - Safety devices       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.4 - Slewing locking lever       2-44         2.8.5 - Emergency stop button		
1.4 - Spare Parts       1-11         1.5 - Information to the owner of the machine       1-12         1.6 - Intended use       1-13         1.7 - Prohibited use       1-14         1.8 - CE Declaration of Conformity       1-16         2 - SAFETY       1-16         2 - Safety symbol       2-1         2.1 - Safety signs on safety       2-1         2.2 - General safety       2-1         2.3 - Safety signs and operation related labels       2-3         2.3 - Safety signs and operation related labels       2-2         2.4 - Machine driver       2-1         2.5 - Work Area - Hazard Zone - No Entry Zone       2-1         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-27         2.8 - 1 - Operator protective structure       2-42         2.8.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-42         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       <	1.3 - Manufacturer	1-10
1.5 - Information to the owner of the machine       1-12         1.6 - Intended use       1-13         1.7 - Prohibited use       1-14         1.8 - CE Declaration of Conformity       1-16         2 - SAFETY       2-1         2.1 - Safety symbol       2-1         2.2 - General safety       2-1         2.3 - Safety signs and operation related labels       2-3         2.3 - Safety signs and operation related labels       2-5         2.4 - Machine driver       2-14         2.4.1 - Personal Protective Equipment (PPE)       2-16         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-42         2.8.3 - Controls cut-out lever       2-43         2.8.4 - Slewing locking lever       2-44         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply		
1.6 - Intended use       1-13         1.7 - Prohibited use       1-14         1.8 - CE Declaration of Conformity       1-16         2 - SAFETY       2-1         2.1 - Safety symbol       2-1         2.2.1 - Manual safety sign consultation       2-1         2.3 - Safety signs and operation related labels       2-3         2.4 - Machine driver       2-14         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-48         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3 <td>1.4 - Spare Parts</td> <td> 1-11</td>	1.4 - Spare Parts	1-11
1.7 - Prohibited use       1-14         1.8 - CE Declaration of Conformity       1-16         2 - SAFETY       2-1         2.1 - Safety symbol       2-1         2.2 - General safety       2-1         2.2.1 - Manual safety sign consultation       2-3         2.3 - Safety signs and operation related labels       2-5         2.4 - Machine driver       2-14         2.4.1 - Personal Protective Equipment (PPE)       2-16         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-27         2.8 - Safety devices       2-27         2.8.1 - Operator protective structure       2-42         2.8.1 FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2		
1.8 - CE Declaration of Conformity.       1-16         2 - SAFETY       2-1         2.1 - Safety symbol       2-1         2.2 - General safety.       2-1         2.2.1 - Manual safety sign consultation       2-3         2.3 - Safety signs and operation related labels       2-5         2.4 - Machine driver       2-14         2.4.1 - Personal Protective Equipment (PPE)       2-16         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3     <		
2 - SAFETY       2-1         2.1 - Safety symbol       2-1         2.2 - General safety       2-1         2.2.1 - Manual safety sign consultation       2-3         2.3 - Safety signs and operation related labels       2-5         2.4 - Machine driver       2-14         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.4 - Slewing locking lever       2-46         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.11 - Undercarriage <t< td=""><td></td><td></td></t<>		
2.1 - Safety symbol       2-1         2.2 - General safety       2-1         2.2.1 - Manual safety sign consultation       2-3         2.3 - Safety signs and operation related labels       2-5         2.4 - Machine driver       2-14         2.4.1 - Personal Protective Equipment (PPE)       2-16         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4 <tr< td=""><td>1.8 - CE Declaration of Conformity</td><td> 1-16</td></tr<>	1.8 - CE Declaration of Conformity	1-16
2.2 - General safety       2-1         2.2.1 - Manual safety sign consultation       2-3         2.3 - Safety signs and operation related labels       2-5         2.4 - Machine driver       2-14         2.4.1 - Personal Protective Equipment (PPE)       2-16         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5 <tr< th=""><th>2 - SAFETY</th><th> 2-1</th></tr<>	2 - SAFETY	2-1
2.2 - General safety       2-1         2.2.1 - Manual safety sign consultation       2-3         2.3 - Safety signs and operation related labels       2-5         2.4 - Machine driver       2-14         2.4.1 - Personal Protective Equipment (PPE)       2-16         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5 <tr< td=""><td>2.1 - Safety symbol</td><td>2-1</td></tr<>	2.1 - Safety symbol	2-1
2.3 - Safety signs and operation related labels       2-5         2.4 - Machine driver       2-14         2.5 - Work Area - Hazard Zone - No Entry Zone       2-16         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity		
2.4 - Machine driver       2-14         2.4.1 - Personal Protective Equipment (PPE)       2-16         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity	2.2.1 - Manual safety sign consultation	2-3
2.4.1 - Personal Protective Equipment (PPE)       2-16         2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7	2.3 - Safety signs and operation related labels	2-5
2.5 - Work Area - Hazard Zone - No Entry Zone       2-17         2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
2.6 - List of Residual Risks       2-19         2.7 - Safety procedures       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-46         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
2.7 - Safety procedures.       2-27         2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
2.8 - Safety devices       2-42         2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
2.8.1 - Operator protective structure       2-42         2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
2.8.1.1 - FOPS Level I canopy (optional)       2-44         2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7	2.8 - Safety devices	2-42
2.8.2 - Seat belt       2-44         2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
2.8.3 - Controls cut-out lever       2-46         2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
2.8.4 - Slewing locking lever       2-47         2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
2.8.5 - Emergency stop button       2-48         3 - TECHNICAL INFORMATION       3-1         3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
3.1 - General data       3-1         3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7	2 TECHNICAL INFORMATION	2.4
3.2 - Engine       3-2         3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		_
3.3 - Power supply       3-2         3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
3.4 - Battery charge times       3-2         3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
3.5 - Electrical system       3-3         3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
3.6 - Hydraulic system       3-3         3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
3.7 - Performances       3-4         3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
3.8 - Digging arm       3-4         3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
3.9 - Counterweight       3-5         3.10 - Dozer blade       3-5         3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
3.10 - Dozer blade		
3.11 - Undercarriage       3-5         3.12 - Brakes       3-6         3.13 - Nominal lifting capacity       3-7		
3.12 - Brakes		
3.13 - Nominal lifting capacity3-7		

3.15 - Rotary structure	3-15
3.16 - Fluid capacities	3-15
3.17 - Overall dimensions	3-16
3.18 - Sound emission	3-20
3.19 - Vibrations	3-21
4 TRANSPORTING THE MACHINE	
4 - TRANSPORTING THE MACHINE	
4.1 - Shipping dimensions	
4.2 - Loading/unloading operations	4-3
4.3 - Securing the machine on the means of transport	
4.4 - Lifting of the machine	4-9
4.4.1 - Lifting procedure	
4.5 - Recovering and towing the machine	4-12
5 - CONTROLS AND TOOLS	5-1
5.1 - Description of main controls and levers	
5.2 - Description of left control console	
5.3 - Description of right control console	5-3
5.4 - Roller operation	
5.5 - Optional electrical buttons on the joystick	
5.6 - Auxiliary power socket on console	
5.7 - Machine status warning indicators	
5.8 - Control panel	
5.9 - Display	
5.10 - Battery disconnect switch (emergency stop button)	
5.11 - Geo-localisation system	
6 - USING THE MACHINE	
6.1 - Commissioning	
6.2 - Battery disconnect switch (emergency stop button)	
6.3 - Driver's seat	
6.4 - Arm rests	
6.6 - Controls cut-out lever	
6.7 - Slewing locking lever	
6.9 - Control panel operation6.9	
6.10 - HOME page	
6.10 - HOME page	
6.10.2 - Machine hours	
6.10.3 - Control mode	
6.10.4 - Engine data and battery data	
6.10.5 - Pop-up messages (information/alarms)	6-13
6.10.6 - Warning indicators	6-14
6.10.7 - Menu button	6-14
6.10.8 - Working light switch	6-14
6.10.9 - Dozer blade mode/undercarriage width indicator light	6-15

6.10.10 - Work mode management	
6.11 - MENU screen	
6.11.1 - BATTERY screen	
6.11.2 - ENGINE screen	
6.11.3 - EQUIPMENT screen	6-18
6.11.3.1 - Equipment SETTINGS sub-menu	
6.11.4 - TEMPERATURES screen	
6.11.5 - SOFTWARE screen	
6.11.6 - SERVICE screen	
6.11.7 - SETTINGS screen	
6.11.7.1 - CONTROL START MODE	
6.11.7.2 - PRESSURE RELIEF	
6.11.7.3 - PARTIAL HOURS RESET	
6.11.7.4 - LANGUAGE sub-menu	
6.11.7.5 - DATE/TIME sub-menu	
6.11.7.6 - DISPLAY BRIGHTNESS	
6.11.7.7 - COMMAND CONFIGURATION	
6.11.7.8 - UNIT OF MEASURE	
6.11.8 - CONTROL MODE screen	
6.11.8.1 - INDIVIDUAL sub-menu	
6.12 - Visibility	6-27
6.12.1 - Travel position	
6.13 - Starting the machine	6-29
6.13.1 - Checks prior to the start up	
6.13.2 - Procedure for starting the machine	
6.14 - Battery power	
6.15 - Machine charging mode	6-38
6.15.1 - On-board battery charger	6-40
6.15.2 - Portable battery charger (optional)	6-42
6.16 - Electrical isolation	6-44
6.17 - Horn	6-45
6.18 - Working lights	
6.19 - Operating at low temperatures	
6.20 - Precautions during operation	6-47
6.21 - Stopping the machine	6-50
6.22 - Machine movement	
6.22.1 - Forward and reverse travel	
6.22.2 - Pivoting the machine around its axis	6-54
6.22.3 - Turning while moving forward	6-55
6.22.4 - Turning while reversing	
6.22.5 - Precautions during the operation of the tracks	6-57
6.23 - Travel speed	6-50
6.24 - Dozer blade control/undercarriage width adjustment lever	6 60
6.24.1 - Dozer blade control lever	
6.24.1 - Dozer blade control lever	0-00
6.25 - Extendible dozer blade	
6.26 - Parking the machine	
6.27 - Operating the boom	
6.27.1 - Left Joystick	6-68

6.27.2 - Right joystick	6-69
6.27.3 - ISO-SAE controls layout TPSS function	
6.28 - Boom swing/AUX2 hydraulics system selector button (optional)	
6.29 - Boom swing control	
6.30 - Discharge residual pressure in the hydraulic system	6-74
6.31 - Auxiliary hydraulic systems	6-75
6.31.1 - Connection of equipment to the hydraulic systems	6-76
6.31.2 - Connections on second boom	6-77
6.31.3 - AUX1 Auxiliary hydraulic system	6-78
6.31.3.1 - AUX1 hydraulic system three-way switch	6-79
6.31.3.2 - Single-acting mode AUX1	6-80
6.31.3.3 - Double-acting mode AUX1	
6.31.4 - AUX2 Auxiliary hydraulic system (optional)	6-82
6.32 - Emergency lifting-boom lowering procedure	
6.33 - Protective structure opening procedure	6-84
6.33.1 - Precautions to be taken during transport	6-84
6.33.2 - Precautions to be taken when travelling in low-height spaces	6-84
6.33.3 - Procedure	
6.34 - Daily storage	6-87
•	
7 - RECOMMENDED OPTIONAL EQUIPMENT	7-1
7.1 - Safety precautions	
7.1.1 - Specifications on authorised equipment	
7.2 - Equipment with standard coupling (pins)	
7.2.1 - Installation and removal	7-6
7.3 - Quick-coupling	
7.4 - Demolition hammer	
7.4.1 - Installation and removal	
7.4.2 - Precautions for use	7-8
7.4.3 - Operation	
7.113 Operation	
8 - MAINTENANCE	8-1
8.1 - Safety	8-2
8.1.1 - Placement out of service for maintenance	
8.2 - Tools and equipment for maintenance	
8.3 - Guards	
8.3.1 - Central compartment hood	
8.3.2 - High voltage compartment guard	
8.3.3 - Rear cover	
8.3.4 - Hydraulic oil tank compartment guard	
8.3.5 - Document glove box guard	R-10
8.4 - Electrical system	
8.5 - Tracks	
8.6 - Refilling	
8.6.1 - Refilling quantity table	0 17 0 10
8.6.2 - Products for lubrication	
8.6.3 - Hydraulic system oil	
8.6.3.1 - Requirements for using ecological hydraulic oil	Ω <sub>-</sub> 16
O.O.O.T. Requirements for using ecological flyuraulic oil	

8.6.3.2 - Scheduled plan for analysis and control of eco-friendly hydraulic oil	8-17
8.6.3.3 - Requirements for the sampling of eco-friendly hydraulic oil	8-18
8.7 - Tightening torque tables	8-21
8.8 - Regular maintenance	8-21
8.8.1 - Performance check	
8.8.2 - Cleaning of radiator and heat sink	
8.8.3 - Check the hydraulic oil level	
8.8.4 - Change discharge circuit hydraulic oil filter	
8.8.5 - Hydraulic system oil sampling/replacement	
8.8.6 - Replacement of intake circuit hydraulic oil filter	
8.8.7 - Check the condition of hydraulic lines	
8.8.8 - Full charge of the battery	8-34
8.8.9 - Check that the screws of the drive wheel/rollers are tight	8-34
8.8.10 - Track service position	8-35
8.8.11 - Track tension check	
8.8.12 - Adjusting the track tension	8-39
8.8.13 - Translation motors and rotation gear motors	8-42
8.8.14 - Lubrication of pins	
8.8.15 - Electrical test	
8.9 - Long inactivity periods	8-44
8.10 - Long-term storage	8-45
9 - ELECTRICAL PARTS	9-1
9.1 - Fuses and relays	9-1
9.1.1 - Fuses	
9.1.2 - Relays	
9.2 - Working lights replacement	
312 Working lights replacement minimum.	



**PAGE LEFT INTENTIONALLY BLANK** 

### 1.1 - Regarding this manual

This booklet is a manual containing the use and maintenance instructions for the operator, relating to a **excavator electric**:

### model CX15EV.

The electrical excavator is powered by a rechargeable lithium-ion battery positioned on the electrical excavator.

This manual will help you to understand how to set your machine up, prepare it for work, perform normal operations and carry out the routine maintenance operations. Additionally, it contains indications that contribute to increasing the degree of reliability and the duration of the machine.

This manual contains information required for a safe and correct use of the equipment.

# All operators must be trained and competent; they must have read and understood the instructions indicated in this manual.

The reading of this manual, careful study and verification that it has been understood by the operator, with particular attention to the safety provisions, must be part of the training and education programme.

For more information see section "2.3 - Safety signs and operation related labels" to page 2-5.


Failure to read and comply with the instructions preceded by a safety-related warning symbol can cause death or serious injury.



This is the warning symbol. It is used in this manual to warn the user of a potential risk of personal injuries. Comply with all the safety warnings referred to this symbol to prevent the risk of serious injuries or death.


The use and maintenance manual is an integral and essential part of the machine and must be delivered to the user.

This manual must always be kept on board the machine or in any case available to operators and must accompany the machine upon resale.



It must be kept safely in the appropriate lockable housing (1) and referred to carefully as it contains important directions for operator safety, proper working operation and correct maintenance.

The machine must be used only as expressly indicated. Any other use is to be considered inappropriate and therefore hazardous.



The manufacturer is excluded from any contractual and non-contractual liability for damages caused by errors in the use and handling of the machine or by the failure to observe the instructions provided by the manufacturer.

The maximum expected life span of this machine is deemed to be 10 years or 10000 working hours. Said duration is subject to the regular carrying out of all the control and maintenance operations as indicated in the relevant manual. Upon expiry of one of the above periods, the machine must be subjected to extraordinary servicing by the manufacturer or by workshops authorised by the same in order to assess the conditions of use and to determine the residual life. Otherwise it must be taken out of service.



The MANUFACTURER reserves the right to modify the product and amend the associated technical documentation without constituting any form of obligation towards third parties.

This version of the use and maintenance manual describes the characteristics of the standard machine, at the time of going to print.

If the use and maintenance manual is lost or damaged, please contact the *Service Centre* to request a new one.


### Copyright

The indications and the illustrations in this manual must NOT be reproduced, published or used for competitive purposes. With explicit reservation of all rights envisioned by the copyright law.

### 1.1.1 - Manual consultation and terminology


The manual has been made up using terminology that is indicated below:

- "**left**" abbreviated as "**lh**" refers to the left side of the operator when sitting in the driver's position;
- "right" abbreviated as "rh" refers to the right side of the operator when sitting in the driver's position;
- "top" or "above" always refers to the part of the machine located above the operator when sitting in the driver's position;
- "bottom" or "underneath" always refers to the part of the machine located below the operator when sitting in the driver's position;
- "front" is always the part of the machine where the dozer blade is fitted;
- "rear" is always the part of the machine opposite to the dozer blade position.



For ease of use and maintenance, the following are the names of some of the machine parts, which will be referred to in the descriptions provided in the manual.


### **ROLL-BAR VERSION**



## Key:

-			
1	Undercarriage	11	Boom Swing Cylinder
2	Tracks	12	First Boom
3	Translation Motor	13	Lifting Cylinder
4	Dozer Blade	14	Second Boom
5	Dozer Blade Cylinder	15	Digging Arm Cylinder
6	Turning Frame	16	Bucket
7	Roll bar	17	Bucket Cylinder
8	Operator Seat	18	Bucket Articulations
9	Joysticks	19	Connecting Rod
10	Boom Swing Tower		

### **CANOPY VERSION**



## Key:

-			
1	Undercarriage	11	Boom Swing Cylinder
2	Tracks	12	First Boom
3	Translation Motor	13	Lifting Cylinder
4	Dozer Blade	14	Second Boom
5	Dozer Blade Cylinder	15	Digging Arm Cylinder
6	Turning Frame	16	Bucket
7	Roll bar	17	Bucket Cylinder
8	Operator Seat	18	Bucket Articulations
9	Joysticks	19	Connecting Rod
10	Boom Swing Tower	20	FOPS Level 1 protective canopy



## **NOTICE**

The pictures in this manual may NOT correspond to the machine for the following reasons:

- technical modifications made after the date when this publication was printed;
- presence of accessories and/or optional equipment;
- installed equipment that differs from that shown in the pictures.

These differences do not compromise the safety of the operator and of the machine; read and always follow the instructions given.

Contact the Service Centre if any part of the manual is not clear.


### 1.2 - Machine identification data

The machine identification plate contains the machine type and serial number. This plate and that on the engine are necessary to request spare parts or to indicate technical problems to the *After-sales Centre*.



Under no circumstances must the information shown on the plates be altered.


### **FACSIMILE OF THE MACHINE CE-UKCA PLATE**




### Key:

1	Business name or manufacturer's full address
2	CE / UKCA Marking
3	Model year
4	Serial number/machine identification number
	(product identification number - PIN)
5	Weight of the most usual configuration (expressed in kg)
6	Year of manufacture
7	Engine nominal power (expressed in kW)
8	Machine designation

### **POSITION OF THE MACHINE CE PLATE**




### **POSITION OF MACHINE PUNCHING PINS**




**Machine PIN** 

### **POSITION OF THE ENGINE PLATE**




Engine ID plate

### POSITION OF THE BATTERY POWER PLATE




Power battery ID plate

### POSITION OF THE PROTECTIVE STRUCTURE PLATE



Protective structure ID plate (roll-bar)



Protective structure
ID plate
(canopy)

### 1.3 - Manufacturer

The excavator electric is produced exclusively by:

### **SAMPIERANA** s.p.a.

Via Leonardo da Vinci, 40 47021 S. Piero in Bagno (FC) http://www.sampierana.com

#### 1.3.1 - Contact the after-sales network

For any communication contact the after-sales network by providing the following information:

- machine model;
- serial number/machine identification number (product identification number PIN);
- year of manufacture;
- date of purchase;
- model and serial number of the engine;
- detailed information concerning problems detected.

### 1.4 - Spare Parts

Our company also boasts top quality original spare parts and a *Service Centre*. However, this manual is not a spare parts catalogue and must not be used to order spare parts.

Only the spare parts catalogue, which can be consulted on-line via serial number/machine identification number (product identification number - PIN), is a valid source of codes and descriptions of the spare parts for your machine.

With the perspective of continuous improvement of product design, several parts may be modified in the future. The only way to have the most updated information regarding spare parts is the on-line catalogue.

The *Service Centre* is at the customers' disposal to assist with any technical problems and spare parts orders.

For replacement of spare parts of the equipment, it is recommended to use original parts; the MANUFACTURER declines all liability with regard to a possible drop in performance of the equipment or damage to the machine and/or personal injuries resulting from the use of non-original spare parts. Please note that some of the parts that compose the machine were produced in PRC.

For maintenance operations that cannot be easily performed with the means that are ordinarily available to an individual, please consult our Service Centre that is able to provide skilled staff, adequate equipment and original spare parts.

The Service Centre is available to provide any required explanations and advice, or to intervene with the company's own specialised technicians if there are any doubts regarding machine performance.

### 1.5 - Information to the owner of the machine

The safety of users that operate the machine is of essential importance for the MANUFACTURER.

To communicate important information about the machine the *MANUFACTURER* uses **TECHNICAL INFORMATION** (INFO TECH) which is transmitted to the dealers and owners of the machine.

The information contained in the technical information is related to the machine using the model and serial number/PIN.

The distribution of technical information is based on the personal information data of the most recent owner, associated with the dealer, available in the MANUFACTURER's archives.

It is important to keep your contact information up-to-date.

In order to guarantee the safety of the machine, the owner must ensure that the specifications indicated in all the technical information are observed.

#### 1.6 - Intended use

The machine, with standard equipment (bucket) is designed for earthmoving operations, specifically:

- movement, collection, transport and unloading of earth, rocks or other materials;
- loading of said materials onto lorries, conveyor belts or other means of transport.

The machine can be fitted with interchangeable equipment or accessories which, however, must have the features indicated in chapter "7 - Recommended optional equipment" to page 7-1.

In the event that the user installs unauthorised equipment, the MANUFACTURER declines all responsibility for this combination.

After installing approved interchangeable equipment or accessories, the machine can be used for jobs corresponding to the function of the equipment or accessory itself.

Strictly observing the instructions given in this manual and performing the maintenance operations at the frequency indicated is also part of the intended use.

Always observe the instructions reported in the use and maintenance publications supplied by the manufacturer of the equipment or interchangeable accessories.

No changes can be made to the machine without the MANUFACTURER's authorisation, as the change could be dangerous.

#### 1.7 - Prohibited use

The machine has been designed and built according to the work for which it is intended. Therefore the technical specifications must be understood as binding for use of the machine depending on the relevant intended use.

Any use of the machine, which does not follow the indications given in the section "1.6 - Intended use" to page 1-13 IS FORBIDDEN.



## **DANGER**

This machine has been designed and manufactured to be used exclusively as indicated in the previous chapter, therefore use of the machine to perform operations different to those described is strictly prohibited.

This section lists some uses considered improper or unauthorised; as it is impossible to foresee all potential improper uses, if particular situations of machine use arise, before commencing work contact the Service Centre for more information.



## WARNING

No changes can be made to the machine without the written authorisation of the manufacturer, as the modification could be dangerous.

It is nevertheless necessary to adhere strictly to the safety regulations contained in this manual.

The MANUFACTURER is RELEASED of all liability in the event of any other use or failure to observe the instructions provided by the manufacturer itself.

DO NOT allow the machine to be used by minors or unskilled persons.

DO NOT transport flammable or otherwise hazardous materials.

DO NOT use the machine to lift or transport people.

NEVER use the machine for load handling operations if it is not equipped with the specific load handling equipment (available as an optional accessory).

DO NOT use the machine to tow other vehicles or trailers.

DO NOT use the machine if it is not in a suitable condition for work, if it has malfunctions in operation or if the controls do not respond perfectly.

DO NOT store the machine at temperatures below -15°C for more than 24 hours. If the temperature is below -15°C or the storage time is more than 24 hours, the machine must be kept continuously in charge.

DO NOT use the machine at an ambient temperature lower than -15°C if adequate modifications are not made as indicated in the section relating to low temperatures. In all cases, it is not possible to operate at temperatures below **-30°C**.

DO NOT store the machine at an ambient temperature above **+50°C**, if the temperature exceeds this value the machine must be kept continuously in charge.

DO NOT operate the machine at an ambient temperature above **+50°C**, if the temperature exceeds this value, place the machine in an environment with a lower temperature and stop its operation.

For battery precautions refer to section "6.14 - Battery power" to page 6-36.

DO NOT use the machine in:

- fire risk areas;
- corrosive atmospheres;
- explosive atmospheres;
- atmospheres with dust harmful to the health of the operator;
- contaminated or unhealthy environments;
- in busy areas (town centres, etc.) without having taken the appropriate and necessary safety measures.

DO NOT use the bucket as a pile-driver or as a pile-extractor.

When possible, AVOID large obstacles, highly uneven ground, stones, fallen logs, steps, ditches, etc., which can cause the tip-over or roll-over of the machine.



## **WARNING**

The MANUFACTURER cannot accept any responsibility in the event of accidents involving persons or property caused by non-compliance with the regulations and instructions listed in this manual and by failure to comply with safety regulations and accident prevention rules.



## **WARNING**

If the machine is used in an improper manner, the operator is personally responsible for his own safety and that of any other persons involved.



## **WARNING**

It is strictly prohibited to drive the machine on public roads, since the machine is not approved for this purpose. Therefore, it is only possible to operate in private spaces and/or building sites NOT open to the public.

### 1.8 - CE Declaration of Conformity

The CE declaration of conformity is a document signed by the manufacturer that ensures and declares that the machine complies with all standards in terms of safety.

This document must always be kept on board the machine and must accompany the machine until its complete decommissioning.

The declaration states all the machine identification data, or the manufacturer and all the relevant standards.

Below is a FACSIMILE of a CE declaration:

CONSTRUCTION		
SAMPIERANA S.p.A.		
"EC" DECLARATION OF C	CONFORMITY	
The undersigned declare that the machine described below has be compliance with the following European Directives, as amended, national laws:		into
1. 2006/42/EC "Safety of machinery"		
1.1 European Harmonised standards under which conformity is dec	lared: EN 474-1:2006+A6:2019, EN 474-5:2006+A3:2013	
1.2 Main safety components installed and supplied with the machine		No
1.2.1 Falling Object Protective Structure (F.O.P.S.)	×	
1.2.2 Object handling application kit (EN 474-5 §5.6.4; EN 474-	1 Annex E)	X
1.2.3 Roll Over Protective Structure (R.O.P.S.)	×	
1.2.4 Cab front guard		×
1.2.7 ###		×
1.4 Name and address of the person authorised to compile the tech Sampierana S.p.A Via Leonardo da Vinci 40 - 47021 S. Piero		
2. 2000/14/EC "Noise emission"		
2.1 Conformity assessment procedure followed: Anne	ex VI (art. 6/2)	
2.2 Name and address of the Notified Body involved: ECO Cert	ificazioni S.p.A. (0714)	
2.3 Measured sound power level LWA (ref. 1 pW):	dB(A)	)
2.4 Guaranteed sound power level LWA (ref. 1 pW):	dB(A)	)
2.5 Engine power (as defined by ISO 14396):	kW	
	Engineering Department ci 40 - 47021 S. Piero in Bagno (FC), Italy	
3. 2014/30/EU "Electromagnetic compatibility"	I EN ICO 42700 4:2040	
3.1 European Harmonised standards under which conformity is dec	lared: EN ISO 13700-1:2016	
4. Other applicable Directive/s: ###		
5. Manufacturer: Sampierana S.p.A. 6. Categ Via Leonardo da Vinci 40 47021 S. Piero in Bagno (FC), Italy	ory: Hydraulic excavator	
7. Type: - 8. Serial	n°: -	
_		
San Piero in Bagno, Italia 01/06/2022	] Signature	
54 15.5 54giio, italia 0 1/00/2022	(Name and Function)	

## Specifically for UKCA

<b>0</b> 16	<b>6</b>	4 64 64 6	a da da da da d	g bg bg bg	de de de de la	
(Q) (G)				A C E		(S)
(A)			<u>G</u>	45E		9
<b>(9</b> )			CON	STRUCTION		Ø
			SAMPIE	RANA S.p.A.		9
(Q) (W)		\	/ia Leonardo da Vinci, 40 – 47		gno (FC) – Italia	(a)
Ó			"UKCA" DECLARA	TION OF CONF	ORMITY	ě
(Q)			0.1.071 220271101		<u> </u>	9)
9			clares that the machine des		een designed and manu	factured in
<b>6</b>	cor	mpliance with the f	following Regulations, as am	ended:		Ø
(Q)	1.		pply of Machinery"			. 9
		1.1 UK designate	d standards under which co	nformity is declared:	BS EN 474-1:2006+ BS EN 474-5:2006+	A6:2019 A3:2013
<b>8</b>			omponents installed and sup		ine:	Yes No
<b>6</b>			Object Protective Structure (I nandling application kit	-OPS)		
			er Protective Structure (ROP	S)		
1631 1632		1.2.4 Cab from				
Ó		1.2.7 # # #				
SENTER SE			dress of the person authoriz S.p.A Via Leonardo da Vin			A6:2019 A3:2013 Yes No
	2.	2001 n.1701 "No	ise Emission in the Enviro	nment for Use Out	door"	(S)
(i)			ssessment procedure followers		HEDULE 9, procedure 1	(SI) 69
<b>(</b>		2.2 Name and ad	dress of the Approved Body	involved:		Ó
			ertification Ltd - 2 Parkfield S		anchester, M14 4PN	Ş.
(9) (8)		2.3 Measured soil	und power level LWA (ref. 1	pW):		dB(A)
Ó		2.4 Guaranteed s	ound power level LWA (ref.	1 pW):		dB(A)
0		2.5 Engine power	r (as defined by BS ISO 1439	96):		kW 💱
(Q)		2.6 Holder of the	technical documentation:	Sampierana S.p.A	· Via Leonardo da Vinci, 40	(Q)
6	3.	2016 n 1001 "Ele	atrama anatia Campatibili	47021 San Piero in I	Bagno (FC), Italy	Ğ
0	э.		ectromagnetic Compatibility of standards under which con		BS EN ISO 13766-1:	:2018
	4.	Manufacturer:	SAMPIERANA S.p.A.			9
	5.	Category:	Hydraulic excavator			9
<b>6</b>	6.	Type:	-			9
<b>(9</b> )	7	Serial n°:	_			Ø
(Q)	•					S
(S)						(S)
<b>6</b>						ě
9	Saı	n Piero in Bagno, It	talia, 00/00/0000		Cinnatura	ğ
( <u>©</u> )					Signature (Name and Function)	<u> </u>
6					,	(a)
	(i)	KS BKS BKS BK	a 60a 60a 60a 60a	(S) A(S) A(S) A(S)	ace ace ace ace	

**PAGE LEFT INTENTIONALLY BLANK** 

### 2 - SAFETY

### 2.1 - Safety symbol



This is the warning symbol. It is used in this manual to warn the user of a potential risk of personal injuries. Comply with all the safety notices referred to this symbol to prevent the risk of serious injuries or death.

### 2.2 - General safety

There are many risks linked to work with a **excavator electric**.

It is recommended that the machine is only used by staff trained specifically for this purpose. The employer is responsible for checking that all safety regulations in force in the place of use of the machine are respected before starting any activity. Safety plates are positioned on the machine to indicate possible hazards.

- The machine must only be used by authorised, skilled, qualified and trained persons.
- Read the instruction manual before using the machine.
- Wear clothing suitable for work on a construction site.
- Inspect the machine thoroughly every day or at every shift, performing a thorough external control before starting it in order to prevent injury or damage to persons.
- Always fasten the seat belt before starting the machine.
- Learn the position and use of the pedals, command levers, instruments and LED indicators.
- Perform all controls indicated.
- Never drive the machine under the effect of alcohol, medicines or other drugs.

- Make sure there are no persons in the machine's radius of action before starting it.
- Always face the machine when climbing onto or off of it and use the steps and handles or cab uprights. DO NOT JUMP DOWN!
- Never try to climb onto or off of the machine when it is moving.
- Do not use the commands as a handle to get on and off the machine.
- Always check the slipperiness of the foot boards, steps and handles when climbing onto or off of the machine.
- Perform a risk assessment of the work area and reduce all risks identified before starting work.



## **WARNING**

### It is forbidden to make any modifications to the machine.

- The machine must not be modified without the MANUFACTURER's permission.
- The realisation of modifications without said consent will lower the level of safety, thus increasing any dangers. Modifications not only worsen the machine functions, but also reduce their duration.
- We are not liable for any accidents or faults due to modifications made without our consent.
- Should you decide to intervene on the machine, it is necessary to submit a written request to the MANUFACTURER.



## **WARNING**

### Anticipate any precautions with regard to optional parts and accessories.

- Do not install any components or accessories that have not been approved by the MANUFACTURER.
- The use of components or accessories not approved by the MANUFACTURER may determine a reduction in the level of safety, thus increasing the possible hazards.
- We are not liable in any way for any injuries, accidents or machine faults due to the use of components or accessories not approved by the MANUFACTURER.

### 2.2.1 - Manual safety sign consultation

To ensure a safe use of the machine, this manual provides all the information on safety precautions in order to highlight potential hazards and the relevant methods to be adopted to avoid them.

The following words are used to provide indications regarding potential hazardous situations that could cause injury and/or damage to property.

They are highlighted by the wording: **DANGER**, **WARNING** and **CAUTION**.



## **DANGER**

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



## **WARNING**

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



## **CAUTION**

Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.

In addition to those listed above, the following indication words are used to recommend precautions to be taken to protect the machine or to provide useful information.



## NOTICE

Indicates information considered important, but not hazard related (e.g., messages related to property damage).



Indicates information considered important to protect the environment, indicating the correct disposal of waste based on the Laws in force in the country where the machine is used.

The manufacturer cannot anticipate all possible circumstances involving potential hazard during operation or maintenance. As a result the safety messages shown in this manual or on the machine may not include all possible safety precautions.

When performing procedures or operations that are not explicitly recommended or permitted in this manual, it is necessary to take all necessary safety precautions to avoid potential hazards.

Under no circumstances must actions be taken or operations performed that are expressly prohibited in this manual.

If you are unsure of the safety requirements for some of the procedures, contact the MANUFACTURER or the Service Centre.

## Meaning of the symbols used:

	Correct, Allowed.
	Incorrect, Forbidden.
0	Be Careful!
	Direction of operation or Direction of movement.
	Closed, Locked.
	Open, Released.
53	Manual Operation.

### 2.3 - Safety signs and operation related labels

Affixed to the machine are **safety signs** with warning and safety symbols for the operator and those who operate near the machine itself; there are also **operation related labels** which provide the instructions for operation and maintenance.

Each type of sign is placed near the part of the machine that may be a hazard source or that requires operating instructions.

The safety signs and the operation related labels are attached to the machine in the form of stickers; they can be divided into three different types:

### - safety signs;

- these are yellow with a black border and lettering to indicate warning;
- these are yellow with a red border and black lettering to indicate prohibition;

### - operating instructions;

- these are white or transparent with a black border and lettering;

### - maintenance instructions;

- these are white or transparent with a black border and lettering.

Read carefully and become aware of the symbols and their message before using the machine.

Check the presence and legibility of the safety signs and operating instructions daily; repair or replace them immediately whenever they are damaged or missing.



## **DANGER**

Make sure that the safety signs and operating instructions are always legible and in the correct position; if necessary, ask the Spare Parts Service for replacements.


The manufacturer declines all responsibility for damage to persons or property due to non-compliance with the warnings and instructions reported by the safety signs and operation related labels or by their imperfect preservation.

### SAFETY


- Wash the labels with soap and water and dry them with a soft cloth.
- Replace any damaged or missing labels with original stickers obtained from your *Service Centre*.
- Should it be necessary to replace a component displaying stickers, make sure that the new component has the same labels.
- When replacing labels, make sure that the base is clean, dry and free from oil or grease. Press any air bubbles towards the outer edges.

Below is a series of images indicating the positioning of the safety signs and operation related labels.


### **SAFETY SIGNS AND OPERATION RELATED LABELS**



### **SAFETY SIGNS AND OPERATION RELATED LABELS**



### **SAFETY SIGNS AND OPERATION RELATED LABELS**



### Safety Sign Key:

# 1 Risk of damage caused by wrong operations and maintenance

Read and acquire the information contained in the use and maintenance manual before starting the machine to prevent all risk of injury.



### 2 Risk of tip-over or roll-over

Always fasten the seat belt when on-board the machine.

In the event of tip-over or roll-over, do not leave the driver's position but grip the seat tightly.



# 3 Risk of damage caused by involuntary movement of the machine

Prior to leaving the driver's seat:

- lower the machine boom;
- lock the controls using the controls cut-out lever;
- shut down the machine and remove the key.



### 4 Risk of damage caused by electricity

The user is warned that the machine uses electricity that could cause harm to persons.



Take care NOT to enter into contact with the electricity.

## 5 Risk of burns caused by hot surfaces

Do not touch hot surfaces.

Wait for the machine to cool before carrying out any maintenance intervention.



# 6 Risk of fatal injury caused by the slewing or by the reversed motion

Stay at a safe distance from the machine to prevent all risk of injury.



# 7 Risk of damage caused by the machine booms or by the equipment installed

Stay at a safe distance from the boom and the equipment installed to prevent all risk of injury.



# 8 Risk of damages/burns caused by the explosion of the battery or by the contact with the battery acid

Never use open flames, do not generate sparks.

Wear personal protective equipment.

Follow the operating instructions.



#### 9 Risk of crushing

Keep an appropriate distance from moving parts.



# 10 Risk of damages caused by the projection of objects while adjusting the track tension

Read and understand the use and maintenance manual.



### 11 Risk of damage caused by electricity

Do not wash the electrical components with water jets to avoid the risk of electrical discharges.



Washing with water jets can only be carried out with hoods and covers closed.

### 12 Risk of damage caused by electricity

Do not extinguish fires with water to avoid electric shock hazard. Use only suitable fire extinguishers.



### 13 Risk of damage caused by electricity

Indicates areas where there may be electrical energy, which may cause injuries.





### Operational labels key:

### 14 Lifting point

Indicates the points to be used to lift the machine.

### 15 Anchorage point

Indicates the points to be used to anchor the machine during transport.

#### 16 Lock - Unlock

The closed padlock indicates the locked position.

The open padlock indicates the unlocked position.



### 17 Hydraulic oil tank cap

Indicates the position of the cap for topping-up the hydraulic oil.



### 18 Hydraulic oil MIN-MAX level

Indicates the position of the MIN-MAX level indicator of the hydraulic oil.



### 19 Controls

Indicates the position and functioning of the machine controls.



### 20 AUX 1 system single/double-acting switch

Indicates how to modify the functioning of the AUX 1 hydraulic plant.



### 21 Lubrication points

Indicates the points where lubrication must be performed. Indicates lubrication intervals.




#### 22 Sound emission

Indicates the value in decibels Lwa of the sound emitted by the machine (read the value on the label located on the machine or refer to section "3.18 - Sound emission" to page 3-20).

# Lwa XX dB


### 23 Lifting and anchorage for transport

Indicates where the lifting and anchorage points for transport can be found on the machine.



### 24 Fuse and relay box


Indicates the layout and relative functions of the fuses and relays.



### 25 Machine charging operations

Indicates the technical data of the mains to which the on-board battery charger needs to be connected.

Indicates that the machine charging operations should be performed with the cable fully extended.



Indicates that the rear cover must be kept open while charging the machine.

For more details, see section "6.15.1 - On-board battery charger" to page 6-40.


### 26 Emergency stop button

Indicates the position of the emergency stop button.



### 27 Use only approved battery chargers

It is forbidden to use external battery chargers other than those approved by the manufacturer.





#### 2.4 - Machine driver

The driver must be a **skilled operator**. This term means a skilled and trained person, appointed to move and manoeuvre the machine.

The use of the machine by a **skilled operator** lies within the normal conditions of use.

From here on the skilled operator will be indicated as **operator**.

The employer must provide the training and education necessary, especially on the introduction of new work equipment (in Italy the obligation is indicated in Legislative Decree 626 art. 22 par. C).

Machine functioning safety is entrusted directly to those operating daily on the same.

**Operation and maintenance** of the machine must be **limited to** those persons who:

- are at least 18 years of age;
- are physically and mentally fit for work, are able to address the requirements associated with operation of the machine at its most intense use;
- have been trained to operate the machine and perform maintenance, are familiarised with the technical features, the overall dimensions, the performance and the relevant limitations;
- know the rules and regulations relating to workplace safety;
- prove their ability;
- are enabled, according to the standards in force, to drive the machine on public roads (only if used on public roads and only if the machine is authorised for road use).

These persons must be assigned to this task by the legal representative of the company that owns the machine.

### The operator is also responsible for:

- stopping anyone approaching during use of the machine;
- preventing use of the machine by unauthorised and untrained staff;
- following on a daily basis the safety procedures learned during the training course;
- identifying and avoiding potential risks at the workplace;
- understanding and complying with the indications of the safety signs and operating labels;
- inspecting the machine and checking for correct operation before starting the work shift;
- communicating every problem related to operating detected before or during operation of the machine;
- avoiding careless or reckless actions that could endanger their own or others' safety;
- always using common sense and always giving priority to absolute safety.

For any further questions on the use of the machine call the *Service Centre* which will provide all the necessary information.



# **DANGER**

The purchaser and the operator of this machine must carefully read the user manual the first time they use it.

If the machine is supplied with a user or hire contract, it is responsibility of the owner to ensure that the new user reads and accepts the user manual. In addition, ensure the new operator has performed an inspection around the machine and that they have become familiar with all safety signs and equipment in addition to trying out the correct use of all the commands.

At the time of first sale, the seller informs the purchaser about safe use and operation of the machine. In the event the machine is to be used by someone other than the original purchaser, for example by an employee or it is to be rented, lent or sold to someone other than the purchaser, make sure the new operator reads and accepts the **User Manual** for the **excavator electric** supplied with the machine, before using it for the first time.

#### 2.4.1 - Personal Protective Equipment (PPE)



# **WARNING**

Operators must ALWAYS wear suitable clothing for construction work. Clothes must not be greasy or soaked with oil.

Long hair must be gathered, avoid wearing chains, clothes with dangling parts, ties, or any other object that could get caught in the moving parts of the machine.



The PPE to be used during **use of the machine** is listed below:

- safety footwear;
- high visibility clothing.

The PPE to be used during maintenance of the machine or assembly/disassembly of optional equipment is listed below:


- a safety helmet;
- safety footwear;
- safety goggles;
- protective gloves;
- ear defenders;
- high visibility clothing.

### 2.5 - Work Area - Hazard Zone - No Entry Zone



# **DANGER**

Nobody must stand in the NO ENTRY ZONE and/or in the HAZARD ZONE.



### Key:

- 1 Work Area
  - 2 Hazard Zone
- 3 No Entry Zone

#### 1 - WORK AREA

This is the area surrounding the hazard zone. The machine may enter this area; when this happens, the work area becomes a hazard zone.

Only authorised people, aware of the operating capacity of the machine, may stand in this area.

#### 2 - HAZARD ZONE

This is the area near the machine where the operating equipment is never present but there is a constant hazard due to the projection of material, the oscillation of the load or the tip-over or roll-over of the machine.

Nobody must stand in this area.

#### 3 - NO-ENTRY ZONE

This is the area surrounding the machine. In this area you may be hit by the operating equipment, by the load falling from a height, or reached by the moving machine.

Nobody must stand in this area.

The Safety Manager at the work area must assess the hazards prior to commissioning the machine.

The work area must be appropriately indicated, even if working at a site that has already been delineated.

### Nobody must stand in the NO ENTRY ZONE and/or in the HAZARD ZONE.

The driver of the machine may operate only when **NOBODY** is in the **NO ENTRY ZONE** and in the **HAZARD ZONE**.

Before starting work, the driver must warn any the people near the machine of the possible hazards and wait for them to move away. This usually occurs by using the horn or simply by telling them.

Stop the machine immediately if someone enters the **HAZARD ZONE**, warn them of the risk and make sure they move away before proceeding with the operations.

To avoid any bruises or accidental contact it is advisable, in the presence of scaffolding or unstable structures, to maintain a safe distance (at least 0.5 m) such that even during accidental manoeuvre, there is no danger of contact with these structures.

#### 2.6 - List of Residual Risks

Below is a description of the operations or situations that may expose people to danger or risks.



# **DANGER**

# RISK OF ELECTROCUTION CAUSED BY HIGH ELECTRIC VOLTAGE

Pay attention to overhead power lines, contact or approach may expose the operator to electrical shocks. Ensure that the boom, equipment, or protective structure is always at a suitable distance.



If the machine enters into contact with the electrical lines:

- DO NOT leave the driver's seat and DO NOT touch the metal parts;
- if possible, move the vehicle away from the hazard zone;
- avoid other people approaching;
- ask other people to cut the power supply to the electrical supply lines.



# **DANGER**

# RISK OF INJURIES TO PERSONS NEAR THE MACHINE

During the work phases do not allow unauthorised persons to approach the machine.






#### **RISK OF TIP-OVER AND ROLL-OVER**

The machine centre of gravity changes depending on the size and position of the load, the slope of the ground and the movement of the machine.

Analyse and record the topography and geological characteristics of the place in order to take appropriate measures to prevent the tip-over or roll-over of the machine, against landslides or mudslides.



Level the ground in the machine's work area.

Careless use and driving that does not comply with this type of machine could cause the tip-over or roll-over of the machine.

Never exceed the nominal lifting capacity of the machine.



# **DANGER**

### RISK OF FALLING OBJECTS/CRUSHING

When handling the machine pay particular attention to people, animals or objects around the work area.



### Do not stand under the lifted parts.

- Nobody must stand under the boom or work equipment if raised.
- When the machine is lifted by means of the work equipment, under no circumstances stand under the raised parts.

Lowering the raised parts may cause serious accidents with possible injuries or even death.




#### **RISK CAUSED BY LITHIUM BATTERY**

The lithium-ion battery, if damaged or exposed to high temperatures, could ignite and produce harmful chemical substances.

Never create sparks or flames, or smoke near the battery.

A damaged lithium battery can ignite and/or explode, this type of fire has a very high energy and is more difficult to extinguish than that of a conventional battery, immediately contact specialised personnel, communicating the type of chemical substance. Do not attempt to extinguish the fire yourself.



Avoid inhalation or contact with chemicals and smoke from the battery by moving away, they are extremely toxic and can cause serious injury or death.



# **DANGER**

#### **RISK OF INJURY TO TRANSPORTED PERSONS**

The machine cannot be used for the transport of persons; only the operator must drive it himself.

Do not allow anyone else to get in the driver's seat, to climb on the tracks or on the work equipment.





#### **RISK OF CRUSHING**

During a possible tip-over or roll-over of the machine, the operator could be thrown off the seat and then get crushed by the machine.

Choose a comfortable driving position. Adjust the position of the seat and the control levers. Adjust the tension of the belt so that it can hold the operator leaving the abdomen completely free. Do not start working before having followed these safety conditions.





# **DANGER**

#### **RISK OF FALLING**

Be sure to check the steps and handrails. If damages, loosening or other faults are found, carry out the necessary repairs.

If there are any slippery substances on steps or handles, such as mud, oil or lubricant, remove them completely.





#### **RISK OF ELECTRIC SHOCK**

Any work on the electrical system or on the battery must be carried out by a competent person.

Before working on the electrical system, disconnect the battery, starting with the earth terminal.

Ensure the electrical connection wires and terminals do not show any signs of corrosion, cracking or scorching, otherwise immediately contact your *local Authorised Dealer*.





# **DANGER**

#### **RISK OF DAMAGE DURING EXCAVATION**

Before starting work in a new area, check for the presence of any electrical power lines, pipelines and telephone lines.

All these elements are a hazard source for the operator and damage to them a safety risk and a potential economic cost.



Before starting the excavation, contact the site manager of the work area or the authorities to locate all utilities present in the subsoil.



#### **RISK OF BURNS**

Do not carry out maintenance work on the hydraulic system immediately after stopping the machine, the oil is very hot. The hot oil could cause serious injuries; have it cool before intervening.





### **DANGER**

#### **RISKY WORKING CONDITIONS**

Find out about any dangers that may be present in the work area.

Proceed with care when working along basins, embankments and slopes; keep away from the edges.

Be careful when working under protrusions that the top part of the machine might hit.



Pay attention to falling rocks and to landslides.

Be careful during filling operations. Do not get too close to the edge because the weight of your equipment may cause subsidence in the soil and the machine may overturn or tilt.



#### **RISK OF HIGH PRESSURE JETS**

The hydraulic system is under pressure when the machine is running and could maintain the pressure even after it is off.

In the event of a fault or maintenance intervention, the operator may be exposed to high-pressure fluid jets.

Fluid escaping under high pressure could enter the skin or eyes and cause serious injury or death.



Pressurised fluid leaks may be invisible. **DO NOT** use hands to check for leaks. Use a piece of cardboard or paper to this purpose.

If oil leaks are found, stop the machine immediately and make the necessary repairs.

Wear appropriate personal protective equipment, as indicated in the specific section, during maintenance work.

**DO NOT** attempt to repair or tighten hydraulic lines or fittings when the machine's hydraulic system is under pressure.


In the event of a hydraulic component failure, place the machine on firm level ground, lower the equipment and dozer blade to the ground, stop the machine and release any residual pressure as described in section "6.30 - Discharge residual pressure in the hydraulic system" to page 6-74.

Should anyone suffer injury due to contact or to the penetration of hydraulic oil or grease into the skin, seek a doctor immediately. Failure to summon a doctor could lead to the emergence of other serious injuries.



### RISK OF OBJECTS/LIQUIDS PROJECTION

Use caution when greasing the belt tensioner; parts of the belt tensioner or jets of high-pressure grease could be projected toward the operator, risking serious injuries or death.



The cylinder that adjusts the track tension is filled with grease; therefore the grease itself may be under high pressure. Under this circumstance, if the plug is loosened carelessly, both the plug and the lubricant may get pushed out causing a dangerous situation.

For operations on the track tensioner, refer to the dedicated section.



#### **RISK OF ENVIRONMENTAL POLLUTION**

The improper disposal of waste fluids may cause serious damage to the environment. Before disposing of waste fluids, contact the competent local bodies for information regarding the correct procedures.

Use suitable containers. Never use empty containers to store food.



**NEVER** pour waste fluids on the ground, into drain lines, into courses or water basins. **Always observe the environmental protection regulations** in force when discharging the following substances:

- oils or lubricant grease;
- filters:
- battery;
- cooling liquids;
- containers or absorbent materials impregnated with these substances.

### 2.7 - Safety procedures



# **WARNING**

#### **UNAUTHORISED MODIFICATIONS**

No modification can be made to the machine without the permission of the manufacturer. Consult the *Service Centre* before making any modifications. The *MANUFACTURER* denies all liability for any injuries or damage caused by unauthorised modifications.



# **WARNING**

#### **SEAT BELT**

Adjust the seat and always fasten the seat belt before starting the machine. Carefully follow the indications given in the dedicated sections: "6.3 - Driver's seat" to page 6-4, and "6.5 - Seat belt" to page 6-5.



# WARNING

### **CHECK FOR ADEQUATE VISIBILITY BEFORE STARTING TO OPERATE**

### Make sure there is proper visibility for work purposes.

Clean the windows (if present), rear-view mirrors (if present) and lights, in order to guarantee good visibility. Make sure the rear-view mirrors are intact and correctly positioned so as to ensure the complete visibility around the machine.

If the cab windows (if present) are cracked or broken, do not start work without repairing them.



#### **CHECKING THE SAFETY DEVICES**

Check all safety devices and guards to ensure their proper installation, operation and the presence of any damage. If faults are found, carry out the necessary repairs. Misuse of safety devices could cause serious accidents with a potential risk of injury or death. Make sure to correctly use the safety devices.



# **WARNING**

#### **EXAMINATIONS PRIOR TO THE START UP**

Before commissioning, carry out all verifications envisaged. If failures are found, repair the machine immediately. Using the machine when faulty could cause accidents.



# **WARNING**

#### CHECK THE SURROUNDING AREA BEFORE COMMISSIONING

Prior to using the machine carry out a visual inspection of the surrounding area to make sure the safety conditions are met.



# **WARNING**

#### **ALERTS PRIOR TO THE START UP**

Before starting the machine, use the horn to signal.



#### SAFETY ASPECTS DURING OPERATION

Before starting to travel, use the horn to signal.



# **WARNING**

#### **GETTING ON AND OFF THE MACHINE**

Get on and off the machine only near the dedicated handles or steps (if present) and tracks.

Before getting on the machine, clean the steps (if present), the part of the track that will be stepped on and the handles if stained with oil, grease and mud, check their condition; have them repaired if necessary.

Both for the upward movement and downward movement, always keep, if possible, three contact points (gripping or supporting), two hands and one foot or two feet and one hand, to be sure not to lose your balance and fall.

Always face the machine when climbing on or off.


Get on and off the machine slowly and carefully, DO NOT carry tools or other items, always keep your hands free and able to grip the handles.

Do not jump on or off the machine.

Do not try to climb on or off the machine when it is moving.

Do not get on or off the machine by grasping the control levers or the controls cut-out lever.

**Get on** facing the machine as shown in the figure (from 1 to 5).



Before getting off the machine, **ALWAYS** perform the following operations:

- align the turning frame to the undercarriage so that the dozer blade stays near the boom;
- lower the dozer blade and the equipment to the ground;
- turn off the machine and remove the ignition key;
- lift the controls cut-out lever and unbuckle the seat belt.

**Get off** facing the machine as shown in the figure (from **5** to **1**).



#### **RISK DUE TO MOVING PARTS**

**DO NOT** place the limbs or other parts of the body close to the moving or rotating parts of the machine during operation. Failure to comply with this warning may lead to serious injury or death due to crushing or amputation.

**STOP** the engine and wait for all moving parts to come to a standstill before carrying out maintenance work.



# **WARNING**

#### MACHINE INSPECTIONS AND MAINTENANCE

Stop the machine before starting inspection and maintenance work on the machine.

It is extremely risky to carry out checks or maintenance operations with the machine in operation. Make sure that you have already stopped the machine. Only start work after the temperature of each device in the machine has lowered.



# **WARNING**

#### PREPARATION AND PREVENTION

Know the location and function of all machine controls. Before starting the machine, make sure that no one is in the work area.

Holes, obstacles, rubble and other hazards associated with work areas could cause bodily harm or death. Always inspect the work area, taking care to identify the hazards before operating the machine.

Avoid hazards when driving the machine around the work site. Get informed on the movement of persons and vehicles around the site. Comply with all signals and signs.

#### **DO NOT** use the machine unless:

- all equipment is present and in good condition;
- all covers and guards are in place;
- all safety signs and labels are applied and readable.

Repair or replace any missing and/or damaged parts.



#### **RISK OF TIP-OVER AND ROLL-OVER**

Performing movements of slewing or travel with the boom extended is hazardous and may cause the machine to tip over or roll over. When moving, keep the boom as close to the machine as possible and maintain a maximum distance of 30 cm between the lower part of the equipment and the ground.

The stability of the machine decreases when it is used on uneven ground or on slopes.

When travelling, plan the direction in which the machine is to move. Avoid making any jerky turns, starts, or stops. Travel with extreme caution and at the slowest possible speed.

**DO NOT** exceed the nominal load capacity of the machine, as the non-observance of the suggested values may cause instability and dangerous operating conditions for the machine and for the operator.

The guard structure makes the driver's seat the only safe place to be in the event of the machine tipping over or rolling over.

#### **During tip-over or roll-over:**

- KEEP THE SEAT BELT FASTENED.
- DO NOT LEAVE THE DRIVER'S SEAT.
- STAY SEATED AND HOLD THE SEAT FIRMLY WITH YOUR HANDS BETWEEN YOUR LEGS.
- LEAN AWAY FROM THE POINT OF IMPACT.

### Once the tip-over or roll-over has finished:

- make sure the machine is stable and there cannot be further tilting;
- unbuckle the seat belt;
- quickly leave the driver's seat by leaving from the machine side facing upwards.

Do not attempt to leave the machine by sliding beneath the structure.

In case the main door is blocked, use the emergency exit.



#### **EMERGENCY EXIT**

After an emergency situation during which it is not possible to use the main access route to abandon the machine, the emergency exit must be used. This is at the front of the driver's seat.

If the emergency exit is blocked too, identify a possible exit on the right side of the cab or at the back.



### **WARNING**

#### **MACHINE STABILITY**

When the turning frame and the boom assembly form a 90° angle with the undercarriage, the stability of the machine is at its minimum; in this position, pay more attention to the risk of tipping over or rolling over.

To provide maximum machine stability while working:

- where possible, position the machine so that the tracks are parallel with the turning frame and first boom assembly;
- keep the dozer blade lowered and in contact with the ground;
- avoid lifting the tracks off the ground using the dozer blade.



# WARNING

#### **INCREASING STABILITY USING THE DOZER BLADE**

The cylinder of the dozer blade is NOT equipped with a security valve, so the dozer blade must not be used to stabilise the machine.

If the dozer blade is used improperly, the hydraulic hoses can get damaged and cause a sudden loss of stability of the machine with the consequent damage to the operator and/or to the machine.



#### TRAVELLING AND WORKING ON SLOPES

When the machine is used in conditions other than those indicated in the manual (for instance, on a surface which is not compact, but rough or slippery, or on a slope, etc.), the operator must take into account the new conditions that reduce the machine's stability and capacity. The operator must therefore work at lower speeds and with lighter loads so as to ensure the stability of the machine.


All indications supplied in the manual refer to the use of the machine on a flat and stable surface.

Travelling or working on a slope is riskier than travelling or working on flat ground.

If it is not possible to avoid slopes, take the following precautions.

Travelling or working on a slope can be hazardous. Ascend or descend slopes slowly and cautiously. Unexpected obstacles or changes in slope can cause loss of machine control that may result in tip-over or roll-over.

### **Maximum slopes permitted for travel**




When travelling on a slope with an angle lower than 15°, always reduce the machine speed and maintain a slow, steady motion. Apply braking by smoothly returning both travel control levers to the NEUTRAL position (N).

If travel on a slope with an angle greater than 15° is required, take the following additional precautions:

- descend or ascend only and NEVER drive the machine across steep slopes;
- the boom assembly must be facing the direction of travel;
- position the dozer blade in front of the operator, under the boom assembly;
- to climb up and go down, proceed with forward travel;
- position the lower part of the equipment about 30 cm off the ground.

### Changing direction on slopes is allowed only if the slope is less than 15°.





# **WARNING**

#### **USE ON DECKS OR RAISED FLOORS**

Check always the space within which the machine is operated and all limitations regarding size and scope of the working area. When working on a deck or a raised floor, always check their bearing capacity. Pay particular attention to the overall rotation of the machine.



#### LIFTING THE MACHINE

Follow all the instructions given in section "4.4 - Lifting of the machine" to page 4-9.



# **WARNING**

#### RISKS WHILE TRANSPORTING PASSENGERS

DO NOT allow anyone to ride on the machine with the operator.

DO NOT use the machine as a lift or working platform for people.

DO NOT allow anyone to climb onto the operating equipment.

There is the risk of falling and of being seriously injured.



# **WARNING**

#### **DISTANCES**

Always check overhead and side clearances carefully before driving around or under any fixed structures, such as buildings, bridges, towers, etc.



# **WARNING**

#### **RISKS RELATED TO THE SUBSOIL**

Get informed on the location of all underground dangers before operating the machine in a new work area. Contact with electrical cables, telephone lines, gas or water pipes, sewers, or other underground utilities could lead to injury or death. Before starting work, contact your local telephone service supplier and request them to locate and mark these utilities.



#### RISK OF ELECTROCUTION CAUSED BY HIGH ELECTRIC VOLTAGE

When operating near any overhead power lines, either barricade them off or apply insulating guards around them. It is also very risky to operate near high voltage lines: the lines can be dangerous even when the machine is NOT in direct contact with the line.

In case of operations at a distance lower than those indicated, contact the company that owns the electrical line to disable the voltage in the work area line section.

NEVER operate this machine in an area where there are overhead or underground power lines, cables, or other power sources, without first requesting that the appropriate power or utility companies isolate the lines or taking other adequate precautions.

Maintain a safe distance from the power lines according to the indications below:

CABLES VOLTAGE	MINIMUM PERMITTED DISTANCE
from 0 to 50 kV	3.0 m
from 50 to 200 kV	4.6 m
from 200 to 350 kV	6.1 m
from 350 to 500 kV	7.6 m
from 500 to 750 kV	10.7 m
from 750 to 1000 kV	13.7 m
more than 1000 kV	Ask the company in charge of the electrical power line for information regarding the minimum distance to be kept from the cables.



#### **OBSTRUCTED VISIBILITY**

Dust, smoke, fog, etc. can decrease vision and cause an accident.

Always stop or slow the machine down until the obstruction clears and the work area is once again clearly visible.



### **WARNING**

### **MOVING ON A FROZEN OR SNOW-COVERED SURFACE**

If work must be performed on surfaces coated with ice or frozen snow, reduce the speed and avoid making any jerky movements. Sideways slipping could easily occur while the machine functions become more sensitive.

When a large amount of snow has fallen, the road edges and any equipment provided are difficult to see. Exercise extreme caution in such situations.

Frozen ground will often get softer as the temperature rises. Exercise extreme caution in such situations.



# **WARNING**

#### **WORKING NEAR WATER COURSES**

Near water courses, lakes or seas, pay attention to the immersion depth of the machine.

Do not immerse the machine in water beyond the permissible depth (upper part of the track).

Immersing the machine over the permitted limit can cause drowning of the operator and/or serious damage to the machine.

If there are any lubrication points in parts of the partly completed machinery that have remained under water for a long time, grease them using the relative grease nipple until grease seeps out from the junctures.



#### **WORK SITE CONDITIONS**

Prior to start working, assess and record thoroughly the topography and geological characteristics of the place in order to take appropriate measures to prevent the tipover or roll-over of the machine, against landslides or mudslides.

Other conditions may also generate effects at the workplace. People can enter the area, equipment and materials can be moved or added. Always be aware of the existing conditions on the work site and always look in the intended direction before starting any movement.

Do not start working if the necessary safety conditions are not met.



# **WARNING**

#### **VENTILATION**

Good ventilation of the work area is very important for the operation of the machine. DO NOT operate the machine in an area containing flammable dust or fumes. Provide good ventilation and wait until the hazard has been eliminated.



### **NOTICE**

#### ABNORMAL NOISE PRODUCED BY THE MACHINE

While working, pay attention to any abnormal noises from hydraulic devices, transmission components, work equipment, etc.

Find below a list of possible abnormal noises.

- Do you hear a squeak caused by poor lubricating oil quantity?
- Do you hear friction noise?
- Do you hear an abnormal vibration or tinkling?
- Do you hear an uneven sound?
- Do you hear a strange noise coming from the hydraulic devices?
- Do you hear beats at determined intervals?
- Do you hear rumbling?

If any of these noises are detected, stop the machine immediately and carry out a check.



#### KEEP THE AREA AROUND THE OPERATOR SEAT CLEAN

Always keep the operator's seat and its accesses clean.

Do not climb with dirty, muddy or greasy shoes.

Do not place any object at the bottom of the operator seat or around pedals, and do not hang anything on the control levers.

These control levers may be engaged accidentally, causing the machine to move or the work equipment to be activated, which may result in dangerous situations.

Stow away any items not required for the current operations in their proper places.

The electrical components have extremely limited resistance to water. The infiltration of water into the various sensors, connectors or electrical system components may result in malfunctions. Do not clean using steam and water.



### WARNING

#### PRECAUTIONS DURING MAINTENANCE

Before starting maintenance, always deactivate the machine as indicated in section "8.1.1 - Placement out of service for maintenance" to page 8-5.

Use the correct tools, make sure that spanners and tools are in the correct position. Treat machined and polished surfaces with care.

Never re-use broken, damaged or badly worn parts.

Tighten all bolts, unions and accessories to the torques specified in the specific sections.

Replace all protections and guards, lock all hoods and covers with a key (if present).



# **WARNING**

### REPAIRS REQUIRING WELDING

All welding operations on the machine are **prohibited**.

If welding repair is required, contact the Service Centre.



#### PREVENTION OF FIRES INVOLVING OILS

Oil is easily flammable if it comes into contact with a flame or spark, utmost care must be taken when working with this fluid.

Follow the precautions listed below:

- keep open flames away;
- stop the machine and do not smoke;
- operate within a well-defined area and do not allow unauthorised persons to approach;
- carefully tighten any caps removed during operations;
- wipe off and dry any spilled oil;
- do not heat the hydraulic devices;
- store the oil in suitable containers and warehouse it in a safe place where access is only permitted to persons authorised to handle it.



# WARNING

#### **DECOMMISSIONING**

#### Park the machine on a flat surface.

Before leaving the machine, lower the equipment and the dozer blade to the ground. Stop the machine, remove the key and close all doors and covers.



# **WARNING**

#### RESIDUAL PRESSURE IN THE HYDRAULIC SYSTEM

Before carrying out any maintenance work on the hydraulic system, the residual pressure must be released, see section "6.30 - Discharge residual pressure in the hydraulic system" to page 6-74.

Please contact the Service Centre for more details.



#### PRECAUTIONS TO BE TAKEN WHILE OPERATING

Never carry out excavations on overhang areas, the edges might collapse or the soil could slide, causing serious injury or fatal accidents.

Do not lift, move or rotate the bucket over people or on the truck cab.

Falling of the loads from the bucket or impacts against the bucket can cause serious injury or damage to the machine.

### 2.8 - Safety devices

### 2.8.1 - Operator protective structure



### WARNING

It is prohibited to remove or change the protective structure.

It is prohibited to operate the machine with no protective structure in place.

It is prohibited to work with the protective structure tipped backward.

It is prohibited to load/unload the machine with the protective structure tipped backward.

The **protective structure** (1) protects the operator from being crushed in the event that the machine tips over or rolls over.

The machine will always be supplied with the operator protective structure (roll-bar).


The protective structure has been tested and has passed the tests according to the following standards:

The protective structure has been tested and has passed the tests according to the following standards:

- ROPS ISO 12117-2 (Roll Over Protective Structure)
- TOPS EN 13531 (Tip Over Protective Structure)

Check that the protective structure is in good condition:

- it must not be damaged;
- it must not have any rusted parts;
- the fastening screws must be correctly tightened.



If at least one of the above problems is found, contact the *Service Centre* to have the structure checked and restored. The protective structure protects the operator from the risk of crushing in the event that the machine tips over or rolls over.

The machine will always be supplied with the operator protective structure (roll-bar).

**DO NOT** change, repair, carry out welding or drilling on the operator protective structure. The protection will be compromised by this, creating a hazard that could cause death or serious injury to persons.

The protective structure, the operator seat and the seat belt must be carefully checked after any accidents. Contact the *Service Centre* to replace any parts that show signs of damage.

#### 2.8.1.1 - FOPS Level I canopy (optional)

On the protective structure, it is possible to install, as an optional, a canopy (1).

The canopy protects the operator from small falling objects (for example: bricks, small blocks of cement, tools, etc...) to which he/she may be exposed while performing maintenance on roads, out in the open or on a construction site.



The canopy has been tested and has passed the tests according to the following standard:

- FOPS ISO 10262 Level I.

The canopy is not supplied as standard and is not an integral part of the standard protective structure.

It is forbidden to modify the FOPS Level I canopy.

# It is forbidden to work without the FOPS Level I canopy if there is the risk of falling objects in the work area.

It is the responsibility of the employer to assess the hazards in the work area and to decide whether a guard against falling objects is necessary or not. If there is the risk of heavy objects falling from a height (for example: trees, rocks, etc...), to which the operator may be exposed while working in environments such as channel digging, overhead demolition or forestation, the machine **MUST NOT** be used.

#### 2.8.2 - Seat belt

The seat belt is essential because it retains the operator anchored to the seat in case of tip-over or roll-over. The condition, cleanliness and mechanical mountings of the seat belt must be checked regularly.

**Operations to be carried out before starting equipment:** before starting the machine, the operator has to fasten the seat belt, after having checked it is in perfect order.

**Operations to be carried out before leaving the machine**: the operator can remove the seat belt only when the machine has come to a stop



Serious injury or death may result from any failure to use the seat belt fitted to this machine. The seat belt is an essential component that complements the operator's protective structure and is provided to protect the operator in the event of the machine tipping over or rolling over. The seat belt MUST be used whenever the machine is being operated.

Inspect the seat belt on each occasion prior to use, in order to identify any cuts or worn webbing, or any defect in the latch assembly. If any wear or damage is noted, DO NOT operate the machine until the seat belt has been replaced.

Before starting the machine, first adjust the seat as required for optimum reach and comfort. Then adjust the seat belt as follows.

### Locking the seat belt:

- take the end of the seat belt (1 from the side of the seat) and pull it across to the other side;
- while holding your back upright on the seat, pull the belt buckle over your body at the level of your pelvis;
- check that the belt is not twisted and that it does not rest on sharp pieces of clothing;
- insert the end of the belt (1) into the latch (2);
- check that it has been inserted correctly by pulling the latch plate (1).



#### Releasing the seat belt:

- press the red button (2) on the buckle;
- remove the latch plate from the buckle (1), and slowly accompany it on the winder to free yourself, then get off the machine.



### **WARNING**

Following an accident, the seat belt must be replaced, the operator seat and the seat fixings must be checked by specialised technicians.

#### 2.8.3 - Controls cut-out lever

The control cut-out lever (safety lever) is located on the left console.

Pulling the lever (1) outwards turns the entire console to the open position (2) and disables all controls.

From the driver's seat, pull the lever (1) inwards until you hear the latch click, the left console returns to the operating position and the control circuit is restored.

Locking the seat belt:




# **WARNING**

This operation must be performed every time one leaves the driver's seat, so as to prevent the accidental activation of the controls while getting on/off the machine.

Each time the console is in the open position, the controls cut-out light (3) on the control panel will turn on.

For normal machine operation, the lever (1) must be closed inwards, the label (4) on the left console indicates the function of the lever itself.





**NOTICE** 

After stopping the machine and leaving the driver's seat, always close the left control panel by pushing it inwards to reduce the space occupied by the machine.

#### 2.8.4 - Slewing locking lever

The slewing of the turning frame can be locked mechanically by means of a specific lever (1) located on the support base at the operator's feet on the left-hand side of the travel levers.


The slewing can be **engaged** only when the turning frame is aligned with the undercarriage, in the following positions:

- with the booms above the dozer blade
- with the booms on the opposite side to the dozer blade.

To **lock** the slewing:

- make sure that the turning frame is aligned with the undercarriage;
- lift the lever (1);
- turn it to position (2);
- lower it so as to lock its position.

To **release** the slewing, carry out the same operations in reverse order.



Always lock the slewing when transporting the machine and at the end of each day of work.




Do not insert the lock when the turning frame is not aligned with the undercarriage because, during the slewing phase, the locking mechanism and the rotation motor may be seriously damaged.

#### 2.8.5 - Emergency stop button

The emergency stop button (1) is positioned on the right console, is red on a yellow background and is shaped like a mushroom, hence why it is called the **emergency mushroom**.

This button stops the machine and therefore all movements and functions are interrupted.

It can be used in situations of risk, for example when control of the machine is lost or before maintenance is performed on the machine.



#### To activate the emergency button:

- press the button until you feel it latch.

#### To restore the machine operating conditions, it is necessary to:

- deactivate the ignition key;
- deactivate the emergency button, turning it clockwise;
- start the machine.

#### 3.1 - General data

MODEL		CX15EV
ISO 6016 operating weight		
without FOPS canopy		
(with bucket and operator)	kg	1,420
ISO 6016 operating weight		
with FOPS canopy		
(with bucket and operator)	kg	1,445
Specific ground pressure		
with or without FOPS canopy	kg/cm <sup>2</sup>	0.32
Travel speed		from 0 to 1 0
	1 <sup>st</sup> - km/h	from 0 to 1.8
	2 <sup>nd</sup> - km/h	from 0 to 3.8
		(AUTO TWO SPEED)
Slewing rotation speed	rpm	9.5

The weights considered for the calculation of the operating weight are:

- bucket 30 kg;
- operator 75 kg.

# If the installed equipment differs from that indicated, the weight of the machine may vary.

The operating weight indicated is referred to the machine with a standard configuration; always take into account the weight of the various accessories installed (e.g. long boom, etc.).

## 3.2 - Engine

MODEL		CX15EV
Туре		Internal permanent magnets (IPM)
Brand		BENEVELLI
Model		SMAC 200-70
Nominal power (S2-30')	kW	11.0
Nominal torque (S2-30')	Nm	38.0
		2,400 ECO
Max. rotation speed	rpm	2,600 STD
		2,800 PWR
Cooling		Air

## 3.3 - Power supply

MODEL	CX15EV
Туре	Battery
Battery chemistry type	LiFePo4
Rated voltage V	102 DC
Nominal capacity Ah	210
Nominal capacity kWh	21.5
Autonomy depending on operating mode h	4 - 8

## 3.4 - Battery charge times

MODEL		CX15EV
On-board charger (220 V)	h	10
Optional 3-phase external		1.0 (80%)
fast battery charger (380 V)	h	1.5 (100%)

## 3.5 - Electrical system

MODEL		CX15EV
Nominal voltage of electrical power system	V	102 DC
Nominal voltage of electrical service system	V	12 DC
Service battery	V - Ah	12 DC - 9
DC/DC Converter	V - V	102 DC - 12 DC

## 3.6 - Hydraulic system

MODEL		CX15EV
Plant type		Open Centre
Pump type		1 gear pump
Pump displacement	СС	10.1
Total flow rate	l/min	28
Operating pressures:		
- first boom		
- second boom		
- bucket	bar	180
- boom swing		
- dozer blade		
- translation motors		
- slewing gear motor		
Electronic servo-controls for work function		3 joysticks + 1 hydraulic pedal
Travel		Variable displacement hydraulic orbital gear motors
Slewing		Hydraulic orbital gear motor

**For the data of the auxiliary hydraulic systems, refer to section** "6.31 - Auxiliary hydraulic systems" to page 6-75.

#### 3.7 - Performances

MODEL		CX15EV
Bucket breakout force (standard boom) ISO 6015	daN	1,150
Boom breakout force (standard boom) ISO 6015	daN	630
Tractive force	daN	1,000
Climbing capacity	%/°	60/30

## 3.8 - Digging arm

MODEL		CX15EV
First boom length	mm	1,460/1,550
Second boom length	mm	900 / 1,020 / 1,150

The difference in weight between the various booms is negligible.

Possible configurations for the machine with the different booms:

	FIRST BOOM	SECOND BOOM
A	1,550 mm	1,020 mm
В	1,550 mm	1,150 mm
С	1,460 mm	900 mm
D	1,460 mm	1,020 mm

## 3.9 - Counterweight

MODEL		CX15EV
Base counterweight	kg	53

### 3.10 - Dozer blade

MODEL		CX15EV
Width	mm	790 - 1,050
Height	mm	220
Stroke height	mm	225
Stroke depth	mm	225
Distance from the centre of the slewing ring	mm	1040

## 3.11 - Undercarriage

MODEL	CX15EV
FRAMED UNDERCARRIAGE	VARIABLE with hydraulic extension
Lower rollers	3 rh + 3 lh - oil bath
Upper rollers	not present
Track tensioner	In oil bath with hydraulic grease regulation of the tension of the track
Rubber tracks mm	180 x 43 x 72

### 3.12 - Brakes

MODEL	CX15EV
	Type: hydrostatic.
Service brake on travel and rotation	<b>Brake activation</b> : it is activated automatically when the movement control lever is released (the distributor spool, together with the balancing valves (counter balance valve) of the drive units, closes the oil passage completely or partially).
	<b>Brake deactivation</b> : it is deactivated automatically when the movement control lever is moved (the distributor spool moves from the centre towards the use, opening the oil passage).
	<b>Type</b> : mechanical with Load Holding Mechanism function inside the engines.
Secondary and parking brake on travel	<b>Brake activation</b> : it is activated automatically when the movement control lever is released (in the absence of movement control pressure, the Load Holding Mechanism function guarantees the braking torque by friction).
	<b>Brake deactivation</b> : it is deactivated automatically when the movement control lever is moved (the movement control pressure overcomes the friction of the Load Holding Mechanism function).
	Type: mechanical with pin.
Secondary and parking brake on rotation	<b>Brake activation</b> : it must be performed manually by lowering the dedicated pin.
Totalon	<b>Brake deactivation</b> : it must be performed manually by lifting the dedicated pin.

#### 3.13 - Nominal lifting capacity



## **WARNING**

The machine is not equipped for handling objects, therefore such operations are forbidden. The handling of objects may cause the tip-over or roll-over of the machine and result in serious injuries or death.

The **nominal lifting capacity** is the maximum weight that can be applied to the bucket pin (weight of equipment with any loaded material).

The nominal lifting capacity refers to:

- machine positioned on sound, firm and level ground;
- the indicated capacities remain valid for the full slewing range of the turning frame;
- boom in NON-slewed position (if present);
- the indicated capacities refer to the bucket hinge pin;
- outreach referred to the centre of rotation (slewing ring);
- undercarriage extended to maximum track widening (if present);
- machine without quick-coupling attachment and equipment;
- all the protective structures available;
- all types of tracks available;
- the lifting capacities do not exceed 75% of the tip-over or roll-over limit or 87% of the hydraulic limit, in accordance with Standard **ISO 10567**;
- for some optional equipment, the Standards indicate that the nominal lifting capacities
  must be reduced in certain operating conditions. For information on the equipment in
  use, see the relevant section in the chapter "7 Recommended optional equipment"
  to page 7-1.



## **WARNING**

When the machine is used in conditions other than those indicated in the manual (for instance, on a surface which is not compact, but rough or slippery, or on a slope, etc.), the operator must take into account the new conditions that reduce the machine's stability and capacity. The operator must therefore work at lower speeds and with lighter loads so as to ensure the stability of the machine.

The capacities shown must be adapted depending on the type of equipment fitted.



## **WARNING**

The cylinder of the dozer blade is NOT equipped with a security valve, so the dozer blade must not be used to stabilise the machine.


If the dozer blade is used improperly, the hydraulic hoses can get damaged and cause a sudden loss of stability of the machine with the consequent damage to the operator and/or to the machine.

Lift capacities shown are for a machine with fully extended undercarriage, no quick coupler, and without bucket.

The symbol \* indicates the hydraulic load limit.

**0 m** refers to the ground level.

The lifting capacity is measured in **tonnes**.



Possible configurations for the machine with the different booms:

	FIRST BOOM	SECOND BOOM
A	1,550 mm	1,020 mm
В	1,550 mm	1,150 mm
С	1,460 mm	900 mm
D	1,460 mm	1,020 mm

## A - Blade raised, First Boom 1,550 mm - Second Boom 1,020 mm

							B (m)						
⋖	1,	1.0	1.	1.5	2.	2.0	2.	2.5	c,	3.0		MAX	
(E)	-	3		8	<b>-</b>	8	<b>-</b>	å	<b>-</b>	8	<b>-</b>	8	
2.5		1		-	1	1	1	1	1		*0.28	0.21	2.20 m
2.0	-	-	-	1	1	1	0.25	0.17	1	-	0.22	0.15	2.70 m
1.5	-	-	l	l	l	1	0.25	0.17	1	-	0.18	0.12	3.00 m
1.0	-	1	*0.43	0.37	*0.35	0.24	0.25	0.17	0.19	0.12	0.18	0.12	3.10 m
0.5		1	0.51	0.32	0.33	0.22	0.24	0.15	0.18	0.12	0.16	0.10	3.20 m
0		1	0.49	0.31	0.32	0.20	0.23	0.15	0.18	0.11	0.16	0.10	3.20 m
-0.5	N.A.	0.61	0.49	0:30	0.31	0.20	0.22	0.14	1		0.17	0.11	3.00 m
-1.0	N.A.	0.62	*0.44	0.31	*0.31	0.20	*0.22	0.15	1	-	*0.17	0.13	2.70 m
-1.5		1	*0.29	*0.29	*0.20	*0.20	l	l	1	1	*0.16	*0.16	2.20 m

## B Blade raised, First Boom 1,550 mm - Second Boom 1,150 mm

							B (m)						
⋖	1,	1.0	1.	1.5	2.	2.0	2.5	2	.c.	3.0		MAX	
(E)	-	3		8		8	<b>-</b>	å	<b>-</b>	8	<b>-</b>	8	
2.5	1	!	!	l	1	-	1	1	-	-	*0.25	0.18	2.40 m
2.0		1	1	1	-	1	1	l	*0.23	0.17	0.21	0.14	2.80 m
1.5		1	1	l	1	1	*0.24	0.17	0.18	0.12	0.17	0.11	3.10 m
1.0	-	1	ļ	1	*0.30	0.24	0.25	0.17	0.19	0.12	0.16	0.10	3.30 m
0.5		1	0.52	0.33	0.33	0.22	0.23	0.15	0.18	0.11	0.15	0.10	3.30 m
0		1	0.49	0.31	0.32	0.20	0.23	0.15	0.17	0.11	0.15	0.10	3.30 m
-0.5	*1.02	09:0	0.48	0:30	0.31	0.20	0.22	0.14	0.17	0.11	0.16	0.10	3.10 m
-1.0	*0.83	0.61	*0.47	0:30	0.31	0.20	0.22	0.14	1	1	*0.16	0.12	2.90 m
-1.5	-	1	*0.34	0.31	*0.23	0.20	l	ŀ	ł	ŀ	*0.15	*0.15	2.40 m

## C - Blade raised, First Boom 1,460 mm - Second Boom 900 mm

							B (m)						
4	Į.	1.0	1.	1.5	2.0	0	2.	2.5	w.	3.0		MAX	
(m)		8	<b>-</b> -	8		8	<b>-</b>	8	<b>—</b>	8	<u>-</u>	8	MAX
2.5			!	-	1	1	-	1	1	-	*0.33	0.29	1.80 m
2.0	-	-	1	1	-	1	-	1	-	-	0.26	0.18	2.40 m
1.5	l	1	I	l	*0.28	0.24	0.25	0.17	1	1	0.21	0.14	2.80 m
1.0	-	-	*0.46	0.37	0.35	0.24	0.25	0.17	-	-	0.20	0.13	2.90 m
0.5	-	-	0.51	0.33	0.33	0.22	0.24	0.16	-	-	0.18	0.12	3.00 m
0	-	-	0.49	0.31	0.32	0.21	0.23	0.15	-	-	0.19	0.12	2.90 m
-0.5	N.A.	0.62	0.49	0.31	0.31	0.20	0.23	0.15	1	1	0.2	0.13	2.80 m
-1.0	*0.66	0.63	*0.41	0.31	*0.29	0.20		l	1		*0.19	0.16	2.40 m

## D - Blade raised, First Boom 1,460 mm - Second Boom 1,020 mm

							B (m)						
⋖	1,	1.0	1,	1.5	2.	2.0	2.	2.5	c,	3.0		MAX	
(E)	-	3		8	<b>-</b>	8	<b>-</b>	å	<b>-</b>	8	<b>-</b>	8	
2.5		1		-	1	1	1	1	1	-	*0.31	0.24	2.00 m
2.0		-	ļ	1	1	1	0.25	0.17	1	-	0.24	0.16	2.60 m
1.5	-	-	-	1	1	1	0.25	0.17	1	-	0.20	0.13	2.90 m
1.0	-	1	ŀ	l	*0.34	0.24	0.25	0.17	0.19	0.13	0.18	0.12	3.10 m
0.5		1	0.53	0.34	0.34	0.22	0.24	0.16	0.18	0.12	0.17	0.11	3.10 m
0		1	0.50	0.32	0.32	0.21	0.23	0.15	0.18	0.12	0.17	0.11	3.10 m
-0.5	N.A.	0.62	0.49	0.31	0.32	0.20	0.23	0.15	1	-	0.19	0.12	2.90 m
-1.0	N.A.	0.62	*0.45	0.31	*0.31	0.20	*0.21	0.15	1	-	*0.18	0.14	2.60 m
-1.5		1	*0.29	*0.29	*0.18	*0.18	l	l	1	1	*0.16	*0.16	2.10 m

## 3.14 - Standard / optional equipment

The following table indicates the different equipment available for the machine.

## **Equipment key:**

• STANDARD OPTIONAL / NOT AVAILABLE
-------------------------------------

EQUIPMENT	CX15EV
Roll-bar ROPS/TOPS	•
FOPS Level 1 canopy	0
Hydraulic track widening	•
Double travel speed with AUTOMATIC SHIFT DOWN	•
Horn for travel movement	•
Extendible dozer blade with extensions	•
Rubber tracks	•
Short first boom	0
Long first boom	•
Short second boom	0
Second standard boom	•
Long second boom	0
Boom swing	•
Guard on dozer blade cylinder	•
Auxiliary hydraulic system on AUX1 boom	•
Auxiliary hydraulic system on AUX2 boom	0
Single-acting/double-acting mechanical switch on AUX1 auxiliary hydraulic system	•
Electronic adjustment of the speed of each movement and of the flow rate of each auxiliary hydraulic system	•
ISO-SAE controls inversion TPSS function	•
220 VAC on-board battery charger	•
380 VAC portable battery charger	0

EQUIPMENT	CX15EV
LED working light on first boom	•
LED working lights on roof on front side	0
Rotating head lamp	0
Auxiliary power socket at the driver's seat	•
Geo-localisation system	•
Seat with safety seat belt	•
Use and maintenance manual	•
Document glove box	•
Interchangeable equipment to be fitted to the second boom (refer to section "7.1.1 - Specifications on authorised equipment" to page 7-4	0

#### 3.15 - Rotary structure

The upper structure of the machine (turning frame, booms) rotates independently from the bottom section (undercarriage). This movement is permitted by the slewing ring, which ensures movement of parts with minimum friction. The slewing ring consists of two rings free to rotate with each other; one is securely joined to the undercarriage, the other to the turning frame.

### 3.16 - Fluid capacities

Refer to section "8.6.1 - Refilling quantity table" to page 8-12.


MODEL	CX15EV
Hydraulic oil tank	9,5
Hydraulic system I	15

#### 3.17 - Overall dimensions


Overall dimensions are given in **mm** for machine equipped with standard 2nd arm and excavation bucket with standard attachment.

If in round brackets (xxx), they refer to machines with optional 2nd arm.


#### Machine equipped with first boom 1,460 mm.




## Machine equipped with first boom 1,460 mm.



## Machine equipped with first boom 1,550 mm.



## Machine equipped with first boom 1,550 mm.



#### 3.18 - Sound emission

#### **SOUND PRESSURE**

NAME		CX15EV
ISO 6396 - LpA		
(recorded at the driver's seat)	dB(A)	75

#### **SOUND POWER**

NAME		CX15EV
2000/14/EC - LwA		
and subsequent changes	dB(A)	82

The guaranteed sound power level is indicated on a sticker attached to the machine (refer to section "2.3 - Safety signs and operation related labels" to page 2-5).



#### 3.19 - Vibrations

The vibrations level transmitted to the operator depends mainly on the conditions of the ground on which the machine is operating, on the work methods being applied and the equipment fitted to the machine.

Exposure to vibration can be reduced substantially by complying with the following suggestions:

- use equipment suitable for the type of machine and the type of task to be performed;
- adjust and lock the seat in the appropriate position; inspect on regular basis the seat suspension, making any necessary adjustments and performing any necessary maintenance;
- regularly perform any maintenance operation of the driving position;
- operate the accessories smoothly, as far as possible, avoiding any sudden movements or excessive jolts;
- adjust your speed and path and, as far as possible, avoid particularly rough paths and hitting possible obstacles, so as to minimise the vibration level.

The machine has been tested in accordance with the following regulations:


- ISO 2631
- EN ISO 5349
- EN 1032
- EN 12096

HAND-ARM VIBRATIONS		
Vibration level	m/s²	1.13
Measurement uncertainty	m/s²	0.56

VIBRATIONS OF WHOLE BODY		
Vibration level	m/s²	0.94
Measurement uncertainty	m/s²	0.47

Tests performed without load on a flat, compact surface.

The values indicated refer to continuous exposure during an 8-hour working day.



#### 4 - TRANSPORTING THE MACHINE



## **WARNING**

Make sure that the truck used to transport the machine has an adequate load capacity.

Before loading the machine, make sure the truck bed and/or the loading ramps are clean and free of any traces of grease, oil, soil, ice or other slippery residues.


A non-slip mat with a friction coefficient of at least 0.6 is required, to be placed between the tracks and the loading platform.

Do not change direction on the ramps. Align the machine with the ramps before getting on and travel in a straight line.

During transportation, the machine must be anchored to the means of transport; to anchor it use the appropriate anchor points.

Follow current standards regarding width, height, weight and transport speed allowed.

## 4.1 - Shipping dimensions



	MODEL	CX15EV
Α	Pitch mm	1,100
В	Machine-side length mm	3,180
С	Undercarriage width mm	1,050
D	Height mm	2,300

The weight of the machine is indicated in section "3.1 - General data" to page 3-1.


#### 4.2 - Loading/unloading operations

It is recommended to use a special platform while loading and unloading the machine from the means of transport.

However, it is permitted to use loading ramps, in this case also consult the use and maintenance manual provided by the manufacturer of the ramps.

Before using ramps to load or unload the machine:

- perform loading/unloading operations on flat and compact ground, keep a safe distance from the edges of canals or roads;
- ensure that the nominal load capacity of the ramps is adequate for the weight of the machine and that each ramp is at least as wide as the track;
- the ramps **MUST NOT** form an angle greater than 16.5° (30% slope);



- fit the ramps so that the axis of the machine is aligned to the track axis;
- the ramps must be rigidly connected (1) to the truck deck to avoid possible disconnection while the machine is being loaded;
- at the contact zone of the track with the ground (2) do not allow a level difference greater than 50 mm; therefore choose ramps with bevelled support;
- make sure the parking brake of the means of transport is engaged;
- apply wedges to block the wheels of the means of transport;
- place a non-slip mat on the loading platform of the truck, in the area where the machine will be placed;
- if necessary, remove the bucket or equipment to suit the size or maximum capacity of the means of transport. They can be transported in an appropriate manner.



## NOTICE

At low temperatures (below  $+5^{\circ}$ C), follow the instructions given in the relevant section before starting the loading/unloading manoeuvres.



## **WARNING**

To reduce the risk of personal injury caused by the machine tipping over or rolling over, DO NOT attempt to change the machine direction and DO NOT activate any lever other than the travel lever while the machine is on a loading ramp.

Load the machine according to the indications:

- **1 -** align the turning frame to the undercarriage so that the dozer blade stays near the boom;
- **2 -** if the machine is equipped with an extendible undercarriage and dozer blade, it is preferable to keep them in an extended position to increase their stability;
- **3** point the rear of the machine to the means of transport;
- **4 -** Align the machine to the means of transport.
- **5** Start loading the machine in reverse. Have another operator watch the loading/unloading operations from a safe distance so as to warn the driver on possible hazardous situations which are not visible from the driver's seat.



## **WARNING**

When reversing, pay attention to the direction of the controls which may not be intuitive, see section "6.22.1 - Forward and reverse travel" to page 6-53 and "6.22.4 - Turning while reversing" to page 6-56.

**6** - If, when climbing the ramp, the machine is not aligned, go back to the starting position and repeat the aligning phase, then resume the loading procedure.



## **WARNING**

As the machine passes over the top of the ramps during loading, it will pivot on the centre of its tracks towards the level of the truck or deck of the means of transport. Maintain a slow, steady movement until the machine completes this rotation movement and both tracks are in full contact with the deck of the means of transport.

#### TRANSPORTING THE MACHINE

- **7 -** Position the machine on the means of transport and lower the dozer blade onto the deck;
- **8** close the bucket or the equipment, retract the second boom and lower the digging arm onto the deck to reduce the overall footprint to the minimum;
- **9 -** park the machine according to the indications given in section "6.26 Parking the machine" to page 6-65;
- **10** make sure that the machine tracks are on the non-slip mat, for the entire surface; if not, reposition the machine correctly;
- **11** secure the machine to the deck of the means of transport as indicated in the following section.

To unload the machine, follow the procedure above in reverse order.



## **WARNING**

During unloading operations, the machine will pivot again as it crosses over the top of the ramp. Maintain slow, steady progress until the machine completes this pivoting movement and both tracks are fully in contact the ramps.



## WARNING

When loading/unloading the machine, the protective structure must NOT be tipped over.

The structure can only be tipped over after the machine has been loaded and must be repositioned before starting the unloading procedure.

To reduce the footprint in height during transport, the protective structure can be tipped over, for indications, refer to section "6.33 - Protective structure opening procedure" to page 6-84.

#### 4.3 - Securing the machine on the means of transport


Before loading the machine, see the identification plate attached to it to know the weight and make sure that the truck used to transport it has an adequate load capacity.

After having loaded the machine onto the truck, position it and secure it as indicated below and on the special operation label (1).

Collect the boom and rest it on the loading platform, in order to reduce the overall dimensions as much as possible; pay particular attention to the maximum height and to anything that may protrude from the back of the truck.

If bulky equipment is installed, remove it and transport it separately, taking care to secure it as indicated by its manufacturer.

Position any equipment installed in such a way that it cannot move during transportation. If necessary, secure it using dedicated fastening elements.



To avoid damage to the anchoring elements and/or to the anchor points of the machine, use guards for sharp edges.

The accessories used to secure the machine and the fixing points of the means of transport must have suitable capacity.


Check and follow the Standards in force in the country the transport is carried out.

#### TRANSPORTING THE MACHINE

The machine can be anchored as shown in the figure:

#### **CONFIGURATION 1**

Boom in opposite position to blade with 4 anchor points: 2 front and 2 rear on turning frame.




Anchor points on DOZER BLADE SIDE		
Allowed range of values	CX15EV	
A1	200 - 600 mm	
B1	1,050 - 2,450 mm	

Anchor points on SIDE OPPOSITE TO DOZER BLADE		
Allowed range of values	CX15EV	
A2	450 - 750 mm	
B2	1,050 - 2,450 mm	

Anchoring capacity of the fastening system	
Minimum value	CX15EV
LC (Lashing Capacity)	1,000 daN

### **CONFIGURATION 2**

Boom in blade position with 4 anchor points: 2 front and 2 rear on turning frame.



Anchor points on DOZER BLADE SIDE		
Allowed range of values	CX15EV	
A1	620 - 1,000 mm	
B1	1,400 - 2,450 mm	

Anchor points on SIDE OPPOSITE TO DOZER BLADE	
Allowed range of values	CX15EV
A2	350 - 750 mm
В2	1,400 - 2,450 mm

Anchoring capacity of the fastening system	
Minimum value	CX15EV
LC (Lashing Capacity)	1,000 daN

#### 4.4 - Lifting of the machine



## **DANGER**

When lifting the machine, comply with the Standards in force in the machine's country of use.

Before lifting the machine, make sure that the lifting device has a suitable capacity in relation to the weight of the machine.

Use clean, undamaged lifting accessories (cables, ropes, chains, shackles, etc.) of adequate capacity.

Use only the anchorage points indicated in the specific label.

Never lift the machine with the operator on board.

Do not lift the machine if it is blocked by mud, debris or ice.

Do not allow access near the machine.

While lifting, keep the machine in horizontal position.

Nobody must stand under the machine when it is lifted from the ground.

Lift the machine ONLY as indicated by the procedure; other methods are risky and therefore forbidden.

Do not use the fillets of the counterweight and/or of the protective structure, to lift the machine; it may break and cause the machine to fall, resulting in serious damage to people or objects.

In order to reduce the risk of accidents and serious damage to people as much as possible, all staff in charge of operating the lifting device and the relative operations must be specialised and must have been appropriately trained. It is their responsibility to ensure that proper equipment is used to lift the machine.



For details on the weight of the machine, refer to section "6.1 - Commissioning" to page 6-1.

The lifting procedure is valid for the machine with standard equipment (bucket) or without equipment. If the machine features different equipment, remove it before starting the lifting procedures.


If in doubt, contact the Service Centre.

#### 4.4.1 - Lifting procedure

The machine must be lifted on a flat and compact surface via the following procedure:

- **1 -** start the engine, rotate the turning frame so that the boom is on the opposite side to the blade, with the turning frame parallel to the tracks;
- **2** move the boom to a swing angle equal to **0**° (if present);
- **3** lift the first boom completely;
- 4 close the bucket completely;
- **5** close the 2nd arm until there is a distance of about **10** cm between the digging boom or the bucket, and the machine;
- **6** raise the dozer blade completely;
- **7** open the controls cut-out lever;
- 8 Enable the slewing lock (if provided);
- **9** stop the machine, close the windows (if any), remove the starting equipment key, then get out of the machine. Close the cab door (if present);
- 10 attach the lifting accessories to the points of the machine intended for that purpose, as shown in the figure (these points are identified on the machine by means of special labels 3):
  - one for each side to the left and right of the dozer blade (1);
  - one for each side to the left and right of the top part of the first boom (2);
- **11** respect the minimum height indicated in the figure to avoid contact between the lifting accessories and the machine, a greater height is allowed;

#### 12 - lift the machine slowly.



**H** Minimum ground height of the anchoring point

4,000 mm

The lifting instructions are given in a simplified manner on a special label (5) applied to the machine.

When the machine has been lifted from the ground, stop the lifting operations and make sure that the machine is in a **HORIZONTAL POSITION**; if the position is not correct, adjust the length of the accessories, then continue with the lifting operations;



- **13** move the machine to the desired place and lower it slowly; the supporting surface must be flat and compact;
- 14 when the machine is completely resting on the ground, disconnect the accessories.

#### 4.5 - Recovering and towing the machine



## **WARNING**

When towing the machine, comply with the Standards in force in the machine's country of use.

Before towing the machine, make sure that the towing vehicle has adequate braking power and capacity to control both machines.

Use a rigid tow bar, with a capacity of at least 150% of the weight of the towed machine. The bar must be clean and free of damage. Comply with the safety instructions given by the manufacturer of the same.

Use only the anchorage points indicated in the specific label.

Nobody must stand near the machine while towing; only the operators on the two machines can be present. Since it is not possible to control the towed machine completely, other people may get crushed resulting in serious injuries.

Tow the machine ONLY as indicated by the procedure; other methods are risky and therefore forbidden.



## **NOTICE**

It is forbidden to tow the machine with other mechanical means for long distances; there is a risk of damaging the travel system.

Towing must be performed only when strictly necessary.

These instructions refer to moving the machine when it has broken down or is stuck in the ground.

If the machine has broken down, try to repair it on site if possible, thus avoiding towing operations. If this is not possible (e.g. machine stuck on a road full of traffic) proceed with towing.


If the machine is stuck in the ground (e.g. muddy ground), proceed with recovery by towing it only as much as necessary to pull it out.

## When towing, meet the following conditions:


- while towing, the operator **MUST NOT** be on the towed machine;
- tow the machine on flat surfaces only;
- the distance towed should be as short as possible; for long distances, load the machine on a truck;

#### TRANSPORTING THE MACHINE

- tow at a maximum speed of 1 km/h;
- maintain a sufficient distance to avoid contact between the machine and the towing vehicle; this distance must be under **3** m;
- while towing, do not allow anyone to access the space between the towing vehicle and the machine;
- maintain a sufficient distance to avoid contact between the machine and the towing vehicle; this distance must be under **3** m;
- while towing, do not allow anyone to access the space between the towing vehicle and the machine;
- connect a tow bar to the dedicated tow hook of the undercarriage (1), the hooks are indicated by the dedicated labels (2).
- DO NOT use other anchorage points (e.g. boom, bucket or any accessory installed);



- the tow bar must be positioned as indicated below;



A	Maximum horizontal pull angle	35°
В	Maximum vertical pull angle	20°


- **NEVER** continue towing unless both tracks are fully in contact with the ground.



## **5 - CONTROLS AND TOOLS**


The function of each control and tool is described in detail in chapter "6 - Using the machine" to page 6-1.

## 5.1 - Description of main controls and levers




1	Left travel lever	5	Controls cut-out lever
2	Right travel lever	6	Left Joystick
3	Left control console	7	Right joystick
4	Right control console	8	Dozer blade lever

# **5.2 - Description of left control console**



1	Boom swing roller/AUX 2 hydraulic system (optional)	3	Optional electrical button 2
2	Optional electrical button 1	4	Horn button

# **5.3 - Description of right control console**



1	Roller AUX1 hydraulic system	5	Starting equipment switch
2	Lock button AUX1 hydraulic system	6	Vehicle status warning indicators
3	Fast drive button	7	Emergency stop button
4	Boom swing/AUX 2 hydraulic system selector button (optional)	8	Current tap

## 5.4 - Roller operation

The rollers are proportional electric controls, not retained, which control hydraulic functions; depending on the installation, they can turn to the right/left or up/down.

A greater movement of the roller gives a proportionally quicker response from the associated function.



The rollers are very sensitive, so take care when working not to touch them by accident, an unwanted hydraulic function could occur compromising the safety of the operator and anyone nearby.


## 5.5 - Optional electrical buttons on the joystick

The electrical buttons, on the joysticks, can be used to activate some optional functions. For details, see the control sticker near the driver's seat.


## 5.6 - Auxiliary power socket on console

An auxiliary socket (1), used to connect the rotating head lamp, is located on the left control console. The socket is of the ISO 4165 standard two-pin type, powered by 12V.

The socket is *locked*; it is powered only when the key in the starting equipment switch is in the STARTING EQUIPMENT position.



## **5.7 - Machine status warning indicators**



## Key:

1 Machine status indicator light on

2 Machine charging status indicator light

## MACHINE STATUS INDICATOR LIGHT ON

This light indicates when the machine is on.




#### MACHINE CHARGING STATUS INDICATOR LIGHT

This light comes on when the charging cable is connected.



## 5.8 - Control panel



1	Display	8	Warning indicator lights
2	Function keys	9	Push-button menu and relative icon
3	Navigation console	10	Boom working lights indicator light and button
4	Hour	11	Canopy working lights indicator light and button
5	Machine hours	12	Indicator light and button for dozer blade/undercarriage width adjustment selector
6	Control mode indicator light and button	13	Indicator lights and work mode management buttons
7	Engine data and battery data		

#### **ROTATION SPEED INDICATOR**

Indicates the current engine speed.

The value is expressed both in percentage, on the left side, and graphically, on the right side.



#### **BATTERY LEVEL INDICATOR**

Indicates the battery charge level.

The value is expressed both in percentage, on the left side, and graphically, on the right side.



#### **CONTROLS CUT-OUT LIGHT**

Turns on when the controls cut-out lever is open.

When this indicator light is on, no movements can be made with the machine.



#### **MAINTENANCE LIGHT**

Lights up when the routine maintenance period has expired.



#### **HYDRAULIC OIL TEMPERATURE LIGHT**

Turns on when the hydraulic oil temperature is too high.



#### **ALARM LIGHT**

Turns on whenever an alarm message appears, remains lit as long as the alarm is present.



#### **FAST DRIVE INDICATOR LIGHT**

Lights up when fast drive is engaged.



#### **AUX1 HYDRAULIC SYSTEM OPERATION LIGHT**

It turns on when the electrical stop of the AUX1 hydraulic system is active.



## **EQUIPMENT LIGHT**

Indicates the setting of the selected auxiliary hydraulic systems, in combination with a specific piece of equipment.

For further details see section "6.11.3 - EQUIPMENT screen" to page 6-18.



### **BOOM SWING/AUX2 HYDRAULIC SYSTEM SELECTOR LIGHT**

Indicates the active function between the boom swing or AUX2 hydraulic system (optional).

The light is only present if the system is installed.



#### **BOOM WORKING LIGHTS INDICATOR LIGHT**

It is the indicator light combined with the relative button, indicates the status of the working lights on the boom. Turns on when the working lights are activated.



## **CANOPY WORKING LIGHTS INDICATOR LIGHT (optional)**

It is the indicator light combined with the relative button, indicates the status of the working lights on the canopy. Turns on when the working lights are activated.

The button and relative indicator light are only active if the optional lights are installed.



# DOZER BLADE SELECTOR / UNDERCARRIAGE WIDTH ADJUSTMENT INDICATOR LIGHT

Indicates the active function between dozer blade or undercarriage width adjustment.



### **POWER WORK MODE INDICATOR LIGHT**

It is the indicator light combined with the relative button, which indicates that the **Power** work mode is active; suitable for particularly heavy workloads.



#### STANDARD WORK MODE INDICATOR LIGHT

It is the indicator light combined with the relative button, which indicates that the **Standard** work mode is active; suitable for normal work operations.



#### **ECONOMY WORK MODE INDICATOR LIGHT**

It is the indicator light combined with the relative button, which indicates that the **Economy** work mode is active; suitable to optimise consumption.



The signals, lights and buttons only operate once the key starter switch has been turned to the IGNITION position.

## 5.9 - Display

By means of software designed and custom made for each machine, the display on the operator panel shows information and any machine operating errors.

The information is displayed in the form of numbers and letters.

The way it works is described in section "6.9 - Control panel operation" to page 6-7.




## 5.10 - Battery disconnect switch (emergency stop button)

The battery disconnect switch functions are performed by the emergency stop button (1), which is located on the right console.

This button stops the machine by interrupting the flow of current, therefore all movements and functions are interrupted.

For operation see section "6.2 - Battery disconnect switch (emergency stop button)" to page 6-3.



### 5.11 - Geo-localisation system



## NOTICE

the CASE CONSTRUCTION **SiteWatch™** website (www.casesitewatch.com) will not be accessible until the CASE CONSTRUCTION **SiteWatch™** subscription for this machine is registred by an authorized CASE CONSTRUCTION dealer. Contact an authorized CASE CONSTRUCTION for details.

This machine can be equipped with a telematics system. This is an asset-monitoring system that combines Internet, cellular, and GPS technologies. A transponder unit is mounted on the equipment that wirelessly communicates with the user interface CASE CONSTRUCTION **SiteWatch™** at www.casesitewatch.com. Using cellular technology, the transponder can send equipment data, including location, on/off status, usage and production metrics, diagnostic data, movement alarms, and unauthorized usage to the interface. The system will help cut costs and keep accurate records. See the furnished quide for operating your telematics system.



# WARNING

Do not remove, repair, modify or move the communication terminal, the antenna or cables, as this could cause a breakdown or short-circuit in the equipment or to the machine itself.

The Service Centre will take care of equipment removal and installation. Prevent cables or wires from being crushed or damaged, do not pull cables or wires with undue force. Short-circuits or disconnected wires could lead to the equipment or the machine breaking down or catching fire.



# NOTICE

The system absorbs a small amount of energy even when the machine is turned off. In the event of prolonged machine inactivity, carefully follow the instructions given in section "8.9 - Long inactivity periods" to page 8-44.

Because the system provides wireless communication, it does not guarantee operation in tunnels, underground, in buildings or in mountainous areas where radio waves cannot be received. Even when the machine is positioned outdoors, operation is not guaranteed in areas where the radio signal is weak or absent.



PAGE LEFT INTENTIONALLY BLANK

## 6 - USING THE MACHINE



# **WARNING**

Safety is dependent on the operator's actions and attitude.

Incorrect use of the machine can be dangerous.

Before starting work, concentrate all your attention on what you are about to do, and take all the necessary precautions.

After ensuring the machine is safe and in good working order, remember that everyone using it must be suitably trained in regards to its use, must be well informed about the hazards deriving from the use of the machine and must be aware of all procedures to be followed to ensure a correct use.

## 6.1 - Commissioning

Carefully read through the information below and always comply with the requirements. Should any malfunctions occur with the operation of the machine, contact the Service Centre.



# **DANGER**

DO NOT check or top up the hydraulic oil tank or other flammable liquids in the presence of open flames or sparks.



# **WARNING**

Remove all dirt from the working lights and check to ensure that they switch on properly.

Remove all dirt from the surface of the rear-view mirrors and check that they are correctly positioned (if present).

Check that no mud or dirt has accumulated around any of the moving parts and ensure that the controls are functioning properly.

Adjust the operator seat to a comfortable position that facilitates machine operation, and check for any signs of damage or wear on the seat belt and its locking mechanism.



# **WARNING**

Check that the warning lights are working properly and check the angle of the headlights and working lights.

Before starting up the engine, fasten the seat belt and lift the control cut-out lever.

Check that there are no people or obstacles on, under or anywhere in the vicinity of the machine.

Before moving the machine or operating the equipment, ensure no persons are present in the surrounding working area.

Acquaint yourself with the rules relating to the use of machines in the working area.

Always maintain a safe distance from other machines and obstacles in order to ensure ideal conditions of visibility.

The cylinder of the dozer blade is NOT equipped with a security valve, so the dozer blade must not be used to stabilise the machine. If the dozer blade is used improperly, the hydraulic hoses can get damaged and cause a sudden loss of stability of the machine with the consequent damage to the operator and/or to the machine.

When reversing, turn the turning frame so as to always look in the direction of movement. Pay attention to the presence of people in the area: should someone enter the manoeuvre area, stop the machine immediately.

**Use only equipment that complies with the indications in chapter** "7 - Recommended optional equipment" to page 7-1.

Follow the provisions of the machine lifting capacity tables and ascertain whether there are any load restrictions imposed by the ground, paving or ramps on which you are to work.

Do not leave the machine until the bucket or equipment and the dozer blade are fully lowered and the machine turned off.

Never leave the machine on without supervision, the operator is liable for the use of the machine by unauthorised persons.

While using the machine, avoid any sudden swerves, abrupt acceleration or braking and making sharp turns. If there is any doubt about the function of the controls, stop the machine and refer to the operation manual.

## 6.2 - Battery disconnect switch (emergency stop button)


The battery disconnect switch functions are performed by the emergency stop button (1), which is located on the right console.

This button stops the machine by interrupting the flow of current, therefore all movements and functions are interrupted.

#### **ALWAYS SWITCH OFF:**

- before carrying out maintenance on the machine, so that it cannot be turned on accidentally by others;
- at the end of the working day before leaving the machine, to prevent any short circuits that could set fire to the machine.

For instructions on use, refer to section "2.8.5 - Emergency stop button" to page 2-48.





Always cut off the power supply before performing operations on the battery or on the electrical system.

#### 6.3 - Driver's seat

The operator seat is equipped with an approved seat belt (1) with two connection points and adjustable in length.

Before starting work, the operator can choose the most comfortable driving position depending on his/her physique by making the adjustments described below.

After adjusting the position of the seat, fasten the seat belt so that it can hold the operator at the waist, leaving the abdomen completely free.





# **WARNING**

Do not operate the seat adjustment levers while the machine is operating. During this operation the control levers could be accidentally moved and generate uncontrolled movements of the machine and therefore cause serious or fatal injuries.

To prevent accidents, before starting the machine check that all adjustments have clicked into place properly.




# **CAUTION**

Do not leave any objects near the seat because during the movements there may be collisions and this may damage the seat or injure the operator.

# LENGTHWISE ADJUSTMENT OF THE SEAT IN RELATION TO THE CONSOLE

Move the adjuster lever externally to release the runners, adjust the seat lengthwise in relation to the consoles.

After making the adjustment make sure that the lever "clicks" to secure the runners. Check that the seat does not move any further backwards or forwards.



#### USING THE MACHINE

The seat position should always be adjusted to suit the operator's physique.

A seat adjustment that is unsuited to the operator or to the type of work to be performed may lead to premature operator tiredness and result in the improper operation of the machine.

The seat position should be individually adjusted for each machine operator.

The operator must be in a position to press the pedals down fully and to operate the control levers properly, with his back resting comfortably against the backrest.


If not, move the seat forwards or backwards and then try again.

#### 6.4 - Arm rests

The arm rests can be adjusted in height.

Height adjustment is carried out for each arm rest as follows:

- slightly unscrew knob (1) counter-clockwise;
- pull it outwards and simultaneously raise or lower the arm rest (2);
- once the desired height has been reached, release the knob and tighten the knob clockwise.



#### 6.5 - Seat belt

The seat belt is essential because it retains the operator anchored to the seat in case of tip-over or roll-over. The condition, cleanliness and mechanical mountings of the seat belt must be checked regularly.

For further details, refer to section "2.8.2 - Seat belt" to page 2-44.

ALWAYS FASTEN the seat belt when seated in the driver's seat.

#### 6.6 - Controls cut-out lever

The controls cut-out lever prevents the accidental activation of all machine functions. For further details, refer to section "2.8.3 - Controls cut-out lever" to page 2-46.

Before leaving the driver's seat, ALWAYS lock the controls by means of the controls cut-out lever.

### 6.7 - Slewing locking lever

The slewing locking lever mechanically locks the slewing of the turning frame (rotary structure).


For more details, see section "2.8.4 - Slewing locking lever" to page 2-47.

Always lock the slewing when transporting the machine and at the end of each day of work.

## 6.8 - Auxiliary electrical socket for the rotating head lamp


An auxiliary socket (1), used to connect the rotating head lamp, is located on the right control console. The socket is of the ISO 4165 standard two-pin type, powered by 12V.

The socket is *locked*; it is powered only when the key of the ignition switch is on the IGNITION position.




## 6.9 - Control panel operation

A control panel is installed inside the cab and houses a display (1), no. 8 function keys (2) and a navigation console (3).



The operator can interact with the display either with the **no. 8 function keys**, located on either side of the screen, or with the navigation **hand grip** (4) and the buttons **Home** (5) and **Reset** (6) located to the right of the display.

Refer to the following texts for operation.





# **WARNING**

Before making any changes to the settings on the control panel, always make sure that the controls cut-out lever is in the OPEN position.

If this is not done, while reading/changing the parameters on the display you may knock the controls making the machine carry out involuntary movements and causing damage to property and/or persons.


#### **DISPLAY NAVIGATION**

To the right of the display are the controls for display navigation.

In particular:


#### 1 - NAVIGATION HAND GRIP

The hand grip can be turned to the right and to the left to scroll through the various items of the menus, to scroll through the texts in the message area of the display, to continuously change the values of any parameters. The hand grip is also a confirmation button, therefore when it is pushed it performs the **Enter** command on the set values, which are accepted by the machine control box.



### 2 - HOME BUTTON


By pushing it, the display goes back to the Home page, see section "6.10 - HOME page" to page 6-10.




#### 3 - RESET BUTTON

By pushing it, the previous command is cancelled, therefore you will leave the current page and go back to the previous one.

Push the button several times to go back to the Home page.



#### 4 - BUTTON NOT ACTIVE



On all screens, if no action is performed after a short period of time, the display will automatically reposition itself on the HOME page.

#### **MULTIPAGE SCREEN**

Certain screens of the display are made up of multiple pages.

The presence of additional pages with respect to the one displayed is indicated by the following symbol.

You can navigate through the various display screens using the navigation hand grip.

#### Scroll bar

#### Description



Indicates the presence of other pages with respect to the one displayed, which can be viewed by scrolling down.




Indicates the presence of other pages with respect to the one displayed, which can be viewed by scrolling up.

On all screens, if no action is performed after a short period of time, the display will automatically reposition itself on the Home page.

## 6.10 - HOME page

When the machine is turned on, the panel performs an initial check of all the electronics; this procedure lasts about 5 seconds.

Following the confirmation of enabling commands by the operator (refer to section "6.13.2 - Procedure for starting the machine" to page 6-31), the **Home** screen appears, present during normal operation of the machine.



1	Hour	6	Push-button menu and relative icon
2	Machine hours	7	Boom working lights indicator light and button
3	Control mode indicator light and button	8	Canopy working lights indicator light and button
4	Engine data and battery data	9	Indicator light and button for dozer blade/undercarriage width adjustment selector
5	Warning indicator lights	10	Indicator lights and work mode management buttons

#### 6.10.1 - Time

This area shows the current time, which can be changed from the dedicated screen, see section "6.11.7.5 - DATE/TIME sub-menu" to page 6-22.



#### 6.10.2 - Machine hours

This panel displays the machine's hours of operation, divided as follows:

- TOTAL machine hour meter (1);
- **PARTIAL** machine hour meter (2): to reset it (refer to section "6.11.7.3 PARTIAL HOURS RESET" to page 6-21).

When the periodic maintenance interval expires, the maintenance indicator light (3), represented by a wrench, lights up to indicate that periodic maintenance is required.

When the light (3) turns on, consult:

- the machine hour meter,
- the maintenance register;
- check the maintenance table to determine which operations need to be carried out, see section "8.8 Regular maintenance" to page 8-21.



After completing the maintenance operations, the *Service Centre* will reset the maintenance interval hour meter, via the specific SERVICE page, so that the indicator light (3) goes out.

#### 6.10.3 - Control mode


Through the button by the control mode icon, one accesses the **CONTROLS** screen, where it is possible to set the control mode for movements of the machine, see section "6.11.8 - CONTROL MODE screen" to page 6-25.




It is possible to select the control mode that will be active each time the machine is switched on, see section "6.11.7.1 - CONTROL START MODE" to page 6-21.

## 6.10.4 - Engine data and battery data

**Engine speed** see section "5.8 - Control panel" to page 5-6.



**Battery percentage indicator** see section "5.8 - Control panel" to page 5-6.



### 6.10.5 - Pop-up messages (information/alarms)

The operator is notified of any warnings via pop-up messages on the display.

The warnings can be **INFORMATIONAL MESSAGES** or **ALARM MESSAGES**.

Some errors are textual and indicate the steps for resolving the problem, other errors appear in code form, for the resolution of these, contact the *Service Department*.

## 1 - INFORMATION MESSAGES (INFO)

Their purpose is to notify the operator with information concerning, for example:

- the battery status;
- periodic maintenance.

#### 2 - ALARM MESSAGES

These messages inform the operator of any machine alarms, such as electronic faults, etc.

The alarm message is also indicated by the indicator light (3) on the display.

All messages, pressing **OK**, are removed from the display.



Some alarms are indicated in section "6.16 - Electrical isolation" to page 6-44.

If an alarm message is received, which is not expressly illustrated in this manual, contact the *Customer Service*.



The machine features a protection system that is activated when certain errors or malfunctions occur. This system limits the maximum engine speed or stops the engine to prevent the machine conditions from worsening.

## 6.10.6 - Warning indicators

Refer to section "5.8 - Control panel" to page 5-6.



#### 6.10.7 - Menu button

Through the button by the icon, one accesses the **MENU** screen, where it is possible to view the machine data and set machine functions, see section "6.11 - MENU screen" to page 6-17.



## 6.10.8 - Working light switch

Refer to section "6.18 - Working lights" to page 6-45.



## 6.10.9 - Dozer blade mode/undercarriage width indicator light


Through this button (1) it is possible to change the function of the lever (2) located on the right console by selecting one of the following modes:

- dozer blade;
- undercarriage width.

Selection is confirmed by the corresponding indicator light next to the button:

- **dozer blade** (3): this indicator light indicates that the movement of the dozer blade is selected;
- **undercarriage width** (**4**): this indicator light indicates that the undercarriage adjustment movement is selected.

For lever operation, refer to section "6.24 - Dozer blade control/undercarriage width adjustment lever" to page 6-60.



## 6.10.10 - Work mode management

Various work modes can be selected for optimised machine operation, depending on the type of operation to be carried out.

The work mode changes the maximum engine speed and power consumption.

There are three work modes that can be selected by means of specific buttons.

#### **POWER**

**Maximum performance mode**: suitable for particularly heavy workloads. The engine can reach a maximum speed of **2,800 rpm**, the power consumption will be high.



#### **STANDARD**

**Standard mode**: suitable for normal work operations. The engine can reach a maximum speed of **2,600 rpm**.



#### **ECONOMY**

**Energy saving mode**: designed to optimise energy consumption. The engine can reach a maximum speed of **2,400 rpm**.



#### **LOW BATTERY MODE**

**Low battery mode**: automatically activates when the battery charge level reaches 10%.

Remember to charge the battery as soon as possible.



Other work modes cannot be selected when this mode is active.

The engine can reach a maximum speed of 2,200 rpm.

### 6.11 - MENU screen


Through the button of the MENU indicator light, one accesses the machine functions/settings menu.



Turning the navigation hand grip will scroll through the items.

The selected item is highlighted in a different colour than the other items.

Pushing the navigation hand grip to confirm, one accesses the selected submenu.



#### 6.11.1 - BATTERY screen

It is possible to view all data about the **BATTERY power**.

The data displayed are:

- CHARGE: percentage of available charge;
- VOLTAGE: current voltage;
- CURRENT: current intensity;
- TEMPERATURE: battery temperature;
- RESIDUAL ENERGY: displays the available energy.



#### 6.11.2 - ENGINE screen

It is possible to view all data about the **ENGINE**.

The data displayed are:

- RPM: number of revolutions of the engine;
- TEMPERATURE: engine temperature;
- CURRENT: current intensity;
- PRESSURE: current hydraulic system pressure.



## 6.11.3 - EQUIPMENT screen

It is possible to view the list of custom equipment. Specific settings for the auxiliary hydraulic systems can be selected for each piece of equipment.

Select the desired equipment to call up the previously saved settings. To change the settings for each piece of equipment, select the icon to the right of the name of the equipment.



The name of the selected EQUIPMENT appears at the beginning of the equipment list, whereas its icon appears on the HOME page.

### 6.11.3.1 - Equipment SETTINGS sub-menu

Selecting the icon to the right of the implement name in the EQUIPMENT screen will access the **SETTINGS** sub-menu. The list of customisable values appears on this screen.

Turn the navigation hand grip to select the setting to be changed, confirm the selection by pressing the same hand grip, turn it to set the desired value and then confirm it by pressing it again.

In particular, the following can be changed:

- The AUX 1 flow rate value for both hydraulic lines, left and right of the boom;
- The **AUX 2** flow rate value for both hydraulic lines, left and right of the.



For each piece of equipment, it is possible to customise the parameters for all the auxiliary hydraulic systems available. It is recommended to perform adjustments only on the systems that the equipment actually uses.

#### 6.11.4 - TEMPERATURES screen

It is possible to view the **TEMPERATURE** values of the various components.

The data displayed are:


- ENGINE;
- CONTROLLER: engine control device;
- HYDRAULIC OIL;
- BATTERY.



#### 6.11.5 - SOFTWARE screen


It is possible to view all data about the **SOFTWARE**.

These codes can be useful when requesting assistance or spare parts and they must be communicated to the *Service Centre*.



#### 6.11.6 - SERVICE screen


Screen for entering the password reserved for the *Service Centre*.



#### 6.11.7 - SETTINGS screen

The **SETTINGS** screen has a list of items that can be changed:

- CONTROL START MODE;
- PRESSURE RELIEF;
- PARTIAL HOURS RESET;
- LANGUAGE:
- DATE/TIME;
- DISPLAY BRIGHTNESS;
- COMMAND CONFIGURATION;
- UNIT OF MEASUREMENT.



#### 6.11.7.1 - CONTROL START MODE

By selecting the **CONTROL START MODE** item in the SETTINGS screen, it is possible to select the control mode that will be active each time the machine is switched on

Turn the navigation knob to select the desired setting, confirm the selection by pressing the hand grip.



For specific settings, see section "6.11.8 - CONTROL MODE screen" to page 6-25.

#### 6.11.7.2 - PRESSURE RELIEF

By selecting the **PRESSURE RELIEF** item in the SETTINGS screen, it is possible to activate two options:

- ON when the residual pressure of the hydraulic system is to be released;
- **Off** to resume normal machine operation.



For more details, see section "6.30 - Discharge residual pressure in the hydraulic system" to page 6-74.

#### **6.11.7.3 - PARTIAL HOURS RESET**


By selecting the **PARTIAL HOURS RESET** item in the SETTINGS screen, it is possible to reset the partial hour meter.



#### 6.11.7.4 - LANGUAGE sub-menu


By selecting the **LANGUAGE** sub-menu in the SETTINGS screen, it is possible to select the preferred language.

Turn the machine off and then on again after changing the language.



## 6.11.7.5 - DATE/TIME sub-menu

By selecting the **DATE/TIME** sub-menu in the SETTINGS screen, it is possible to set both.



### 6.11.7.6 - DISPLAY BRIGHTNESS

By selecting the **DISPLAY BRIGHTNESS** item in the SETTINGS screen, it is possible to adjust the brightness of the display.




### **6.11.7.7 - COMMAND CONFIGURATION**

By selecting the **COMMAND CONFIGURATION** item in the SETTINGS screen, it is possible to change the configuration of the commands of the joysticks from the **ISO** (European) standard to the **SAE** (American) standard.

For more information, see section "6.27.3 - ISO-SAE controls layout TPSS function" to page 6-70.

Before starting work, always check which configuration is selected using the appropriate light (1) on the HOME screen.



# **6.11.7.8 - UNIT OF MEASURE**

By selecting the **UNIT OF MEASURE** item in the SETTINGS screen, you can change the unit of measurement of the data shown on the display from the International Standard (**SI**) to the US Customary System (**USA**).




### 6.11.8 - CONTROL MODE screen

Through the button by the control mode icon, one accesses the **CONTROLS** screen, where it is possible to set the control mode for movements of the machine, in particular:

- PRECISION;
- NORMAL;
- PRODUCTIVITY;
- INDIVIDUAL.

The active control mode is indicated by the control mode button.



### **PRECISION**

In this mode, the sensitivity of the controls is increased; this allows the machine to perform slow and precise movements.



### **NORMAL**

In this mode, the machine performs movements at normal speed.



#### **PRODUCTIVITY**

In this mode, the sensitivity of the controls is reduced; this allows the machine to perform rapid and dynamic movements.



### **INDIVIDUAL**

In this mode, the operator can set the sensitivity of each individual control, see following section.




### 6.11.8.1 - INDIVIDUAL sub-menu

Selecting the icon to the right of the CONTROLS screen will access the relative **INDIVIDUAL** sub-menu. The list of customisable values appears on this screen.

For each movement, it is possible to set the maximum speed, shown in percentage, example: 100% corresponds to the maximum speed.

Turn the navigation hand grip to select the setting to be changed, confirm the selection by pressing the same hand grip, turn it to set the desired value and then confirm it by pressing it again.



# 6.12 - Visibility

During machine operation, constantly check the surrounding area in order to identify any potential hazardous s in advance as soon as they become visible.

Pay particular attention when moving. More information on how to configure the machine is provided below.

The machine can be equipped with devices to improve visibility, such as rear-view mirrors; refer to the procedures below for instructions on how to use them.

The employer must organise the construction site in such a way as to minimise risks caused by poor visibility.

Some events to pay attention to are listed below:

- well-defined routes for each vehicle;
- presence of personnel directing traffic;
- safety signs on the machine or vehicles;
- a communication system between machine operators;
- a communication system between personnel and operators of the machines.

Changes to the configuration of the machine by the operator, with consequent reduction of visibility, ARE FORBIDDEN.


### 6.12.1 - Travel position

To move, keep the machine configured as indicated below:

- move the boom to a swing angle equal to **0°** (if present);
- lift the first boom completely;
- Position the 2nd arm so that the pin at the end is in the position shown in the figure;
- position the bucket as indicated in the figure;
- raise the dozer blade completely;
- An illustrative image is shown below.

If it is not possible to follow the instructions provided with the equipment installed, it will be necessary to:

- adjust the position of the booms as closely as possible to the indications listed above, ensuring a distance of approximately 400 mm between the ground and the equipment itself;
- ensure that the site is properly organised to minimise the risks of limited visibility.



Н	Height from ground at centre of pin of first/second boom	~ 1,960 mm
R	Distance from the centre of the slewing ring to the centre of the bucket pin	~ 1,330 mm

# 6.13 - Starting the machine

# PRECAUTIONS WHEN STARTING THE ENGINE

- Start up and run the machine exclusively from the driver's seat.
- On starting the engine, sound the horn to warn everyone.
- Do not allow unauthorised persons to get on the machine.

# 6.13.1 - Checks prior to the start up

Always perform all checks in this section before starting the machine.

Neglecting any of the checks may result in problems being experienced with the machine, including the hydraulic equipment.



# **CAUTION**

Carry out checks and maintenance operations before starting the machine.

Keep unauthorised persons away from the machine while checking it.

The checks and inspections to be performed before starting the engine are:

### 1 PERIODIC MAINTENANCE

Perform the reading of the hour meter to check whether periodic maintenance is required, see section "8.8 - Regular maintenance" to page 8-21.

### 2 CHECKING THE MACHINE FOR LEAKS

Check the whole machine for any liquid leaks, even if slight.

Leaks can lead to malfunctions and machine breakdown.

It is necessary to check all the parts present: flexible and rigid pipes, hydraulic jacks, pumps and motors.

### 3 CLEANING THE MACHINE

Check the cleanliness of the machine so as to avoid any operating problems or faults occurring while the machine is working.

Clean away from the machine all material that has built up during use (e.g. dirt, dust, stones, grass, etc.), especially in the movement and articulation are.

Check the outside as well as the inside of the machine to avoid any manoeuvrability problems during operation.

### 4 CHECKING THE MACHINE FOR WEAR

Check the machine for any signs of worn or missing parts.

If so, replace or restore them prior to starting up the machine.

### 5 CHECKING THE TRACKS FOR WEAR

Check to ensure the tracks show no signs of cracks, breaks or excessive wear, and their tension is correct (see the section on maintenance for adjustment procedures).

## **6 STATUS OF EQUIPMENT**

Check the equipment installed on the second boom in order to ensure that it has been properly installed and fixed in place, as indicated in the manuals of the respective manufacturers.

Check the wear and inspect for signs of oil leaks or accumulation of debris on the equipment, in which case immediate action must be taken to repair the leaks and remove the debris to avoid machine malfunction.

### 7 EMERGENCY STOP BUTTON

Make sure that the emergency button on the machine is deactivated, see section "2.8.5 - Emergency stop button" to page 2-48.

# 8 POSITIONING OF REAR-VIEW MIRRORS (IF PRESENT)

Make sure the rear-view mirrors are intact and correctly positioned so as to ensure the complete visibility around the machine.

## 6.13.2 - Procedure for starting the machine

Before starting the machine, learn the procedure described in the following pages.

Each command, indicator and indicator light involved in starting the machine and in checking the condition of the machine when it is started is listed in the order in which the operator encounters them.



# **WARNING**

Before starting the machine, carefully study the safety indications and function of the controls described in this manual.

After starting the machine, the operator is directly responsible for any damage that may result from failure to comply with the instructions in this manual and with the laws in force.

Only start the machine when the operator is sitting in the driver's seat and with the seat belt fastened.


Before starting the machine, check that there are no persons within the machine's operating range and then signal the starting with the horn.

### **IGNITION SWITCH**

The starter switch and other locks used on this machine use the same key.

The starter switch has two positions:

- 1 "OFF";
- 2 "IGNITION".



### 1 - OFF POSITION:

When the key is absent or in this position, **the machine is OFF**, and does not supply electrical power to any function; in this position the key can be inserted or removed.

While the machine is switched on, turning the key to the OFF position will turn off the machine.

### 2 - IGNITION POSITION:

When the key is inserted and moved to this position, the machine is SWITCHED ON.

If the machine does not turn on, check the position of the emergency stop button switch, see section "2.8.5 - Emergency stop button" to page 2-48.

### **MACHINE STATUS INDICATOR LIGHT**

This light indicates that **the machine is SWITCHED ON**.

The light will only go out when the ignition key switch is turned back to the **OFF** position.





# **NOTICE**

When the machine is switched on and no movement is carried out, it remains one when entering in **IDLE mode FOR A LONG TIME (also called IDLE)**: the engine speed values are reset while **the machine controls remain operational**.



If the idle mode lasts for a long time, a message appears on the display and the machine beeps to remind the operator that it is switched on.



# **WARNING**

Always check the machine status light to see if the machine is switched on.

In idle mode, the machine does not emit sound, but remains switched on and the controls are operational. Avoid distractions, the activation of an undesired control command could cause involuntary movements and serious injuries.

When the work is complete, check that the ignition light is off before leaving the machine.

### MACHINE CHARGING STATUS INDICATOR LIGHT

This light will turn on to indicate when the machine is charging, the machine cannot be operated in this state. At the same time, the display shows the charging status.

To restore normal working functionality, see section "6.15 - Machine charging mode" to page 6-38.



### START-UP

After you have learned the procedure, proceed to starting the machine.

Before staring work operations, make sure you have learned the following indications.

### **DISPLAY**

When the display is turned on, the commands are disabled. To enable the commands, press the **OK** button (navigation hand grip) to confirm the message (1).



No errors should appear on the display, if there are any, stop and start the machine again. In this way, the system can recover from errors by restarting. If the errors are still present, see section "6.10.5 - Pop-up messages (information/alarms)" to page 6-13.

### **BATTERY LEVEL INDICATOR**

This indicator shows the percentage of battery charge.



Before starting work, check the battery charge level indicated by the gauge, if the value is **less than or equal to 10%**, it is necessary to charge the machine.

When the battery charge level drops below the indicated limit, the machine enters the **low battery mode** and the performance is automatically reduced, this situation is indicated on the display with appropriate messages; proceed to charging the machine as soon as possible.



Maintain a charge of between 20% and 80% to ensure longer battery life.

For information on charging the machine, see section "6.15 - Machine charging mode" to page 6-38.

### **TRAVEL HORN**

Before starting work, check that the travel horn is working, if not stop the machine and have the horn repaired.

Refer to the following sections to learn the work modes.

## 6.14 - Battery power



# **WARNING**

Do not tamper with the battery, it contains chemicals that can cause fire and serious health problems.

**Respect the machine use temperatures indicated in section** "1.7 - Prohibited use" to page 1-14.

The machine is powered by a rechargeable lithium-ion battery positioned on board.

The battery is very sensitive to ambient temperature, the optimum temperature range (within which the battery has the best performance) is between **+5°C** and **+45°C**.

An integrated system in the battery monitors its temperature: when the machine is started or during charging, if the temperature is below a certain level, the system warms up the battery.

During the heating of the battery (indicatively between **-15°C** and **-10°C**), the performance of the machine is reduced; when the battery reaches the ideal temperature, it will deliver maximum performance again.

The battery heating is automatically switched on/off without notice or indication to the operator.



# NOTICE

When the machine is out of service, store it at a temperature between  $+5^{\circ}$ C and  $+45^{\circ}$ C to ensure a longer battery life.

## Charging conditions based on ambient temperature/machine usage

Temperature  Duration of inactivity	<-30 °C	>-30 °C <-15 °C	>-15 °C <+50 °C	>+50 °C
Up to 24 hours	•	1	1	•
Up to 4 weeks	•	•	0	•
Over 1 month	•	•	•	•

### Key:

<ul> <li>Continuous</li> </ul>	charging	/	Charge not strictly necessary
o At least on	e full charge before storing the		
machine			

The battery guarantees maximum performance when the charge level is above 10%.

When the battery charge level drops below the indicated limit, the machine enters the **low battery mode** and the performance is automatically reduced, this situation is indicated on the display with appropriate messages; proceed to charging the machine as soon as possible.

If the display does not come on after the ignition key has been switched on, the cause could be that the battery is completely discharged (0% charge level). Proceed to charge the machine and wait at least **60 minutes** before starting the machine; if the problem persists, contact the *Customer Service*.

The battery requires no maintenance, so any work on it is prohibited, only the Service Centre can intervene in the event of a fault.



At the end of the work it is always recommended to charge the battery.

Prolonged periods of low battery power damage the battery. If the charge is less than 10%, charge within one week.

# 6.15 - Machine charging mode



# **DANGER**

Do not charge the machine if the connecting cables and their connectors are damaged. A damaged component exposes people to a risk of electrical discharge that could cause serious injury or death.



# **WARNING**

The operator is the only person authorised to charge the machine. Charging operations must be carried out from the ground. Pay attention to cables, there is a risk of tripping.

No person is allowed on board the machine during charging.



# **WARNING**

For charging, place the machine and the accessories used for charging in a covered, dry place where they are not in the way of people or vehicles.

When charging the machine, the temperature of the components inside the rear cover may be high and may cause burns. Avoid touching hot components indicated by the safety signs.

The characteristics of the mains supply and the type of socket must comply with those indicated in the following sections.

The battery can be charged at any time of the day to increase the available energy, even if it is not completely discharged. It supports a large number of charge and discharge cycles even if they occur in multiple partial sessions or in full sessions.

- **Partial charging** session: a charging operation in which the battery charge level DOES NOT reach 100%.
- **Full charging** session: the charging operation, carried out with the machine switched off, in which the battery charge level reaches 100%.

The battery must be charged with the machine in the park position (machine off).

If the machine is switched on while charging, a notice message appears on the display.

In this situation, all commands are disabled.



To keep the battery in good condition, follow these guidelines:

- perform at least a full charge once every 4 weeks, while the machine is not in use;
- perform at least one **full charge** once a **week**, during the period when the machine is in use;
- charge when the charge level indicator mark is **less than or equal to 10%**.

A system integrated into the battery monitors its temperature, if the battery temperature is below a certain level, the battery will warm up before starting charging.

In cold weather, the battery charge can be automatically inhibited or slowed down.

The charging time can vary depending on different factors, the charging current, the ambient temperature, battery charge status, the time elapsed since the last charge.

When charging, make sure that no person or other vehicles can approach the machine, cable and portable battery charger (if present).

The battery can be charged only:

- with **on-board** battery charger;
- with **portable** battery charger (optional).

Both modes draw power from an electrical mains.

The connection to the mains and/or to the machine is made with cables equipped with connectors. Remove the connectors by grasping them, avoid yanking at the cable.

Protect connection cables from heat, oil, sharp edges or moving parts of equipment.

### USING THE MACHINE

The cables and their connectors must NOT be changed.

DO NOT use adapters or multi-way adapters.

Electrical extension cables can only be used if they comply with current standards and have the **same or superior characteristics** compared to the cables to be extended. The use of charging cable extensions (between the battery charger and the machine) is PROHIBITED when using the portable battery charger.



Maintain a charge of between 20% and 80% to ensure longer battery life.

Do not connect both chargers at the same time, the battery could receive excessive stresses which could damage it.

# 6.15.1 - On-board battery charger

The on-board battery charger is located inside the machine within the rear compartment where a cable is located to connect to the mains.


The mains power supply and its socket must comply with the standards in force and have the following characteristics:

Rated voltage	V	100/120 AC	200/240 AC
Phase and frequency	Hz	50/60	50/60
Rated current	Α	12	7
Power	W	1330	1630
Plug type	ype Schuko R4A or U		A or US R20

# To **charge** the battery:

- position the machine on an area with a compact surface, if possible levelled and in which the movement of persons or other vehicles is not obstructed;

- lower the equipment and the dozer blade to the ground;
- stop the machine;
- get off the machine and open the rear cover (1);
- fully unwind the charging cable (2) and connect the plug to the mains socket;
- while charging, the rear cover must remain open;
- charging starts immediately and is indicated by the light (3) coming on and by the display lighting up and showing the charging status (4);
- it is possible to stop charging at any time;
- when charging is complete, the power consumption will be stopped automatically, the indicator light (3) will remain on to indicate that the charging cable is connected;
- when the desired charge has been completed or the complete charge has been reached, disconnect the plug from the mains, the indicator light (3) goes out;
- rewind the cable (2) into the cable holder (5), close the rear cover (1).





Keep the rear cover open during charging to allow the heat to be disposed of.

## 6.15.2 - Portable battery charger (optional)

The portable battery charger is external to the machine and must be transported to the charging location by a suitable means.

The portable battery charger has two cables, the charging cable that connects to the machine and the power supply cable that connects to the mains.



# **WARNING**

The portable battery charger or the electrical network to which it is connected must be equipped with TYPE B differential switches.

The recharging cable (from the portable battery charger to the machine) must be covered with adequate protective corrugated element to prevent damage to the cable and the possible dispersion of electrical energy on the machine frame.



# NOTICE


The portable battery charger must always be placed in a covered, ventilated area, away from heat and flammable materials, rain or water jets.

The portable battery charger must be of the type indicated and authorised by the machine manufacturer; for further details, contact the Service Centre.

Always consult the manual supplied by the manufacturer of the battery charger.

## To **charge** the battery:

- position the machine on an area with a compact surface, if possible levelled and in which the movement of persons or other vehicles is not obstructed;
- lower the equipment and the dozer blade to the ground;
- stop the machine;
- get off the machine and open the rear cover (1);
- connect the charging cable from the portable charger to the socket (2) of the machine;
- connect the power cable (3) of the portable battery charger (4) to the mains socket;
- activate the battery charger as indicated in the relative user manual;
- charging is indicated by the light (**5**) coming on and by the display lighting up and showing the charging status (**6**);
- it is possible to stop charging at any time;
- when charging is complete, the power consumption will be stopped automatically, the indicator light (5) will remain on to indicate that the charging cable is connected;
- once the desired charge is complete or full charge has been reached, deactivate the charger then disconnect the plug (3) from the mains, the indicator light (5) turns off;
- disconnect the charging cable from the socket (2) and close the rear cover (1).



Keep the rear cover open during charging to allow the heat to be disposed of.

### 6.16 - Electrical isolation



# WARNING

IT IS FORBIDDEN to carry out work and/or maintenance operations when the electrical isolation alarm is shown on the display; people could be exposed to a risk of electric shock. Contact the Service Centre as soon as possible.

The machine is equipped with a system that constantly monitors the correct isolation of the electrical components.

In the event of anomalies, the following alarm is shown on the display; the precautions to be taken are described below:

- interrupt work;
- drive the machine on a flat, levelled surface;
- choose an area where the machine will not get in the way of people or other vehicles;




- lower the equipment and the dozer blade to the ground;
- stop the machine, remove the ignition key and get off;
- cordon off the area around the machine to prevent people from approaching it and to make sure that no one can use the machine until the fault has been repaired;
- contact the Service Centre to request a repair intervention.

### 6.17 - Horn

The horn button (1) is located at the bottom of the left joystick and is activated when the ignition key switch is set to the "IGNITION" position".

Sound the horn every time you climb aboard and start working, use it especially when it is noticed that anyone in the vicinity is in danger.



# 6.18 - Working lights

On the machine there are **working lights** that are to be used when visibility is low:

### As standard, there are:

- **no. 1 light** on the first boom.

On request, (optional) the following are available:

no. 2 lights on the front canopy.


The standard lights are controlled using the (1) button.

The optional lights are controlled using the (2) button.

Their lighting is confirmed by the indicator light located next to the relative control button.

First press (indicator light on): lights ON.

**Second press** (indicator light off): lights OFF.



# 6.19 - Operating at low temperatures



# **CAUTION**

It is not possible to operate at temperatures below -30°C.

For battery precautions refer to section "6.14 - Battery power" to page 6-36.

At low ambient temperature (below  $+5^{\circ}$ C) the viscosity of the oil increases, in these conditions, it is possible to have difficulty in using the machine immediately after the first cold start. It is important to use an oil suitable for low temperatures, to select one, take advantage of the recommendations of the *Service Centre*.



# NOTICE

When starting at low temperatures, work at low speed for 10 minutes, this allows the oil to reach normal operating temperature.

### **HYDRAULIC OIL**

Use oil that is suitable for low temperatures, see section "8.6.3 - Hydraulic system oil" to page 8-14.

## 6.20 - Precautions during operation



# **WARNING**

The control devices must only be operated from the driving position. Using the controls from the ground may cause serious injuries or death.

Learn the position and operation of: controls, instruments and indication lights, then check that they are working correctly. If abnormal operation occurs, stop the machine immediately and call the Service Centre.

Do not use the equipment for lifting people or as a work platform.

Never transport other persons.

Avoid making sudden, sharp movements.

At low temperatures (below  $+5^{\circ}$ C), follow the instructions given in the relevant section before starting the normal work operations.

When working on uneven ground, always proceed slowly and operate with the bucket or equipment as low as possible.

Carefully check the conditions of the area in which you will be working, in order to ascertain whether there are any anomalies in the terrain that could make the work hazardous.

If possible, level the ground of the work area, prior to starting operation.

Note the position of any overhead or buried pipes or electrical cables, as well as any open or filled trenches.

When travelling, move carefully near the edge of excavations or trenches, and exercise extreme caution in cramped working spaces, or when working on uneven or steeply sloping ground.

Never try to start or use the machine unless you are sitting in the driver's seat.

Only use the controls when you are sure of the movement the machine will make and do not take any chances if you're unsure, especially in obligatory work conditions or in the presence of dangers for your safety or the safety of others.



# **WARNING**

Do not rest the feet on the control pedals when not in use; rest your feet on the floor, or, alternatively, on the supports provided at the side of the travel levers (if present).

Use extreme caution when moving over uneven ground with kerbs or railway lines; drive slowly so as not to lose machine stability.

Do not use the bucket as battering ram. When working on slopes, always keep the bucket lowered.

Never stand under the raised bucket.

Do not try to crush concrete or boulders using the sideways motion of the bucket.

Do not free-fall the bucket during excavation.

Do not travel nor dig with the bucket stuck into the ground.

Do not use this machine to lift or move materials under any circumstances, if not using appropriate and dedicated optional equipment, at all times following the specific warnings.

### While reversing:

- before commencing any movement, check that there are no persons or obstacles in the surrounding area;
- if there are areas where the operator has poor visibility, place a person in charge of reporting, this person must ALWAYS be in a safe area at an adequate distance from the machine;
- take particular care not to bump into other machines or persons when turning or rotating the machine;

During work, always check that the site conditions (e.g. weather conditions) do not change from what was initially checked, in which case, take appropriate precautions.



# **NOTICE**

When driving or transporting the machine with the booms collected, do not allow the bucket to strike against the blade.

After having operated in water or mud, always clean and inspect the machine and grease the pins on the bucket, the swing post, and any other parts that have been submerged.

Digging with the booms on the opposite side of the blade prevents the cylinder of the first boom from striking against the blade.

Do not operate the digging boom with brusque movements, especially if moving downwards: the track frame could get damaged.

Ensure that the rear of the machine does not hit anything while turning.

Before starting to work, always make sure the equipment installed does not collide against the booms.

During excavations in depth, make sure the cylinder of the digging boom and the second boom are not accidentally hitting the ground.

Do not try to move rocks or similar objects using the blade: it can damage both the blade and its cylinder.

# 6.21 - Stopping the machine

To stop the machine, proceed as follows:

- park the car as described in section "6.26 Parking the machine" to page 6-65;
- turn the starting equipment key switch to **OFF** and remove the key;
- open the controls cut-out lever;
- Enable the slewing lock (if provided);
- Close all the windows (if fitted);
- unbuckle the seat belt and get out of the machine;
- close and lock the cab door (if present) and the all covers, refer to section "8.3 Guards" to page 8-7;
- charge the machine as indicated in section "6.15 Machine charging mode" to page 6-38.



It is not necessary to enable the parking brakes, they get enabled automatically.



Do not get off the machine with the equipment raised, always lower it to the ground.

Do not leave the machine turned on.

### 6.22 - Machine movement


For safe machine movement, always move the travel control levers slowly and smoothly. Operators which are not familiarised with tracked machines should initially operate the machine at 50% of its maximum travel speed until they master the control function and feel confident on the machine.

The travel levers control the machine FORWARD and REVERSE motion, as well as LEFT and RIGHT steering and braking. The left lever controls the left track, while the right lever controls the right track.

The functions of all controls are locked when the control cut-out lever is open to the outside for entry/exit operations into/from the machine. To enable the controls, the control cut-out lever must be fully closed, see the procedure in section "6.6 - Controls cut-out lever" to page 6-6.

With both levers in the **NEUTRAL** position (**N**), both tracks are motionless and hydraulic braking is engaged on the travel engines.

- Whenever either lever is moved from its **NEUTRAL** (**N**) position, the brake for the related track drive is released and movement starts.
- Whenever either lever is returned to its **NEUTRAL** position (**N**), the movement of the respective track drive ceases and braking is engaged back.



### USING THE MACHINE

During movement of one or both tracks, in any direction, the travel horn will sound intermittently to warn any persons in the vicinity of the movement of the machine. The horn is of the "smart" type: it adapts the sound level to the noise in the environment so that the sound is always clearly audible.



# **NOTICE**

Unless specifically noted, all references to direction in this manual, including travel and turn instructions, are deemed to be from the operator's point of view and with the dozer blade at the front.

The travel control levers operate the track drive engines mounted on the undercarriage.

The machine movements depend on the driver's orientation; if the operator is turned 180° in relation to the dozer blade, the machine movements are the opposite of those indicated in the operating instructions.




# NOTICE

Both the hand travel control levers have projecting pedals near the bottom of each lever.

These pedals allow the operator to operate the tracks without removing his/her hands from the joysticks.

### 6.22.1 - Forward and reverse travel




To begin **FORWARD** travel, move both control levers forward equally. As additional pressure is applied on the control levers, the machine speed will increase. To STOP the forward travel, return slowly both controls to their NEUTRAL (N) position.



Any forced, quick return of either travel control levers to the NEUTRAL position will cause an immediate braking response from the respective track drive.

To travel in **REVERSE**, pull back slowly on both control levers. The further the controls are moved, the more the speed of movement will increase. To STOP REVERSE travel, slowly return both controls to their NEUTRAL (N) position.


# 6.22.2 - Pivoting the machine around its axis



To pivot the machine to the **LEFT** on its axis, push the right control lever forward while pulling the left lever to the rear.

To pivot the machine to the **RIGHT** on its axis, push the left control lever forward while pulling the right lever to the rear.

# 6.22.3 - Turning while moving forward




With the machine travelling straight **FORWARD,** both control levers must be pushed forward by equal amounts.

To turn **LEFT** while travelling **FORWARD**, reduce forward pressure slightly on the left hand lever, thus slowing down the left track.

The machine will turn toward the LEFT.

To turn **RIGHT** while travelling **FORWARD**, reduce forward pressure slightly on the right hand lever so that the machine will turn toward the RIGHT.

# 6.22.4 - Turning while reversing



With the machine moving straight in **REVERSE**, both control levers must be pulled back by equal amounts.

To turn **LEFT** while **REVERSING**, reduce rearward pressure slightly on the right hand lever, thus reducing the speed of the right track.

The machine will turn toward the LEFT.


To turn **RIGHT** while **REVERSING**, reduce rearward pressure slightly on the left hand lever so that the machine will turn toward the RIGHT.

## 6.22.5 - Precautions during the operation of the tracks


All of the above precautions are applicable to both rubber tracks and steel tracks (optional).

When moving, **DO NOT** ride over or turn on any sharp edges or steps.


The machine will subject the track to an excessive load, resulting in the breakage or cutting of the tread (in the case of rubber tracks, the internal steel cord may be damaged).



Prevent foreign bodies from getting stuck between the track and the frame or the components of the undercarriage; if this happens, the entire undercarriage may be damaged and the track may be deformed and/ or cut.



Protruding bodies should be avoided, if possible. If this manoeuvre is not possible, proceed with care at low speed and moving in a straight direction without steering when the track is over the obstacle.



### USING THE MACHINE

Do not steer abruptly when travelling over surfaces with a high coefficient of friction (e.g. concrete surfaces); this may cause excessive wear of the track.

Clean the rubber tracks if fuel or hydraulic oil is spilled on them; this may cause corrosion and damage the track.



# **WARNING**

The tracks can slip easily on wet, frozen surfaces or surfaces covered with snow. Be very careful when travelling and working in these conditions.

Rubber tracks are less stable than those made of steel due to their flexibility. Be very careful when operating a machine with rubber tracks.



# MOTICE

Any movements or steering over protruding bodies or uneven ground may cause the local loosening of the track resulting in the possible release of the same (in the case of rubber tracks, the internal steel cord may be damaged).

Avoid rotating around the machine axis at high speed.

Rotating around the machine axis on a surface made of high friction material, such as sharp stones, could damage the track and the components of the undercarriage.

### 6.23 - Travel speed

The machine features double travel speed which can be used in both directions.

The two gears are called:

- 1st gear or slow gear;
- 2<sup>nd</sup> gear or fast gear.

The gear selection is made using the button (1) located:

- on the top of the dozer blade lever;


#### or

on the right-hand joystick.

The gear is changed by pressing the button (it is not necessary to keep it pressed).

When the fast gear is active, the relative light (2) turns on.

It is possible to change gear before or during travel.



#### 6.24 - Dozer blade control/undercarriage width adjustment lever

This lever controls both the **lifting/lowering** of the dozer blade function and the **undercarriage width** adjustment function.

#### 6.24.1 - Dozer blade control lever



# WARNING


**Before any operation concerning the dozer blade control, ALWAYS check which mode is selected on the indicator light (1 - refer to section** "6.10.9 - Dozer blade mode/undercarriage width indicator light" to page 6-15).


### The activation of an undesired control may cause serious injuries.

To move the dozer blade:

- check that in the display on the indicator light (1) the dozer blade mode is selected;
- to **lift** the blade pull the lever **back** (2);
- to **lower** the blade push the lever **forward** (3).

The operation may be performed both while the vehicle is stopped and when it is moving (while travelling).





### Key:

- 2 Raised position of the dozer blade
- **3** Lowered position of the dozer blade



# **WARNING**

The cylinder of the dozer blade is NOT equipped with a security valve, so the dozer blade must not be used to stabilise the machine.

If the dozer blade is used improperly, the hydraulic hoses can get damaged and cause a sudden loss of stability of the machine with the consequent damage to the operator and/or to the machine.

#### 6.24.2 - Undercarriage width adjustment control

The expandable undercarriage has the ability to hydraulically change the width of the tracks to adapt to the specific work or movement needs.

In the narrower configuration, the width is reduced to allow access to smaller and more confined work areas or for the transport operations of the machine. In the wider configuration, the maximum stability of the machine is achieved.



# **WARNING**

Before any operation concerning the undercarriage width adjustment control, ALWAYS check which mode is selected on the indicator light (1 - refer to section "6.10.9 - Dozer blade mode/undercarriage width indicator light" to page 6-15).


### The activation of an undesired control may cause serious injuries.


To change the width of the undercarriage (extension/closing):

- check that in the display on the indicator light (1) the undercarriage width adjustment mode is selected;
- to widen the undercarriage push the lever forward
   (2). When the extension is complete, put the lever back in the neutral position and release the button;
- to withdraw the undercarriage pull the lever back
   (3). When the extension is complete, put the lever back in the neutral position and release the button.

Adjust the tracks only on flat, even ground.

The operation may be performed both while the vehicle is stopped and when it is moving (while travelling).





### Key:


- 2 Wide position of the tracks
- 3 Narrow position of the tracks

#### 6.25 - Extendible dozer blade

The dozer blade is equipped with two extensions (1 - 2) which are used to increase the width of the blade so that it adapts to the width of the undercarriage.

In this way the material moved by the dozer blade will be pushed away and not under the tracks, to allow the machine to travel over a level surface.


If the extensions are not used, they can be closed back into the blade, limiting its size and making it easier for the machine to travel.



#### To **close** the extensions:

- remove the outermost fixing pin (3);
- remove the split located on the underside of the pin and poll it out;
- turn the extension towards the inside of the machine (4);
- secure the extension by placing the pin (3) in the hole provided (5);
- refit the safety split pin.

To **open** the extensions repeat the procedure in reverse order.





Before using the machine after opening or closing the blade extensions, make sure they are secured correctly with the safety pin and relative split pin.

#### 6.26 - Parking the machine



# **WARNING**

#### Avoid as much as possible parking the machine on slopes.

#### Parking procedure:

- drive the machine on a flat, levelled surface;
- choose an area where no falling of rocks nor landslides are possible;
- choose an area where the machine does not block pedestrians or other means and however, in an area permitted according to the standards in force;
- align the turning frame to the undercarriage so that the dozer blade stays near the boom;
- lower the equipment and the dozer blade to the ground;
- stop the machine in accordance with the procedure described in section "6.21 Stopping the machine" to page 6-50;
- then turn the starter switch to the "OFF" position and remove the key;
- open the controls cut-out lever, making sure that it comes up all the way;
- Enable the slewing lock (if provided);
- Get off the machine:
- close the controls cut-out lever so that the machine is more compact in the parking position;
- lock all covers present, see section "8.3 Guards" to page 8-7.




### **NOTICE**

It is not necessary to enable the parking brakes, they get enabled automatically.

#### USING THE MACHINE

Should it be unavoidable to park the machine on a slope it is necessary to:

- it is necessary to check that the slope is less than 10°;
- point the dozer blade down the slope and dig it in the ground (1);
- position the bucket down the slope and make sure the teeth of the bucket are dug in the soil (2), if no equipment that can be dug into the ground is present, just rest the bucket to the ground;
- block suitably (using wedges 3) both tracks.



#### 6.27 - Operating the boom

The joysticks allow for the first boom, the second boom, the bucket and machine slewing to be controlled.

2 control configurations, also called "control layouts" are available:

- ISO European:
- SAE American.

Choose the most suitable one depending on the operator's driving experience.

To set the desired layout, see section "6.27.3 - ISO-SAE controls layout TPSS function" to page 6-70.



# WARNING

Before starting work, always check the controls layout set.

Before rotating the turning frame, use the rear-view mirrors (if present) or turn your head to make sure that the area is clear.

Pay attention to the presence of people in the area: should someone enter the manoeuvre area, stop the machine immediately.

The functions of all controls are locked out when the controls cut-out lever is open to allow entry or exit from the machine. To enable both joysticks, the controls cut-out lever must be fully closed, refer to section "6.6 - Controls cut-out lever" to page 6-6.




# **NOTICE**

Some movements of the boom have a function that slows down the speed of the hydraulic cylinder near the limit stop. This feature reduces brusque movements during work, ensuring longer life of the machine components.

#### 6.27.1 - Left Joystick

The left joystick controls the extension and retraction of the second boom, as well as the RH and LH rotation of the first boom and turning frame:

- Moving the left joystick to the LEFT will swing the turning frame to the left (1 counter-clockwise direction);
- moving the left joystick to the RIGHT will swing the turning frame to the right (2 clockwise direction);
- pushing the left joystick BACKWARDS will lower the second boom (3);
- pulling the left joystick FORWARDS will raise the second boom (4).



#### Key:

- **1** Slewing of the turning frame and first boom to the left
  - 2 Slewing of the turning frame and first boom to the right
- 3 Closing the second boom
- **4** Opening the second boom




When the joystick is in neutral position (in the centre), the slewing service brake is automatically engages; this braking is of a mechanical type (negative) and, therefore, is always on during normal machine use, acting also as parking brake. The brake is automatically enabled when the machine is stopped.

### 6.27.2 - Right joystick

The right joystick controls the raising and lowering of the digging arm and controls the movement of the bucket. The bucket works according to the switches on the 2nd arm which must be in DIG mode:

- Moving the right joystick to the LEFT will tilt the bucket to the closed position (1);
- moving the right joystick to the RIGHT will tilt the bucket to the open position (2);
- pushing the right joystick FORWARD will extend the first boom (3);
- pulling the right joystick BACKWARD will retract the first boom (4).



### Key:

1	Closing	the	buc	ket
---	---------	-----	-----	-----

**<sup>2</sup>** Opening the bucket

**<sup>3</sup>** Lifting the first boom

**<sup>4</sup>** Lowering the first boom

#### 6.27.3 - ISO-SAE controls layout TPSS function


The TPSS function allows the selection of the controls layout:

- **ISO European** (1);
- SAE American (2).

The ISO controls layout differs from the SAE controls layout for the position of the first boom and second boom controls.

For more information, see section "6.11.7.7 - COMMAND CONFIGURATION" to page 6-23.

In SAE configuration, the functions **3-4** of the left joystick are performed by the right joystick **5-6** and vice versa (see figure below). All the other machine functions remain unchanged.



#### Key:

- **3** Lowering the first boom
- 4 Lifting the first boom
- **5** Opening the second boom
- **6** Closing the second boom

### 6.28 - Boom swing/AUX2 hydraulics system selector button (optional)


The roller (1) located on the left-hand joystick is used both to perform the boom swing movement and to control the AUX2 hydraulic system (optional).

The roller function (1) can be selected using the button (2) on the right-hand joystick.

If the AUX2 system is not installed, the roller is only used for the boom swing and the button does not activate any functions.

When this indicator light (3) is lit, it means that the roller controls the **AUX2 hydraulic system** (refer to section "6.31.4 - AUX2 Auxiliary hydraulic system (optional)" to page 6-82).

When this indicator light (4) is lit, it means that the roller controls the **boom swing** (refer to section "6.29 - Boom swing control" to page 6-72).



#### 6.29 - Boom swing control

The roller (1) located on the left joystick is used to turn the first boom to the left or to the right of the turning frame; this boom movement is called the boom swing.




# **WARNING**

Before carrying out the boom swing movement, ALWAYS check which mode is selected on the indicator light if present (2 - refer to section "6.28 - Boom swing/ AUX2 hydraulics system selector button (optional)" to page 6-71).

The activation of an undesired control may cause serious injuries.

#### To activate the control:


- check that in the display on the indicator light (2) if present, the boom swing mode is selected;
- push **DOWN** the roller to rotate the first boom to the left;
- release the roller when the boom reaches the required position;
- push **UP** the roller to rotate the first boom to the right;
- release the roller when the boom reaches the required position.





### **NOTICE**

DO NOT leave any of the hydraulic controls engaged after the cylinder reaches its limit stop in any direction. This practice forces the hydraulic oil to pass through the main relief valve, causing a rapid build-up of heat in the system resulting in overheating and loss of power, in addition to reducing the component life.



#### Key:

- **3** Pushing the roller downwards will swing the first boom to the left
- **4** Pushing the roller upwards will swing the first boom to the right



The hydraulic system is equipped with a shock absorber that reduces the speed of the boom's travel when the cylinders approach their limit stops.



If a very wide equipment is fitted (ditch cleaning bucket) and the machine is operated with the boom swing slewed, pay attention when the equipment moves closer to the machine body and/or to the operator protective structure. This position could cause impacts resulting in serious or fatal injury.

#### 6.30 - Discharge residual pressure in the hydraulic system




# **WARNING**

The hydraulic system may remain under pressure even after the machine has stopped. Release the residual pressure before maintenance interventions.

To discharge the residual pressure:

- position the machine on flat, compact ground;
- lower the equipment and the dozer blade to the ground;
- from the display:
  - press the button (1) MENU;
  - turn the navigation hand grip and select the item (2) SETTINGS, then confirm by pressing it;
  - turn the hand grip and select (3) ON of the Pressure relief, then confirm by pressing it;
- keep the controls cut-out lever closed;
- operate all controls (joysticks, levers and roller) to release the pressure;
- stop the machine;
- slowly unscrew the cap of the hydraulic oil tank;
- proceed with the maintenance of the hydraulic system.


When maintenance is complete, proceed in reverse order, remembering to select **OFF**, to resume normal machine operation.



### 6.31 - Auxiliary hydraulic systems

The second boom features the end of some pipes that can be connected to optional equipment that require additional hydraulic functions.

The pipes are on both sides of the boom; below is an indication of which system each pipe refers to.



### Key:

- 1 AUX1
  - 2 AUX2 (optional)

Auxiliary Max capacity hydraulic (I/min)			Pressure max (bar)		Connection
system	left	right	left	right	tilleau
AUX1	28	28	180	180	3/8" GAS lh
AUXI	20	20 100	100	160	3/8" GAS rh
AUX2	10	7	180		1/4" GAS lh
(optional)	10	/			1/4" GAS rh

To understand the operation of the systems in detail, see the following sections.

#### 6.31.1 - Connection of equipment to the hydraulic systems



# **WARNING**

Read carefully the contents of the equipment instruction manual before using the machine or carrying out any maintenance operations.



# **WARNING**

Never connect any equipment to the hydraulic lines before it is properly installed from a mechanical point of view and locked on the second machine boom.

Before carrying out any interventions on the hydraulic system, stop the machine and release any residual pressures.

All operations must be performed with the machine parked on flat and compact ground.



### NOTICE

When removing hydraulic connections, be very careful that impurities do not enter the pipes.

Clean immediately any oily area.

To **connect** the equipment to the hydraulic system:

- mechanically install the equipment;
- place the machine on flat,, compact ground and lower the equipment to the ground;
- stop the machine;
- release the residual pressures of the system, see section "6.30 Discharge residual pressure in the hydraulic system" to page 6-74;
- remove the caps from the ends of the taps indicated, take care not to damage or lose the parts removed;
- connect the pipes from the equipment to the taps, making sure that the characteristics and sizes of the fittings are the same as those prescribed.



### **NOTICE**

As far as the threads and functions of the equipment connections are concerned, see the manufacturer's manual.

- After connecting the hoses, start the machine;
- lift the equipment off the ground and send pressurised oil for around ten times, alternately to the two connections, in order to purge any air left in the circuit;
- repeat the operation for each system used by the equipment;
- stop the machine and wait at least **5 minutes** before starting work operations. This will eliminate any air bubbles that have built up in the tank;
- make sure there are no oil leaks and clean up any oil spilled.



### NOTICE

For any doubts that may arise concerning the connection of the equipment to the hydraulic system, contact the Service Centre.

#### 6.31.2 - Connections on second boom

The pipes of the auxiliary systems end with threaded fitting on which taps are installed which allow to isolate the hydraulic system from dirt entering and prevent oil leaks if no equipment is connected.

The hydraulic equipment must be connected to the taps by means of flexible rubber hoses.

After disconnecting the equipment, always put the caps back on.

#### 6.31.3 - AUX1 Auxiliary hydraulic system



For the technical characteristics, see section "3.6 - Hydraulic system" to page 3-3.

The **AUX1** auxiliary hydraulic system can feature two operating modes:

- single-acting mode;
- double-acting mode.

Switching between the two modes takes place manually by means of a 3-way valve; the operation is described in the next section.

For the operating details, refer to sections:

- "6.31.3.2 Single-acting mode AUX1" to page 6-80;
- "6.31.3.3 Double-acting mode AUX1" to page 6-81.

The single-acting auxiliary hydraulic system provides a continuous supply of hydraulic oil to a pipe, while the other is discharged directly into the tank, the system used for equipment such as demolition hammers.


The double-acting auxiliary hydraulic system provides pressure alternately to one of two outlets, the system used for equipment such as augers.

The oil flow can be regulated by acting on the accelerator hand grip; always observe the flow rate indicated by the manufacturer of the equipment.

### 6.31.3.1 - AUX1 hydraulic system three-way switch

The three-way switch (1) allows to change the operating mode of the **AUX1** system. To select the desired mode:

- Turn the valve **counter-clockwise** to select the **double-acting** mode (2).
- turn the valve **clockwise** to select the **single-acting** mode (3).




#### 6.31.3.2 - Single-acting mode AUX1

This mode provides for the pressurised flow only on the left connection, while the right connection will remain discharged.

To enable this mode, refer to section "6.31.3.1 - AUX1 hydraulic system three-way switch" to page 6-79.

#### To operate the **AUX1 single-acting control**:

- push and keep pushed UP the roller (1) to provide a constant flow of hydraulic oil to the left piping; the right piping is always empty (direct to the tank) even if no control is engaged;
- release the roller to stop the flow;
- while pushing the roller, the electric hold can be activated by pressing the button (2), so that the control remains on and the roller can be released; the electric hold for the oil flow to the equipment can be activated at any stage of the roller travel, making it possible to provide a partial flow and keep it constant at the required level; When the automatic hold is activated the relevant light on the control panel comes on (3);



- To **deactivate** the hold, press button (2) again or move the roller (1) from its neutral position;
- no function is activated by pushing the auxiliary hydraulic control roller down if it is in single-acting mode.



For details on the controls, refer to the label located on the driver's seat and to the instructions in this user manual.

DO NOT keep the roller pressed down for long periods. The hydraulic circuit does not activate any function but is still under pressure and so there is the risk of the hydraulic oil overheating.


#### 6.31.3.3 - Double-acting mode AUX1

This mode provides for the reversible control of the flow; while one of the two pipes is pressurised, the other is discharged.

To enable this mode, refer to section "6.31.3.1 - AUX1 hydraulic system three-way switch" to page 6-79.

### To operate AUX1 double-acting control:

- push and hold the roller (1) UP to provide a constant flow of hydraulic oil to the left piping; at the same time, the right piping is discharged;
- release the roller to stop the flow;
- while pushing the roller, the electric hold can be activated by pressing the button (2), so that the control remains on and the roller can be released; the electric hold for the oil flow to the equipment can be activated at any stage of the roller travel, making it possible to provide a partial flow and keep it constant at the required level; When the automatic hold is activated the relevant light on the control panel comes on (3);



- To **deactivate** the hold, press button (2) again or move the roller (1) from its neutral position;
- push and hold the roller (1) pushed **DOWN** to provide a constant flow of hydraulic oil
  to the **right piping** while the left piping is discharged. In this case, it is not possible
  to activate the electric hold.



For details of the controls, see the label located on the driver's seat and the instructions in this user manual.

#### 6.31.4 - AUX2 Auxiliary hydraulic system (optional)



# **WARNING**


**Before each use, always check which mode is selected on the indicator light (2 - refer to section** "6.28 - Boom swing/AUX2 hydraulics system selector button (optional)" to page 6-71), to be sure which control will be activated.

#### The activation of an undesired control may cause serious injuries.

The hydraulic system **AUX2** works in double-acting mode and is suitable for equipment that requires a reduced oil flow such as for tilting buckets or gripper rotors.

To operate the **AUX2** control:

- check that in the display, on the indicator light (2),AUX2 hydraulic system mode is selected;
- push and hold the roller of the left joystick (1) UP to provide a constant flow of hydraulic oil to the right piping; at the same time, the left piping is discharged;
- release the roller to stop the flow;
- push and hold the roller of the left joystick (1)
   DOWN to provide a constant flow of hydraulic oil to the right piping; at the same time, the left piping is discharged;
- release the roller to stop the flow.





### **NOTICE**

For the technical characteristics, refer to section "3.6 - Hydraulic system" to page 3-3.

For details on the controls, refer to the label located on the driver's seat and to the instructions in this user manual.

### 6.32 - Emergency lifting-boom lowering procedure



# **WARNING**

Ensure no one is standing under or near the equipment before starting the procedure to lower the booms.

This procedure is to be carried out if the machine stops and cannot be restarted or, if any other failure occurs that stops the machine with the booms and equipment not resting on the ground.

Lower the lifting boom as follows until the bucket or equipment rest on the ground:

- turn the starter switch (ignition key) to ON;
- close the controls cut-out lever;
- move the right joystick control lever forwards the first boom will start to descend;
- keep the joystick pushed forwards until the equipment reaches the ground.



# **WARNING**

If in carrying out the above procedure the boom does not lower to a position where the equipment is resting on the ground, contact the Service Centre.

IN THE MEANTIME DO NOT ALLOW ANYONE TO COME NEAR THE BOOM.

### 6.33 - Protective structure opening procedure



# **WARNING**

It is prohibited to work with the protective structure tipped backward.

It is prohibited to load/unload the machine with the protective structure tipped backward.

It is prohibited to remove or change the protective structure.

To reduce the height footprint when moving in low-height spaces or when transporting the machine, the protective structure can be tipped over.

#### 6.33.1 - Precautions to be taken during transport



# WARNING

When loading/unloading the machine, the protective structure must NOT be tipped over.

The structure can only be tipped over after the machine has been loaded and must be repositioned before starting the unloading procedure.

Refer to the appropriate chapter for transport operations.

### 6.33.2 - Precautions to be taken when travelling in low-height spaces



# **WARNING**


Tipping of the protective structure is allowed ONLY for passing through lowheight passages, the machine cannot remain or work in these spaces.

Keep the protective structure tipped over ONLY for as long as is strictly necessary to pass through low-height spaces.

#### USING THE MACHINE

When you need to move in low-height spaces, you can tip the protective structure over. Before proceeding, check that the following conditions are met:

- There must be NO hazard of tipping over or rolling over and nor any hazard of falling objects from above;
- the surface must be flat and compact throughout the entire journey with the protective structure tipped over;
- the workplace safety officer has authorised the tipping over of the protective structure;
- The height of the passage must be less than the height of the machine with the protective structure NOT tipped over;
- the height of the passage must be greater than the minimum indicated in the figure below.



#### 6.33.3 - Procedure

Before tipping over the protective structure, ensure that the conditions, as described in the preceding sections, are met.

To **tip over** the protective structure:

- place the machine in a location adjacent to the lowheight space, and ensure that the roll bar tip-over range is free from obstacles;
- lower the equipment and the dozer blade to the ground;
- stop the machine;
- remove the (1) fastening screws;
- with the assistance of a second operator, rotate the protective structure (2) towards the front of the machine, guiding it to the end of its stroke (3).



# **WARNING**

Crushing/shearing hazard.

Handle the roll bar away from the tip-over hinge.

To **cross** the low-height space:

- wear the appropriate PPE head protection (protective helmet);
- start the machine;
- fully raise the first boom and the dozer blade;




- drive through at reduced speed and in forward travel;
- After the travel is completed, lower the equipment and the dozer blade to the ground;
- stop the machine.



# **WARNING**

Before carrying out any work, replace the protective structure in its original position.



#### USING THE MACHINE

#### To **reposition** the protective structure:

- place the machine in a location at a suitable height, ensure that the roll bar tip-over range is free from obstacles;
- lower the equipment and the dozer blade to the ground;
- stop the machine;
- with the assistance of a second operator, rotate the protective structure (2) towards the front of the machine, guiding it to the end of its stroke;
- insert bolts (1) of the type indicated in the table into their housings using a suitable spanner and tighten them to the indicated torque.

Characteristics	
Bolt size	M12 x 1.75 x 35
Bolt strength class	10.9
Tightening torque Nn	120

### 6.34 - Daily storage

Proceed as indicated in section "6.26 - Parking the machine" to page 6-65.



**PAGE LEFT INTENTIONALLY BLANK** 

### 7 - RECOMMENDED OPTIONAL EQUIPMENT



# **DANGER**

IT IS FORBIDDEN to perform load handling operations.



# WARNING

If optional equipment is installed and used, carefully read the relevant user manual and strictly follow the instructions contained in it.

Only use optional equipment recommended by the MANUFACTURER and compliant with the requirements reported in the table in section "7.1.1 - Specifications on authorised equipment" to page 7-4.

THE MANUFACTURER shall not be held responsible for any damage to property or people and for the reduction of the efficiency of the machine, due to the application or use of incompatible equipment.

All the tools required for the normal replacement of equipment are included in the wrench kit supplied with the machine.

While replacing equipment it is important to wear appropriate PPE, according to the indications given in section "2.4.1 - Personal Protective Equipment (PPE)" to page 2-16, to avoid contact with grease, splashes of pressurised oil or metal splinters.

#### 7.1 - Safety precautions

Any type of interchangeable equipment or accessory can be installed on the machine for construction works, roadworks and earth-moving operations, in compliance with the operating limits indicated in this manual. Installation must be performed in compliance with the safety standards, according to the instructions in this manual and in compliance with those of the manufacturer of the equipment or accessory. Interchangeable equipment and accessories must be compliant to the applicable accident prevention standards.

The employer must in any case verify the suitability of the combination in relation to the activities to be carried out.

The installation of optional equipment or accessories other than those authorised by the *MANUFACTURER* not only compromises the machine life, but can also cause safety issues.

When installing accessories or optional equipment not indicated in this use and maintenance manual, contact the *Service Centre*. Otherwise, the *MANUFACTURER* denies all liability for accidents or damage.

The use of equipment on the machine can change its stability. The stability depends on the dimensions and weight of the machine with the accessory fitted to it, as well as on the weight and position of any resulting loads applied to the machine (lifting capacity).

The lifting capacities for this machine are listed in the relative tables in chapter "3 - Technical information" to page 3-1; always refer to these tables.

The machine lifting capacity is reduced by the weight of the equipment installed.

Third party accessory suppliers may or may not supply accessory lifting capacity tables. The nominal lifting capacity values for this type of accessory must be requested from the third party suppliers.

The MANUFACTURER does not issue any declarations or warranties, express or implied, regarding the design, manufacture or suitability for use on the machine of accessories provided by third parties. This machine does not envisage the use of, and must not be used with, any accessories that exceed the maximum permitted lifting capacity.

The installer of the equipment must check that:

- the **hydraulic characteristics** of the equipment are compatible with those of the machine, see section "6.31 - Auxiliary hydraulic systems" to page 6-75;

#### RECOMMENDED OPTIONAL EQUIPMENT

- the characteristics of the equipment coupling are compatible with those of the second boom of the machine;
- after pairing the machine-equipment, the operator's visibility is guaranteed and complies with standards in force;
- the equipment does not interfere with any parts of the machine, in particular with the protective structure and the driver's seat.



# **WARNING**

When removing or installing equipment, take the following precautions and pay attention to the safety conditions during operations.

Perform installation and dismantling operations on a solid, level surface.

When the operations are performed by two or more operators, agree on the signals for communication and follow them during the operations.

Use a crane for the installation or the removal, on the machine, of equipment with a weight greater than 25 kg.

The use of a crane requires specialized personnel. Never allow non specialised persons to use a crane.

It is dangerous to perform operations with suspended equipment; never stand under a load lifted by a crane. Always choose a safe position in order not to run any risks if the load should drop.

Identify the centre of gravity of the equipment so as to hook it in such a way that during the movements it will remain stable and well hooked.

After removing the equipment from the machine, place it on the ground and check that it is stable; if the equipment is not stable, place it on a suitable support.

After installing the equipment, check that it is connected in a stable manner.

Keep unauthorised people out of the equipment storage area.

For further information on installation and dismantling operations, contact the *Service Centre*.

#### 7.1.1 - Specifications on authorised equipment



# **WARNING**

The tables below provide details of the equipment recommended by the MANUFACTURER.

Pay particular attention to safety criteria and, before starting any operations, perform a test (in a safe place) to check the operating area of the equipment and its centre of gravity.

Some equipment, in fully retracted position, may interfere with some parts of the machine (in particular with the operator cab). Therefore, pay attention to avoid interference.

The recommended equipment is listed below:

BUCKET	WIDTH	WEIGHT WHEN EMPTY	CAPACITY
	(mm)	(kg)	<b>(I)</b>
Excavation bucket	200	18	10
Excavation bucket	300	24	18
Excavation bucket	400	27	25
Excavation bucket	500	32	34
Excavation bucket	600	36	42
Ditch cleaning bucket	800	41	58
Pivoting ditch cleaning bucket	800	68	58
Trapezoidal bucket	60°	28	37

The weight of the bucket, the volumetric capacity of the bucket and the density of the material to be handled must be considered when choosing the bucket to be used.

#### RECOMMENDED OPTIONAL EQUIPMENT

QUICK COUPLING	WEIGHT (kg)
Mechanical or hydraulic quick-coupling attachment	22

EQUIPMENT	MAX WEIGHT (kg)
Demolition hammer	60

The hydraulic characteristics of the equipment must be compatible with those of the auxiliary hydraulic systems of the machine, refer to section "6.27 - Operating the boom" to page 6-67.



The total weight of the equipment must **NOT** exceed the nominal lifting capacity indicated in the table in section "3.13 - Nominal lifting capacity" to page 3-7.

To calculate the total weight of the equipment, use the following formula:

**Total weight = Weight of equipment + Weight of quick coupling (if present)** + Weight of hydraulic thumb (if present) + Weight of loaded material (if present).

### 7.2 - Equipment with standard coupling (pins)

The equipment is installed on the second boom by means of a mechanical pin connection.



### NOTICE

The pictures of the equipment are purely indicative. The procedure is valid for all equipment with a standard coupling (pins).

#### 7.2.1 - Installation and removal




# **WARNING**

To avoid personal injury from loose material or flying debris, always wear safety glasses and proper protective clothing when removing or refitting pivot pins.

#### To **remove** the equipment:

- position the machine on flat, compact ground;
- lower the first boom, positioning the second boom and equipment in such a way that the latter is resting on the ground;
- block the equipment (1) using a suitable support (if necessary) so that it maintains its position during and after the removal operations;



- disconnect any hydraulic or electrical systems as indicated in section "6.31.1 Connection of equipment to the hydraulic systems" to page 6-76;
- remove both pins (2-3) and raise the second boom to release the equipment and complete the operation.

### To **install** the equipment:

- the equipment must be firmly secured using a suitable support (if necessary) so that it maintains its position during the installation operations;
- Clean both pivot pins and their fixing holes (2-3);
- align the second boom with the first pivot pin mounting holes of the equipment (2). Fit the pin and secure it in place;
- align the equipment coupling with the second pivot pin mounting holes of the equipment (3). Fit the pin and secure it in place;
- lubricate both pivot pins;
- connect any hydraulic or electrical systems as indicated in the dedicated sections;
- start the engine and make the cylinder perform two complete movements to check that it runs smoothly.

If there is no abnormal friction or jamming when rotating the equipment, it means the operation has been carried out correctly; otherwise, contact the *Service Centre*.

## 7.3 - Quick-coupling



# **WARNING**

Use only quick-couplings in accordance with current Standards and which allow for the correct coupling of the equipment to be checked from the operator seat, without having to get off the machine.

Before performing any operation, carefully read this manual and the instructions provided by the manufacturer of the quick coupling device.

Perform all coupling and release operations with the bucket or the equipment placed on the ground and make sure that there are no people in the work area before and during the procedure.



## NOTICE

The quick-coupling system increases the overall dimensions of the equipment. Check the operating range of the coupled equipment to avoid the hazard of contact with the protective structure of the machine.

The quick-coupling attachment is an interchangeable device that can be installed on the machine 2nd arm which is used to rapidly replace the end tool/equipment.

The following positions are therefore possible:

- quick dismantling of the tool/equipment being used;
- quick installation of another tool/different equipment.

With the quick-coupling attachment, changing between various tools/equipment, even of different types, is simple and fast.

The quick-coupling is **mechanically operated**.

The control of the **mechanical quick coupling** is of the manual type and it is activated by means of a lever that acts directly on the quick coupling.

For the warnings concerning safety and instructions for operation, always refer to the use and maintenance manual of the manufacturer of the quick-coupling attachment itself.

The machine can be supplied with or without the quick-coupling attachment installed.

To install and remove the quick-coupling attachment, proceed as indicated for the installation of the equipment with standard coupling (pins).

#### 7.4 - Demolition hammer



# **WARNING**

During operation with the demolition hammer, there is a risk of flying splinters and/or debris which may cause serious injuries to the operator.

Do not use the demolition hammer on the roll-bar / canopy version machine without having installed the operator protection front panel (optional).

The machine is prearranged for the installation of a hydraulic demolition hammer.

A suitable breaker must be chosen, bearing in mind its intended use.

The working conditions with a demolition hammer are more demanding that with other equipment.

#### 7.4.1 - Installation and removal

Proceed as indicated in the previous sections according to the type of coupling available on the equipment.

#### 7.4.2 - Precautions for use




# **WARNING**

During the work, flying splinters or debris may hit the operator position or other parts of the machine; take the following precautions and be very careful so as to prevent accidents that may damage the machine and cause injuries to the operator.


During work operations, keep the boom in the position without swing, the demolition hammer must always be in front of the operator, never to the side.

#### RECOMMENDED OPTIONAL EQUIPMENT

Avoid operating with the machine cylinders near their limit stop (maximum extension or retraction), so as not to damage the accessory or the cylinders.




Do not operate with the demolition hammer in a sideways position; the machine will become unstable and the undercarriage components will be subjected to increased wear.




## RECOMMENDED OPTIONAL EQUIPMENT

When operating the machine, take care not to hit the boom or other parts of the machine with the demolition hammer.




Do not use the demolition hammer with the second boom in a vertical position; excessive vibration on the second boom may cause oil leaks.



#### RECOMMENDED OPTIONAL EQUIPMENT

With the boom, apply a force in the same direction of the tip while: approaching the object to be demolished, during the demolition and while moving away from the object.



Do not operate with the demolition hammer for more than one minute in the same spot, since the tip and/or hydraulic mechanism may get excessively worn; if the object does not break within a minute, place the tip on another spot.

## 7.4.3 - Operation

For operating the demolition hammer, refer to section "6.31.3 - AUX1 Auxiliary hydraulic system" to page 6-78. Always consult the manual supplied by the manufacturer of the equipment.



## 8 - MAINTENANCE

This section contains a complete list of requirements and procedures regarding the maintenance of this machine.

Maintenance provides for two types of operations:

- daily: through checks and operations performed every day directly by the operator;
- periodical: through checks and operations performed at specific time intervals by the Service Centre.

See the Periodical Maintenance table for the list of operations and relative time intervals.

Periodical maintenance operations must be performed at authorised *Case workshops*, where the interventions must also be recorded in the special register.

If the information or procedures contained in this chapter are not fully understood, contact your local *Service Centre* for clarifications before proceeding.

Before starting work, make sure that the maintenance work has been carried out on the equipment in use, as described in the Use and Maintenance Manual of the equipment itself.

## 8.1 - Safety



# **WARNING**

Carry out maintenance operations on a sturdy, flat surface.

Maintenance operations must be carried out with the dozer blade and the equipment resting on the ground.

**Do not carry out maintenance when the machine is running. Before any intervention set the machine in safety according to** "8.1.1 - Placement out of service for maintenance" to page 8-5.

Before doing any work on the machine, read the instructions in the manual carefully.

During maintenance operations, observe the precautions printed on the safety signs on the machine.

Do not try to carry out any maintenance unless you have the necessary skills, the right information, the safety tools and the instruments and equipment necessary to do the job properly.

Ensure the equipment used to lift and support the machine is in good working order and withstands the weight of the machine.

**NEVER** carry out any maintenance or servicing work on this machine while the engine is running. Contact with moving or hot parts, or with any high-pressure fluid leaks, may cause serious injury or death.

**Wear appropriate PPE as indicated in** "2.4.1 - Personal Protective Equipment (PPE)" to page 2-16.

Do not wash the electrical components with water jets to avoid the risk of electrical discharges. Washing with water jets can only be carried out with hoods and covers closed.

#### MAINTENANCE

If you are working in dusty environments, reduce maintenance interval times by half.

Failure to comply with the safety regulations and proper maintenance procedures could cause damage or faults on the machine and result in injury or even death of the operator or other persons in the vicinity.

Before starting the machine, clear the area from the machine action range.

Never leave the machine switched on.

Wash the machine regularly and remove all traces of grease, oil and debris, so as to prevent any form of personal injury and machine damage.

Do not spray water or steam inside the cab or anywhere near the driving position.

Clean the machine avoiding to point high-pressure water jets directly at the radiator.

When washing, protect the connectors of the electrical system and do not wet the starting equipment switch.

When working in dusty areas:

- check frequently for air filter blockage;
- clean the radiator and air conditioner condenser (if present) frequently, to prevent the fins from clogging;
- clean the electrical components; in particular, remove any dust from the alternator and starter engine.

Do not use flammable liquids to clean machine components, avoid open flames, and do not smoke.

Keep all grease nipples, breather pipes and areas around the dipsticks particularly clean to prevent any dirt getting in.

Thorough cleaning of the machine will help to identify damaged components more easily.



# **NOTICE**

#### IT IS RECOMMENDED TO USE ORIGINAL SPARE PARTS ONLY.

Do not carry out any procedure, modification or repairs of any kind, except for those indicated in this handbook. Only the Service Centre has the necessary knowledge of the machine and the experience to carry out any intervention with the appropriate technique.

This machine has been assembled using instruments based on the metric decimal system. Use metric tools of the appropriate type and size to carry out maintenance procedures.



CASE recommends waste storage and disposal procedures in respect of the environment. Do not discharge liquids into the ground or drains, or into waste catchment areas. Use suitable containers for the collection of these liquids, then store and/or dispose of them in the safe and approved manner. Check and observe all government and/or municipal regulations regarding the storage, disposal and recycling of waste.

#### 8.1.1 - Placement out of service for maintenance

The **placement out of service for maintenance** procedure must be carried out to deactivate and place the machine in safe conditions during maintenance operations.



# **WARNING**

Before carrying out any maintenance intervention or service on components of the hydraulic system, release any residual pressure.

Before performing any inspections or maintenance operations disable the machine as follows:

- position the machine on a flat, level surface;
- place the equipment and dozer blade on the ground;
- stop the machine;
- Release the pressure of the hydraulic system as described in section "6.30 Discharge residual pressure in the hydraulic system" to page 6-74;
- remove the starting equipment key, which must remain in possession and accessible only to the person performing the maintenance;
- enable the engine shut down safety switch as indicated in section "2.8.5 - Emergency stop button" to page 2-48;
- apply a caution sign (1), **NOT supplied**, near the starting equipment board.



At the end of the interventions, the person in charge of the maintenance operations can restore the machine by following the procedure in reversed order; the machine will therefore be ready for normal operation.

## 8.2 - Tools and equipment for maintenance

Any additional instruments or tools required for maintenance and adjustment purposes, and not included in the tool kit, are included in the following table.

## Key to the following table:

- (1) "Manually" means that the maintenance or adjustment operation can be performed by hand, without using any tools.
- (2) Various tools may be used to tighten the screws and nuts found on the machine.

	PART INVOLVED IN MAINTENANCE	Manually (1)	Hex Keys (2)	Socket wrenches (2)	Tool for oil filter	Torque wrench
UNDERCARRIAGE	Tracks			×		
	Rollers			×		×
	Idle wheel			×		×
	Drive sprocket			×		×
HYDRAULIC	Components	×	×	×		×
SYSTEM	Distributor		×	×		×
	Gear motors		×	×		×
	Radiator	×	×	×		
ELECTRICAL	Alternator		×	×		
SYSTEM	Lighting	×	×			
	Starting system		×	×		

#### 8.3 - Guards

The guards, also called hoods or covers, provide protection against the risks such as high noise level, burns or moving parts.

The inner parts of the machine can be accessed for maintenance through the hoods and covers.

During the operation the guards must be kept closed. The guards present on the machine are listed below.

Their integrity and anchorage must be checked periodically.



# **WARNING**

Do not hold the hood and access covers open when the machine is on a slope or in windy conditions. The hoods and access covers can close accidentally causing personal injury.

#### 8.3.1 - Central compartment hood

The central compartment hood (1) is located in the centre of the machine.


From here one can access: hydraulic oil tank, cooling system, radiator, etc.

### To **open** the hood:

- open the controls cut-out lever;
- insert the key into the lock (2) and turn it counter-clockwise;
- release the lock by pushing the key;
- with your right hand, lift the hood using the dedicated handle (3);
- keep lifting it until it stops and clicks (4);
- release the hood, which is held in the open position by the catch.

#### To **close** the hood:

- with your right hand, lift the hood using the dedicated handle (3);
- at the same time, with your left hand, push the catch (4) inwards;
- lower the hood slowly until the lock can be heard engaged;
- lock the hood by turning the key clockwise and then remove it.





# **CAUTION**

Be very careful when the hood is open as it could close suddenly and cause serious injury to the operator's hands or head.

## 8.3.2 - High voltage compartment guard




# **WARNING**

It is FORBIDDEN to remove the high voltage compartment guard, risk of electrical shock.

The high voltage compartment guard (1) is located under the central compartment hood.

Access to the components of the high voltage compartment is only available to the *Service Centre*.



#### 8.3.3 - Rear cover

The rear cover (1) is located on the rear side of the machine.


From here one can access: charging plugs, fuses and relays.

## To **open** the cover:

- insert the key into the lock (2) and turn it counterclockwise;
- guide the cover upwards until it stops, to open it.

#### To **close** the cover:

- push the cover down until it stops;
- lock the cover by turning the key clockwise and then remove it.



## 8.3.4 - Hydraulic oil tank compartment guard

The hydraulic oil tank compartment guard (1) is located on the right-hand side of the machine.


From here one can access: hydraulic oil filter drain circuit.

## To **remove** the guard:

- unscrew the knobs (2-3);
- remove the guard by extracting it.

## To **refit** the guard:

- rest the guard in the seat so that the holes are aligned with the threads;
- screw in the knobs (2-3).



## 8.3.5 - Document glove box guard

The document glove box guard (1) is located under the driver's seat.


From here one can access: hydraulic oil filter suction circuit, etc.

## To **remove** the guard:

- open the controls cut-out lever;
- open the central compartment hood;
- grab the cover with both hands in the points indicated (2-3);
- pull the guard toward the front of the machine until it is unconnected from the fixings.

## To **refit** the guard:

- align the rubber fixings (4) with the holes on the fixed part of the machine (5);
- push with both hands until it clicks;
- close the central compartment hood.



## 8.4 - Electrical system



# **DANGER**

Before any interventions on the electrical system, carefully read the indicated warnings.

The battery requires no maintenance, so any work on it is prohibited, only the Service Centre can intervene in the event of a fault.



# **WARNING**

### Operations not indicated ARE PROHIBITED.

The maintenance interventions to be carried out on the electrical system are the following:

- check and replace fuses and relays, see section "9.1 Fuses and relays" to page 9-1;
- replace working lights, see section "9.2 Working lights replacement" to page 9-4.

If the cables are damp or their insulation is damaged, the electrical system will leak current and may cause machine malfunction or harm to the operator.

Avoid getting the electrical system wet when washing the machine or if it rains.

If damaged cables are noticed, stop the machine and contact the *Service Centre* for repairs.

When working for many hours on the banks of rivers, lakes or the sea, protect the connectors with suitable anti-corrosive agents.

#### 8.5 - Tracks

Inspect the condition of the tracks periodically and check their tension.

If the track is too tight, there will be more friction on the rolling components and, as a consequence, more power will be needed for travel.

If the track is too loose, there will be more friction while reversing and, as a consequence, more power will be needed for travel. The track may also come out of the guide edges of the rolling components, causing the travel to stop.

Make sure that the tracks have equal tension: a different tension can cause a deviation of the machine from the travel trajectory.

## 8.6 - Refilling

#### 8.6.1 - Refilling quantity table



Before each change or refill of the liquids/oils used by the machine, check to see if the system is filled with mineral or organic products.

Never mix different types of products so as not to alter their characteristics.

For more information on lubricants, see section "8.6.2 - Products for lubrication" to page 8-13.

The filling quantities shown in the table are only indicative values, however, the level indicators are binding.

After each change or refill, check the level of the corresponding group.



Oil and filters are considered to be polluting waste not to be dispersed in the environment and to be recovered and disposed of in accordance with the current anti-pollution regulations.

## **EQUIPPING THE MACHINE FOR THE FIRST TIME**

Refilling	Туре	Brand	Quantity
Hydraulic system	ISO 11158	TUTELA HYDROSYSTEM	15 l
Hydraulic oil tank	L-HV46	46 HV NT	9,5 l
Track tensioner grease nipples	NII CT 2 (*)	ENI	
Joints greasing points	NLGI 2 (*)	TUTELA MOLY GREASE	-

<sup>(\*)</sup> Lithium + Molybdenum bisophlurum.

# EQUIPPING THE MACHINE FOR THE FIRST TIME WITH ECO-FRIENDLY LUBRICANTS

Below is the list of eco-friendly lubricants used; for other fluids, refer to the previous table.

Refilling	Туре	Brand	Quantity
Hydraulic system	ISO 46	PANOLIN	15 l
Hydraulic oil tank	150 46	HLP SYNTH E46	9,5 l
Track tensioner grease nipples	FP 2	PANOLIN	
Joints greasing points	EP Z	BIOGREASE EP 2	-

#### 8.6.2 - Products for Jubrication

The scrupulous observation of the rules for the use of lubricants and products for the operation of the machine, increases the reliability and life of the machine itself.

It is particularly important to comply with the lubricant qualities indicated.

The replacement and lubrication intervals are indicated in section "8.8 - Regular maintenance" to page 8-21.

Do not mix different types of oil, if there is no certainty about the type of oil used, avoid topping up and proceed with changing.

## Filling quantity specifications:

For further information on the filling quantities and specifications on the lubrication and products required for the operation of the machine, refer to section "8.6.1 - Refilling quantity table" to page 8-12.



### Measures for environmental protection

Always adopt and respect the measures for environmental protection.

Comply with the specific national laws.

Before draining fluids from the machine, take precautions to ensure their proper disposal.

## Disposal of used products

Used products and special waste are, for example:

- oils, lubricants, etc.;
- filters, oil filter cartridges, etc.

#### 8.6.3 - Hydraulic system oil

The following maintenance is required on the hydraulic system:

- periodic check of the oil level in the tank;
- periodic replacement of the oil filters;
- periodic oil change.

When seals and O-Rings are removed, replace them with new ones and clean the sealing surfaces well. After the maintenance operations, check the seals and make sure there are no leaks.

When a cylinder or hydraulic system component is removed, bleed out the air as follows after refitting:

- start the machine and run the engine at low speed;
- allow all cylinders to perform their full stroke 4/5 times, slowly and without insisting on the limit switch.

The machine is first equipped with mineral or synthetic eco-friendly hydraulic oil with a high viscosity index. The choice between the two products is made at the request of the customer depending on the intended use of the machine.

Eco-friendly hydraulic oil is suitable for use in environmentally sensitive areas, it reduces the risk of contamination in the event of accidental spillage, while minimising direct and indirect legal consequences, additionally, it has longer drain intervals than mineral oil if the requirements indicated are met.

The use of regenerated or re-refined base oil is not recommended.

Hydraulic oils with characteristics equal to or greater than the following are recommended:

Hydraulic oil type	Performance specifications	Environmental specifications
Mineral	ISO-L-HV DIN 51524 3rd part (HVLP) or ISO 11158:2009 (HV) Viscosity index ≥150 and <170 VICKERS M-2950	No requirement
<b>Eco-friendly</b> (Synthetic ester)	ISO 15380 HEES  Viscosity index ≥145 and <155  Zinc-free  ASTM D943 dry TOST > 3000 h  ASTM D 2070 (mod. 1680 h)  Test FZG A/8.3/90 12° fill level  VICKERS V104 C	Biodegradable as per OCSE 301 B >70% Water hazard class according to VwVwS: WGK1



## **NOTICE**

Always check the correct type of oil for the machine in use by consulting the liquids table.

#### **VISCOSITY OF THE LUBRICATING OIL**

The lubricant oil viscosity is chosen according to the ISO classification.

In order to choose the correct ISO class, knowing the **operating temperature** of the oil is essential.

The ISO classification does not determine the quality of a lubricating oil.

If the viscosity is too high, the hydraulic system may not work correctly or get damaged; if the viscosity is too low, the performance of the machine may be reduced.

The viscosity of the hydraulic oil changes as its temperature changes. The oil can work at a viscosity ranging from 13 to 860 mm<sup>2</sup>/s, the optimum conditions for which maximum performance is achieved occur at a viscosity ranging from 15 to 35 mm<sup>2</sup>/s.

It is difficult to correlate the ambient temperature with the operating temperature of the hydraulic oil, because the operating temperature is linked, in addition to the ambient temperature, to the way the machine is used and to the type of work being carried out. The table below gives the indicative values that can help in the selection of the oil, if in doubt contact the *Service Centre*.

Viscosity	Reference viscosity at +40°C	Ambient temperatur		
class	mm²/s	min. °C	max °C	
ISO VG 32	32	-20	+30	
ISO VG 46	46	-5	+40	
ISO VG 68	68	+5	+50	

### 8.6.3.1 - Requirements for using ecological hydraulic oil

The use of eco-friendly lubricants involves the knowledge and the respect of certain specific procedures that have the purpose of allowing oil change intervals that are much longer than the corresponding mineral oil, while ensuring correct operation of the machine and the protection of its components.

The procedures to be followed are as follows:

- Mixing with other biodegradable oils is NOT permitted.
- Top-ups with mineral oil are NOT permitted.
- The maximum percentage of mineral oil permitted is 5% of the total quantity of filling (resulting from accidental mixing, for example, the use of equipment previously installed on a machine equipped with mineral oil).
- Throughout the working life, pollution with solid materials (debris, dust and the like) should be limited as much as possible, it must not exceed the purity class 21/17/13 (according to ISO 4406). Pay particular attention when changing equipment.
- The water content must not exceed the maximum permissible value of 0.1%.
- The costs of the oil analysis, carried out at the intervals indicated below, are borne by the manufacturer of the oil. The costs of taking and sending samples are excluded.
- The measures indicated by the manufacturer following the oil analysis, such as drainage, filtration and the like, must be complied with. After the measurements have been carried out, an additional control sample must be taken and sent back to the manufacturer.
- In the event of an accidental loss of oil into the environment, immediately take a sample of the oil from the machine and send it to the manufacturer in the same way as for regular testing. This operation will be useful in case of any dispute of contamination by the supervisory bodies.

## 8.6.3.2 - Scheduled plan for analysis and control of eco-friendly hydraulic oil

The planned analysis and control plan consists of taking a hydraulic oil sample at predefined intervals and sending it to the oil manufacturer's laboratory.

The laboratory will check the functional parameters of the sample, issuing a report with the results and indicating whether the oil needs to be replaced.

The oil check intervals are as follows:

Check interval after commissioning/oil change	Normal use	Heavy duty use (example demolition hammer or shredder head)
1st check after	500 hours	200 hours
2nd check after	1000 hours	500 hours
Following checks after	1000 hours or at least once a year	500 hours or at least once a year

The actual need to change the oil will be indicated by the laboratory.



In the absence of regular periodical checks, the replacement interval is the one indicated in the periodical maintenance table.

### 8.6.3.3 - Requirements for the sampling of eco-friendly hydraulic oil

For the procedure for taking the oil sample from the machine, refer to section "8.8.5 - Hydraulic system oil sampling/replacement" to page 8-29.

The following are additional requirements on which the reliability of the oil analysis depends.

#### **CONTAINERS**

Use sterile, new, clean and originally sealed sample containers (500 ml capacity). Containers must have a label with the following data:

- company name;
- machine model;
- machine serial number;
- identification of the content (type of oil);
- sampling date.

To the side is an example of a label and recommended container.



#### **ACCOMPANYING DOCUMENT**

The document accompanying the oil sample must be sent with the sample. In the absence of a correct accompanying document it is not possible to perform an exact evaluation of the sample. An accompanying document must be filled in completely for each sample submitted.

The form for the sample accompanying document is shown below.

An electronic format for printing can be downloaded directly from the PANOLIN website:

www.panolin.com

#### **MAINTENANCE**

Accompanying document for samples of eco-friendly hydraulic oil:

## Oil sample consignment form



Use separate form for each sample Please write in block letters! Please send to: PANOLIN Production AG Tec Center/Laboratory \*Serial/chassis number \_\_\_\_\_ Blaesimuehle 2 - 6 Inventory number/code \_\_\_\_\_ CH-8322 Madetswil of lubricant used \_\_\_\_\_ \*mandatory Machine/vehicle/device Machine, vehicle, type (e.g. power shovel) Oil sampling point ☐ Engine ☐ Compressor ☐ Gearbox ☐ Centralised lubricating system ☐ Axle ☐ Recirculation ☐ Hydraulic Minimess/warm oil ☐ Bottom hydraulic-tank/cold oil ☐ Top hydraulic-tank/warm oil Other \_\_\_ Working time/oil volume \_\_\_\_\_ Working time Kilometer Mileometer reading \_\_\_\_\_ Working time since last oil drain \_\_\_\_\_ \( \sqrt{Working time } \sqrt{Kilometer} \) Top up quantity since last oil drain \_\_\_ Grounds for oil analysis ☐ Oil condition monitoring ☐ Sample after conversion ☐ Sample after filtration/dewatering ☐ Comparison ☐ Other Remarks ☐ by mail ☐ by e-mail Please send the analysis report Name: \_\_\_\_ Signature: \_\_\_ No signature required if sent by email. E-Mail: To be completed by PANOLIN UB-Nr.

## MAINTENANCE

#### **PACKING**

Containers should be placed inside plastic bags to contain any spills. Store the containers inside a cardboard box with filling material to protect the contents.

Samples must be shipped within 48 hours to the following address:

## **PANOLIN International Inc.**

Bläsimühle 2 - 6 CH-8322 Madetswil Switzerland Tel. 044 956 65 65 info@panolin.com

## 8.7 - Tightening torque tables

Refer to these tables when no specific tightening torques are given. The following specifications apply to clamping devices with metric threads supplied, either dry or lubricated with motor oil.

Values are given in Nm, tolerance is  $\pm$  10%.

METRIC COARSE THREADS						
THREAD	8.8	10.9	12.9			
M6	10	14.5	17.5			
M8	25	35	42			
M10	48	68	82			
M12	86	120	145			
M14	135	190	230			
M16	215	300	360			
M18	295	410	490			
M20	410	580	690			
M22	550	780	930			
M24	720	1000	1200			
M27	1040	1450	1750			
M30	1400	2000	2400			

METRIC FINE THREADS						
THREAD	8.8	10.9	12.9			
M8x1	27	38	44			
M10x1.25	52	72	88			
M12x1.25	95	135	165			
M12x1.5	90	125	150			
M14x1.5	150	205	250			
M16x1.5	220	310	380			
M18x1.5	320	460	550			
M20x1.5	460	670	770			
M22x1.5	620	880	1050			
M24x2	800	1100	1300			
M27x2	1100	1600	1300			
M30x2	1500	2100	2500			

## 8.8 - Regular maintenance

The hour meter records the total engine operating hours, and should be used to schedule all the maintenance procedures listed below. Read the hour meter daily.

Refer to the value indicated on the electronic hour meter on the display (if present).

Carry out the assistance interventions respecting the working hours interval or upon expiry of the indicated time limit.

Intervene more frequently if the machine is used in harsh conditions.

## MAINTENANCE

Reference	OPERATION DESCRIPTION	Page	DAILY	EVERY MONTH	AFTER 100 HOURS	EVERY 500 HOURS	EVERY 1,000 HOURS	EVERY 5,000 HOURS
1	Check of safety devices	2-42	•					
2	Check of safety signs	2-5	•					
3	Check of guards	8-7	•					
4	Check of hydraulic oil level	8-25	•					
5	Cleaning of radiator and heat sink	8-23	•					
6	Lubricate pins	8-42	•					
7	Full battery charge	8-34		•				
8	Performance check (speed of machine movements)	8-23			Δ			
9	Hydraulic system operating pressures check	8-23			Δ			
10	Track tension check	8-37			Δ	•		
11	Check that the screws of the drive wheel/ rollers are tight	8-34			Δ	•		
12	Replacement of drain circuit hydraulic oil filter	8-27			Δ	•2		
13	Hydraulic system oil sampling / replacement	8-29					•2*	
14	Replacement of intake circuit hydraulic oil filter	8-31					•2	
15	Electrical test	8-43						•

To be carried out at the indicated work time interval or at the latest within:

 $\mathbf{1} = 1 \text{ year}$ 

2 = 2 years

3 = 3 years

 $\Delta$  = First time only

\* = the change interval may vary, refer to the appropriate section for details

#### 8.8.1 - Performance check

To check the performance (speed of machine movements) and operating pressures of the hydraulic system, contact the Service Centre.

## 8.8.2 - Cleaning of radiator and heat sink



# **WARNING**

**Secure the machine as indicated in section** "8.1.1 - Placement out of service for maintenance" to page 8-5.



# WARNING

Immediately after using the machine, the temperature of the components and of the hydraulic oil may be high and may cause burns, after stopping, wait until the temperature drops below 40°C before proceeding with maintenance operations.




## NOTICE

When the machine is operating in very dusty conditions, check radiator and heat sink for clogging more frequently.

In these conditions the cleaning interval should be halved with respect to the indications given in the periodic maintenance table.

To check the cleanliness of the radiator and heat sink:

- open the central compartment hood (1);
- check the radiator (2) and the heat sink (3);
- if they are dirty with dust, cleaning with a jet of compressed air (max 10 bar) from the outside toward the inside is sufficient;
- if they are clogged, clean them with a brush soaked in a suitable detergent, then dry using a jet of compressed air (max 10 bar) by blowing from the outside toward the inside;
- for better cleaning of the heat sink, use the air jet from the inside toward the outside (4);
- always clean the central compartment with compressed air (max 10 bar);
- close the central compartment hood (1).





## **NOTICE**

Perform this operation whenever the radiator and/or the heat sink, due to accidental causes, are soiled with oil or other greasy or fatty substances, otherwise they may become clogged, reducing their cooling capacity and cause the machine to overheat.

### 8.8.3 - Check the hydraulic oil level



# **WARNING**

**Secure the machine as indicated in section** "8.1.1 - Placement out of service for maintenance" to page 8-5.



# **WARNING**

Immediately after using the machine, the temperature of the components and of the hydraulic oil may be high and may cause burns, after stopping, wait until the temperature drops below 40°C before proceeding with maintenance operations.

#### To **check** the oil level:

- position the machine as indicated in the following figure;
- wait for the oil to cool (temperature below 30° C);
- check on the indicator (1) that the oil level is in the middle;
- if the level is correct, the check is over.




# **WARNING**

Before carrying out any maintenance work on the hydraulic system, the residual pressure must be released as indicated in the specific section.

## If the **level is below** the halfway line:

- open the central compartment hood;
- unscrew the hydraulic oil tank cap (2) by turning it counter-clockwise;
- add more oil according to the type indicated in the liquids table until the level has been reached;
- once oil has been added screw the cap back on following the reverse procedure;
- close the central compartment hood.



#### 8.8.4 - Change discharge circuit hydraulic oil filter



# **WARNING**

**Secure the machine as indicated in section** "8.1.1 - Placement out of service for maintenance" to page 8-5.




# **WARNING**

Immediately after using the machine, the temperature of the components and of the hydraulic oil may be high and may cause burns, after stopping, wait until the temperature drops below 40°C before proceeding with maintenance operations.

Before carrying out any maintenance work on the hydraulic system, the residual pressure must be released as indicated in the specific section.

The drain circuit hydraulic oil filter (1) is housed in the hydraulic oil tank compartment. To **replace** the filter:

- remove the hydraulic oil tank compartment guard;
- unscrew the filter cover (2) and remove it;
- unscrew the old filter (1) and dispose of it in compliance with the applicable standards;
- clean the surrounding area and insert the new filter;
- screw the filter cover;
- make sure that the hydraulic oil level is correct;
- start the machine for a few minutes and then stop it;
- check the level again;
- check for leaks;
- refit the guard.





Old filters and hydraulic fluid are highly pollutant items; do not discard them into the environment, but put them in sealed containers and deliver them to the specialised waste disposal centres.

### 8.8.5 - Hydraulic system oil sampling/replacement



# **WARNING**

**Secure the machine as indicated in section** "8.1.1 - Placement out of service for maintenance" to page 8-5.



# **WARNING**

Immediately after using the machine, the temperature of the components and of the hydraulic oil may be high and may cause burns, after stopping, wait until the temperature drops below 40°C before proceeding with maintenance operations.

Before carrying out any maintenance work on the hydraulic system, the residual pressure must be released as indicated in the specific section.



## NOTICE

The hydraulic oil change operation should be performed when the oil is lukewarm  $(+25 \text{ to } +40^{\circ})$ , as this improves the drainage of the old oil. In lower temperatures, evacuation may be compromised or difficult.

This would cause the mixing of old oil and new oil, resulting in a reduction of the life of the components.

Only use the allowed lubricating oils indicated by the MANUFACTURER in the dedicated table in section "8.6 - Refilling" to page 8-12.

Never start the machine with the tank empty as the pump would certainly be damaged.

For intervals for sampling/replacement of ecological oil, refer to section "8.6.3.2 - Scheduled plan for analysis and control of eco-friendly hydraulic oil" to page 8-17.


If it is suspected that the hydraulic oil contains water, take the sample with the hydraulic system cold (i.e. after downtime of at least 2 days).

## To perform the **sampling** of the oil:

- start the machine and make movements until the hydraulic oil has reached a temperature of approximately +40°C, then stop the machine;
- open the central compartment hood;
- unscrew the hydraulic oil tank filler cap (3);
- using a clean syringe, withdraw 500 ml of oil through the cap (3), ensuring that aspiration takes place at the middle of the level;
- oil samples from different sampling points are NOT allowed.

#### To **replace** the oil:

- open the central compartment hood;
- remove the hydraulic oil tank compartment guard;
- unscrew the screws and remove the right-hand housing (1);
- unscrew the screws and remove the left-hand housing (2);
- unscrew the hydraulic oil tank filler cap (3);
- unscrew the protective caps of the quick-release valves (4-5);
- screw the special drain pipe (6) supplied with the machine onto each valve, making sure that the unthreaded end is inside a suitable container; when screwing in, the valves open, causing the oil to flow out;
- wait for all of the oil to flow out, then dispose of it in compliance with the standards in force;
- unscrew the drain pipes and screw on the protective caps of the quick-release valves (4-5);
- replace the discharge circuit hydraulic oil filter, refer to section "8.8.4 - Change discharge circuit hydraulic oil filter" to page 8-27;
- replace the intake circuit hydraulic oil filter, refer to section "8.8.6 - Replacement of intake circuit hydraulic oil filter" to page 8-31;



#### MAINTENANCE

- fill up with oil, of the type and quantity indicated in the liquids table, until the level is reached as described in section "8.8.3 Check the hydraulic oil level" to page 8-25, and then screw on the cap (2);
- refit the right-hand housing (1) and the hydraulic oil tank compartment guard;
- start the machine and perform all movements several times, extending and closing the cylinders completely to remove the air from the system;
- stop the machine, recheck the level and reset if necessary.



Old filters and hydraulic fluid are highly pollutant items; do not discard them into the environment, but put them in sealed containers and deliver them to the specialised waste disposal centres.

### 8.8.6 - Replacement of intake circuit hydraulic oil filter



## **WARNING**

**Secure the machine as indicated in section** "8.1.1 - Placement out of service for maintenance" to page 8-5.



# **WARNING**

Immediately after using the machine, the temperature of the components and of the hydraulic oil may be high and may cause burns, after stopping, wait until the temperature drops below 40°C before proceeding with maintenance operations.

Before carrying out any maintenance work on the hydraulic system, the residual pressure must be released as indicated in the specific section.



## NOTICE


Never start the machine with the tank empty as the pump would certainly be damaged.

Only use the allowed lubricating oils indicated by CASE in the dedicated table in section "8.6 - Refilling" to page 8-12.

The hydraulic oil filter circuit aspiration is housed inside the central compartment.

### To **replace** the filter:

- open the central compartment hood;
- drain the hydraulic oil as indicated in section "8.8.4 Change discharge circuit hydraulic oil filter" to page 8-27;
- wait for the liquid to flow out completely;
- disconnect the intake sleeve (1);
- unscrew the old filter (2) and dispose of it in compliance with the applicable standards;
- clean the surrounding area and fit a new filter;
- connect the intake sleeve (1);
- close the central compartment hood;
- restore the hydraulic oil level;
- start the car for a few minutes, stop it and check the level again;
- check for leaks.





Old filters and hydraulic fluid are highly pollutant items; do not discard them into the environment, but put them in sealed containers and deliver them to the specialised waste disposal centres.

#### 8.8.7 - Check the condition of hydraulic lines



# **WARNING**

**Secure the machine as indicated in section** "8.1.1 - Placement out of service for maintenance" to page 8-5.



## **WARNING**

Before carrying out any maintenance work on the hydraulic system, the residual pressure must be released as indicated in the specific section.



## **CAUTION**

DO NOT run or otherwise operate the machine if any hydraulic hose or fitting is found to be leaking or visibly damaged. Serious injury could result from contact with hydraulic oil expelled under extreme pressure from hoses or fittings.

Before using the machine, inspect the machine from the outside, and inspect all hydraulic system pipes, hoses and fittings for damage or leaks.

In the doubt of a hidden leak, avoid approaching with your hands but use a piece of cardboard to check for the actual presence of the leak.

If a leak or other damage is found DO NOT use the machine, repair the fault before using the machine.



### NOTICE

When you disconnect a hydraulic component, label the parts so you do not make mistakes when reconnecting the fittings.

### 8.8.8 - Full charge of the battery

To ensure a longer battery life, periodically fully charge the battery, see section "6.15 - Machine charging mode" to page 6-38.


### 8.8.9 - Check that the screws of the drive wheel/rollers are tight



## **WARNING**

**Secure the machine as indicated in section** "8.1.1 - Placement out of service for maintenance" to page 8-5.

Periodically check for loose bolts on the drive gears, track tensioner and track rollers.



### 8.8.10 - Track service position



# **WARNING**

**Secure the machine as indicated in section** "8.1.1 - Placement out of service for maintenance" to page 8-5.




## **WARNING**

There must be present a second person in charge with maintenance so as to supports the operator moves from the ground level while the machine is in track service position.

To carry out a number of maintenance procedures on the undercarriage, the tracks must first be raised off the ground, allowing access and creating some space between the ground and the undercarriage. To raise the machine into the track servicing position, proceed as follows:

- turn the upper part of the structure 180° so that the dozer blade stays behind the operator;
- move the first boom to the central position in front of the operator (if the boom swing or deportè is present);
- lower the dozer blade to the ground and keep pressing the control until the end of the machine is lifted off the ground (1) of about 100 mm;
- Position the second boom so that the boom cylinder is at right angles (90°) to the ground;
- Lower the boom to bring the bucket to the ground (2);
- apply downward pressure on the first boom, and simultaneously extend the second boom as required, so that the front of the machine rises off the ground (3) of about 100 mm. The machine body must be positioned horizontally.





# **WARNING**

DO NOT lift the machine over the indicated limit since it could tilt and damage the hydraulic lines and cause serious injuries.

- Switch off the machine, open the controls cut-out lever outwards and wait for the person on the ground to block the machine safely.



## **WARNING**

Prior to getting off the machine or starting any maintenance interventions, block it in track service position and set it in safety.

The person on the ground must block the machine in a safe condition by placing suitable jacks under the frame of the undercarriage that withstand the entire weight of the machine. While setting the machine in safety, use caution to avoid crushing hazards.

- Get off the machine very carefully since it is in a lifted position;
- once all track maintenance operations are complete, repeat in reverse order the steps of the procedure described to lower the machine from the track maintenance position.

#### 8.8.11 - Track tension check



## **WARNING**

**Secure the machine as indicated in section** "8.1.1 - Placement out of service for maintenance" to page 8-5.

The machine is equipped with a system that allows the tension of the tracks to be adjusted.

If one or both of the tracks is not properly tensioned the following problems may occur:

- uneven tension between the two tracks will make it difficult for the machine to travel in a straight direction, either forwards or in reverse;
- high tension will result in increased pressure on the idler and drive sprocket bearings, causing vibration and leading to premature failure of the tracks;
- low tension may cause the track to slip off the front idler.

Probable causes of a change in track tension are:


- wear of undercarriage components (tracks, drive wheels, idlers, rollers) caused by normal working operations;
- the type of soil on which the machine is positioned, e.g. muddy or compacted soil;
- accumulation of mud, sand or other material on the surface (inside and outside) of the tracks.

Take the following precautions before checking and adjusting track tension:

- place the machine on flat, firm ground, preferably tarmac or concrete;
- ensure that the tracks and undercarriage components are free from foreign bodies.

#### Measurement of track tension:

- Determine a reference point near the centre of each track frame (1), then measure the distance between each reference point and the top of the corresponding track tread (2);
- bring the machine to the track service position as indicated in the dedicated section;
- Re-measure the distance from the same track frame reference points to the corresponding track treads (3);
- Subtract the smaller measurement from the larger (2-3) for each side;
- the result is the track tension value;



- If the result for each side is within the range of values *indicated in the table*, then the tensions are correct.

ТҮРЕ		min	max
Rubber tracks	mm	20	25

- the machine can now be removed from the track service position and placed onto the ground;
- should the tension of the tracks be wrong, see section "8.8.12 Adjusting the track tension" to page 8-39.

### 8.8.12 - Adjusting the track tension



## **WARNING**

**Secure the machine as indicated in section** "8.1.1 - Placement out of service for maintenance" to page 8-5.



# **WARNING**

DO NOT attempt to make any track tension adjustments until the following procedures have been read and clearly understood.

If any uncertainty remains after having read the material, contact the Service Centre immediately for additional information.


Track tension is adjusted by increasing or reducing the grease loading of a hydraulic cylinder (also known as a track tensioner) that applies a thrust to the idler wheel.

Adding grease increases the thrust and tensions the track, removing it has the opposite effect.

Each track has a dedicated adjustment, adjust one at a time.

The tension is adjusted by means of the tension valve, which is accessed by removing a cover (1) located on the outside of the frame of each track.

The valve is equipped with a grease nipple that meets the specifications *given in the table*; a suitable grease pump must be used to increase the tension.



Valve specifications						
Tightening torque	Nm	90				
Max. pump pressure	bar	300				
Pump coupling type		UNI 7663				



# **WARNING**


DO NOT remove the grease nipple on the end of the valve, or attempt to turn the valve body by hand.

The grease may be ejected at a very high pressure and penetrate the skin causing serious injuries to the person or the valve body may be projected and hit the operator causing serious injuries or death.

Always operate WHILST STANDING TO THE SIDE of the valve access hole. DO NOT stand with head, hands or body in front of the valve access hole.

#### To increase track tension

- STAND TO THE SIDE of the valve access cover as shown in figure (2);
- remove the cover (3) located on the track frame;
- using the grease pump, add a small amount of grease to the grease nipple (4) at the end of the valve (5);
- proceed until the tension reaches the indicated value then replace the cover;
- carry out the procedure on the other track, if necessary.
- Start the machine and drive straight ahead for at least 20 m;
- stop the machine and check the tension of the tracks.




If the tension corresponds to the values indicated, the adjustment is complete.

If the tension is still insufficient, repeat the procedure.

If the tension is too high, follow the procedure described below.

#### To decrease track tension

- STAND TO THE SIDE of the valve access cover as shown in figure (2);
- remove the cover (3) located on the track frame;
- using a spanner that allows adequate clearance from the opening, slowly unscrew the valve body (5) counter-clockwise by 0.5/1.0 turn to allow the grease to escape;
- When the tension reaches the indicated value, screw the valve in a clockwise direction with the indicated tightening torque, then replace the cover;
- carry out the procedure on the other track, if necessary.
- Start the machine and drive straight ahead for at least 20 m;
- stop the machine and check the tension of the tracks.



If the tension corresponds to the values indicated, the adjustment is complete.

If the tension is still too high, repeat the procedure.

If the tension is insufficient, follow the procedure described above.

#### 8.8.13 - Translation motors and rotation gear motors

The translation motors and the rotation gear motor are lubricated internally by the same hydraulic oil as the machine system. Therefore, these components require no maintenance.

#### 8.8.14 - Lubrication of pins



## **WARNING**

**Secure the machine as indicated in section** "8.1.1 - Placement out of service for maintenance" to page 8-5.



### NOTICE

Only use the allowed lubricating greases indicated by CASE in the dedicated table in section "8.6 - Refilling" to page 8-12.

Couplings between certain parts of the machine must be lubricated using grease, inserted via special accessories called grease nipples (in accordance with UNI 7663).

Clean the grease nipples before attaching the grease gun.

Clean off any excess worn grease after lubrication.


If you use the machine under critical operating conditions, carry out this maintenance task more frequently.

As a general rule it is well to remember that each cylinder has two grease nipples located on the connecting hitch and that each pin that acts as a pivot for movement has at least one grease nipple.


After working with machine parts immersed in water, lubricate pins that have been in contact with water.

#### To **lubricate** the machine:

- position the machine as shown in the figure;
- lower the equipment to the ground, then stop the machine;
- Grease nipples are located at the points indicated by the grease nipple label on the machine and shown below.



#### LUBRICATION



#### 8.8.15 - Electrical test



The permissible operations on the electrical system are indicated in section "8.4 - Electrical system" to page 8-11.

### Operations not indicated ARE PROHIBITED.

In order to ensure correct operation of the machine and the safety of the operator, a test of the electrical system must be carried out periodically.

This procedure must be carried out and registered with the Service Centre.

### 8.9 - Long inactivity periods

For battery precautions refer to section "6.14 - Battery power" to page 6-36.

If **long periods of inactivity** are expected (longer than **1 month**), the battery should be fully charged every month to keep it in good condition and prevent it from deteriorating.

If **long periods of inactivity** (over **6 months**) are expected, in addition to the instructions provided above, to keep the machine in efficient condition and prevent it from deteriorating, it is advisable to hospitalise it in a sheltered place and take the following measures:

- park the machine on a flat, solid surface (e.g. concrete floor);
- inspect the machine. Repair any damaged or worn parts. Replace with new parts where necessary;
- carry out a complete and thorough cleaning;
- place the machine in a dry, covered location. If it cannot be placed in a covered area, select flat, compact ground and protect it with a waterproof sheet arranged to allow ventilation. Otherwise condensation could form, which is harmful to the machine;
- the ambient temperature of the machine's place of storage must comply with the instructions given in this manual;
- preferably retract all cylinders. Otherwise, cover any exposed parts of the cylinder rods in grease;
- grease the hydraulic cylinder rods and all the equipment joints;
- lubricate all greasing points;
- paint all vulnerable parts to prevent any rust formation.

### To restore the machine operation follow the procedure below:

- remove any grease from the hydraulic cylinder rod;
- fully charge the power battery;
- carry out all the periodic maintenance indicated in the special table, see section "8.8
   Regular maintenance" to page 8-21;

- when a vehicle stands idle for an extended period, the humidity in the air could get into the oil. Make sure that the oil does not contain water before and after starting. If any water is found in the oil, replace the oil;
- before moving the machine, check that the instruments, indicator lights and working lights are working properly;
- check the condition of all hoses and connections;
- carry out complete cycles of all the hydraulic functions several times.

#### 8.10 - Long-term storage

If you decide to permanently decommission the machine, dispose of it in accordance with the laws in force in the country of use.



## **WARNING**

The disposal of the machine must be undertaken exclusively by suitably trained and qualified personnel authorised to carry out this operation.

Commence with the dismantling of hydraulic components only once these, as well as the hydraulic oils and lubricants, are completely cool and after any residual pressure has been vented.

Prior to commencing any dismantling operations, drain all the components supplied with the machine, tanks and systems, of all fluids in accordance with the GENERAL SAFETY STANDARDS.

Below is a non-exhaustive list of the pollutants and components in the machine:

- fluids (hydraulic system oil);
- gas (accumulator);
- acid (service batteries);
- lithium batteries;
- plastic material (tracks, coverings, etc.).



Break down the machine into homogeneous parts, do not disperse the polluting products in the environment, but deliver them to the appropriate collection centres where they will be disposed of according to the laws in force.



**PAGE LEFT INTENTIONALLY BLANK** 

### 9 - ELECTRICAL PARTS



## **WARNING**

Before working on the electrical system, make sure that the machine is stopped and wear suitable PPE.

Before carrying out any work on the electrical system, carefully read all the instructions given in section "8.4 - Electrical system" to page 8-11.

### 9.1 - Fuses and relays



## **WARNING**


**Secure the machine as indicated in section** "8.1.1 - Placement out of service for maintenance" to page 8-5.

The fuses protect the electrical components and wiring against damage. The relays are used to activate the high power circuits.


If a fuse or a relay appear to be rusty, or are loose in their holders, fit new ones immediately.

Always replace a fuse with another of the same capacity.

The fuses and relays are located inside the rear compartment (1).




### 9.1.1 - Fuses



### **List of fuses**

1	F21	2A 12V monitoring fuse
2	F22	10A Solenoid valve control unit power fuse
3	F23	15A Fan controller fuse
4	F24	10A Fuse horn
5	F25	10A Lights line fuse
6	F26	3A Main line auxiliary relay coils/lights fuse
7	F27	5A Buffer battery charge fuse
8	F28	5A 12V emergency line fuse
9	F29	5A Satellite/display direct lines fuse
10	F30	5A Cigarette lighter socket power (resettable) fuse

### 9.1.2 - Relays



### List of relays

1	R1	Solenoid valve control unit line relay		
2	R2	Horn relay		
3	R3	Front lights relay		
4	R4	Working lights relay		
5	R5	Optional relay		

### 9.2 - Working lights replacement



## **WARNING**


**Secure the machine as indicated in section** "8.1.1 - Placement out of service for maintenance" to page 8-5.


The working lights are LED type, in the event of a fault, the entire lamp must be replaced.

Before replacing the working light, check that all the fuses and relays are in good working order.

### To **replace** the working light:

- position the machine on a flat, level surface;
- place the equipment and dozer blade on the ground;
- stop the machine;
- activate the emergency stop button;
- if the working light is not accessible from the ground, use a suitable ladder according to the standard;
- disconnect the electrical connector (1);
- unscrew the mounting screw/s (2);
- remove the damaged working light;
- to fit the new working light, follow the procedure described in reverse order.





The manufacturer and its authorized representative reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions, and illustrative material herein are as accurate as known at the time of publication, but are subject to change without notice.

Availability of some models and equipment builds varies according to the country in which the equipment is being used. For exact information about any particular product, please consult your Case dealer.

© 2023 CNH Industrial Italia S.p.A. All Rights Reserved.

Case is a trademark registered in the United States and many other countries, owned by or licensed to CNH Industrial N.V., its subsidiaries or affiliates.

Any trademarks referred to herein, in association with goods and/ or services of companies, other than owned by or licensed to CNH Industrial N.V., its subsidiaries or affiliates, are the property of those respective companies.

